UNCLASSIFIED



AD NUMBER

AD-486 295

NEW LIMITATION CHANGE

TO

DISTRIBUTION STATEMENT - A

Approved for public release; distribution is unlimited

LIMITATION CODE: 1

FROM No Prior DoD Distr Scty Cntrl St'mt Assigned

AUTHORITY

AFFDL, Oct 12, 1970.

19990303 142

THIS PAGE IS UNCLASSIFIED

MATRIX ANALYSIS METHODS FOR ANISOTROPIC INELASTIC STRUCTURES

W. R. JENSEN W. E. FALBY N. PRINCE

GRUMMAN AIRCRAFT ENGINEERING CORPORATION

TECHNICAL REPORT AFFDL-TR-65-220

APRIL 1966

AIR FORCE FLIGHT DYNAMICS LABORATORY RESEARCH AND TECHNOLOGY DIVISION AIR FORCE SYSTEMS COMMAND WRIGHT-PATTERSON AIR FORCE BASE, OHIO

This document is subject to special export controls and each transmittal to foreign governments or foreign nationals may be made only with prior approval of AFFDL (FDTR), Wright-Patterson Air Force Base, Ohio 45433.

NOTICES

When Government drawings, specifications, or other data are used for any purpose other than in connection with a definitely related Government procurement operation, the United States Government thereby incurs no responsibility nor any obligation whatsoever; and the fact that the Government may have formulated, furnished, or in any way supplied the said drawings, specifications, or other data, is not to be regarded by implication or otherwise as in any manner licensing the holder or any other person or corporation, or conveying any rights or permission to manufacture, use, or sell any patented invention that may in any way be related thereto.

Copies of this report should not be returned to the Research and Technology Division unless return is required by security considerations, contractual obligations, or notice on a specific document.

MATRIX ANALYSIS METHODS FOR ANISOTROPIC INELASTIC STRUCTURES

W. R. JENSEN W. E. FALBY N. PRINCE

This document is subject to special export controls and each transmittal to foreign governments or foreign nationals may be made only with prior approval of AFFDL (FDTR), Wright-Patterson Air Force Base, Ohio 45433.

FOREWORD

This report, prepared by the Grumman Aircraft Engineering Corporation, Bethpage, New York, covers work performed under Air Force Contract AF 33(615)-2260. The contract was sponsored by the Air Force Flight Dynamics Laboratory of the Research and Technology Division, Air Force Systems Command, Wright-Patterson Air Force Base, Ohio. It was accomplished under Project No. 1467, "Structural Analysis Methods," Task 146701, "Stress-Strain Analysis Methods for Structures Exposed to Creep Environment." The work was administered by Mr. Laszlo Berke, FDTR, Project Engineer. The report covers work conducted from January 1965 to October 1965. The manuscript was released by the authors in February 1966 for publication as an RTD Technical Report.

The investigation was supervised by Dr. Warner Lansing, Chief of Structural Mechanics. The computer programming was carried out by Mr. Albert Davidson. Some preliminary elastic analysis data were automatically generated by the ASTRAL, Automated STRuctural Analysis program developed by Mr. Philip Mason.

The work of Dr. T. J. Mentel on the evaluation of procedures for carrying out inelastic analyses, and on the formulation of the biaxial stress procedure is also acknowledged. His "Instability Analysis of the Constant Stress and Constant Strain Methods" is reproduced from Reference 6 in Appendix III.

Acknowledgements are made to Drs. Gabriel Isakson and Harry Armen of the Grumman Research Department for their suggestions and review of certain portions of this work.

All computations were carried out at the Grumman Computing Center.

This technical report has been reviewed and is approved.

FRANCIS J. JANIK, JR.

Chief, Theoretical Mechanics Branch

Structures Division

ABSTRAC'I'

Most aerospace structural materials exhibit some degree of anisotropic strain hardening. During the past few years, several methods have appeared in the literature for introducing inelastic isotropic material behavior effects into existing matrix analysis procedures using the incremental theory of plasticity. A review is presented of these methods and a step-by-step routine known as the "constant strain" method is selected for the development of an anisotropic inelastic procedure.

A simple truss with one redundant is used to indicate the basic ideas of the approach. Then the procedure is generalized to the more important case of biaxially stressed structures. Nodal stresses are evaluated step-wise for increasing load through the use of an influence coefficient equation. The inelastic (plastic and creep) strains at one load level are used as initial strains at the subsequent level to account for nonlinear effects. The anisotropic behavior is considered by using a proposed extension of Hu's strain hardening theory.

Several analyses of an aluminum alloy (2024-T4) shear lag structure, which has been tested previously for the Air Force, are carried out, first assuming isotropic and then anisotropic material properties. The correlation between test results and those predicted by isotropic theory is reasonably good. The anisotropic analysis gives predicted results which are in slightly more consistent agreement with the test data.

The procedure is also modified to give an isotropic deformation theory solution, which produces numerical results in a much shorter computer time than required for the incremental theory solution. In the case of the shear lag structure investigated, the results by the two theories are in very close agreement.

Creep test results of an 1100-F aluminum shear lag structure are also available. An analysis of this structure by the proposed incremental method is carried out and its predictions too are in reasonably good agreement with the test data. The 1100-F material is very nearly isotropic and no testing of structures exhibiting anisotropic creep is known to have been performed. Hence the anisotropic creep capability of the proposed method cannot be checked out against tests at this time. A sample calculation is nevertheless carried out for a hypothetical material having this characteristic.

The approach presented, which is simple in concept and execution, is found to be a reasonably good phenomenological model of an exceedingly complex physical problem. The accompanying digital computer program is believed to be very versatile, and well suited for the inclusion of any other types of material nonlinearity that may be of interest.

PREVIOUS PACE WAS BLANK, THEREFORE NOT FILMED

TABLE OF CONTENTS

SECTION		PAGE
ı	INTRODUCTION	1
II	INELASTIC MATRIX METHODS	. 3
· · · · · · · · · · · · · · · · · · ·	A. Formulation	3
` .	B. Example Problem	Ĭį.
	C. Step-by-Step Methods	6 6
	D. Constant Stress Method E. Constant Strain Method	7
III	ISOTROPIC ELASTIC-PLASTIC ANALYSES	8
	A. Biaxial Theory	8
	B. Determination of Calculation Step Size	11
	C. Description of Shear Lag Structure	11
	D. Elastic Shear Lag Structure Analysis	12
	E. Flow Theory Shear Lag Structure Analysis	12
	F. Deformation Theory Analysis	13
IA	ISOTROPIC ELASTIC-PLASTIC-CREEP ANALYSIS	15
	A. Introduction to Creep Theory	15
	B. Creep Theory Details	15
	C. Description of Structure and Tests	16
	D. Results of Creep Shear Lag Analysis	17
V	ANISOTROPIC ELASTIC-PLASTIC ANALYSIS	19
	A. Anisotropy in Structures	19
	B. Hu's Strain Hardening Theory	19
	C. Extension of Hu's Theory	22
	D. Anisotropic Theory Details	23
	E. Rotation of Axes of Anisotropy	24
•	F. Anisotropic Analysis of Shear Lag Structure	25
	G. Discussion of Results	27
VI	ANISOTROPIC ELASTIC-PLASTIC-CREEP ANALYSIS	29
	A. Anisotropic Creep Theory	29
	B. Sample Problem	29
AII	CONCLUSIONS	31
VIII	FIGURES	44

TABLE OF CONTENTS (continued)

PENDIX		PAGE
I	ELASTIC ANALYSIS OF SHEAR LAG STRUCTURE	61
	 A. Idealization of Shear Lag Structure B. Force Method C. Stiffness Method D. Comparison of Elastic Results and Perspective 	61 61 61 62
II	POISSON'S RATIO EFFECT	63
III	INSTABILITY ANALYSIS OF THE CONSTANT STRESS AND CONSTANT STRAIN METHODS	65
IA	ROTATION OF AXES OF ANISOTROPY	72
v	INELASTIC MATRIX COMPUTER PROGRAM	75
	A. Program Description B. Symbols and Format of Data Cards C. Anisotropic Parameter Matrices D. Restart Procedure E. Time Estimates F. Sample Data Form G. Flow Charts H. Fortran Program	75 77 81 81 82 83 92
VI	STRESS DISTRIBUTIONS DUE TO UNIT INTIIAL STRAINS	115
	A. Force Method B. Stiffness Method	115 119
	REFERENCES	123

LIST OF ILLUSTRATIONS

FIGURE	TITLE	PAGE
1	Truss Structure	34
2	Constant Stress Method	34
3	Constant Strain Method	34
4	Results of Constant Stress Method for Bar No. 3 of Truss	35
5	Results of Constant Strain Method for Bar No. 3 of Truss	- 35
6	Shear-Lag Specimen Designated SLS1 - From Air Force Report No. RTD-TDR-63-4032; 2024-T4 Aluminum Alloy (1100-F Specimen Similar)	36
7	Stiffness Method Idealization	36
8	Force Method Idealization	36
9	Typical Elements of Force Idealization	37
10	Typical Elements of Stiffness Idealization	37
11	2024-T4 Aluminum Alloy Stress-Strain Data and Curve RO2M	38
12	Comparison of Predicted Effective Stress- Strain Relationship with RO2M at (0, 0) for Various Load Increments	38
13	Instrumentation of 2024-T4 Aluminum Alloy Specimen	39
14	Elastic Strains Along x-Axis for P = 1 lb	40
15	Elastic Strains Along $x = 0.8125$ in. for $P = 1$ lb	40
16	Strains Along x-Axis for $P = 11,600$ lb and $\Delta P = 5$ lb	41
17	Strains Along $x = 0.8125$ in. for $P = 11,600$ lb and $\Delta P = 5$ lb	41
18	Strains Along x-Axis for $P = 14,600$ lb and $\Delta P = 5$ lb	42
19	Strains Along x = 0.8125 in. for P = 14,600 lb and ΔP = 5 lb	42
20	Strains Along x-Axis for $P = 16,760$ lb, and $\Delta P = 5$ lb	43
21	Strains Along $x = 0.8125$ in. for $P = 16,760$ lb and $\Delta P = 5$ lb	43

LIST OF ILLUSTRATIONS (continued)

FIGURE	TITLE	PAGE
22	Elastic-Plastic Strains at (0, 0) for Several Assumed Stress-Strain Curves	1414
23	The Strain Hardening Rule	45
24	1100-F Aluminum Time-Dependent Behavior and Fitted Curves (Reference 7)	46
25	1100-F Aluminum Stress-Strain Data at Room Temperature and at 206°C, for Time t = 0.00	47
26	Location of Strain Gages on 1100-F Specimen (Reference 7)	47
27	Strains Along x-Axis for $P = 1600$ lb and $t = 0.06$ hr	. 48
28	Strains Along $x = 1$ in. for $P = 1600$ lb and $t = 0.06$ hr	48
29	Strains Along x-Axis for $P = 2020$ lb and $t = 1.10$ hr	49
30	Strains Along $x = 1$ in. for $P = 2020$ lb and $t = 1.10$ hr	49
31	Strains Along x-Axis for $P = 2020$ lb and $t = 3.0$ hr	50
32	Strains Along $x = 1$ in. for $P = 2020$ lb and $t = 3.0$ hr	50
33	Effective Stress vs Strain at Center Node	51
3 ¹ 4	Total (Elastic, Plastic and Creep) Strains at Center of Specimen (Gage 1) for P = 1600 lb to Time 1 hr, then P = 2020 lb to Time 3 hr	52
35	Total (Elastic, Plastic and Creep) Strains at (1.0 in., 3.0 in.) (Gage 8) for P = 1600 lb to Time 1 hr, then P = 2020 lb to Time 3 hr	53
36	Typical Uniaxial Stress vs Plastic Work, w, Plot	54
37	Assumed Effective Stress (y-y) Curve, Calculated x-x Curves and Test Data	55
38	Node Strains at (0, 0) - Isotropic and	56

LIST OF ILLUSTRATIONS (continued)

FIGURE	TITLE	PAGE
39	Strains Along x-Axis for P = 16,760 lb - Isotropic and Anisotropic Analyses	57
40	Strains Along $x = 0.8125$ in. for $P = 16,760$ lb - Isotropic and Anisotropic Analyses	57
41	Strains Along x-Axis for $P = 2020$ lb and $t = 3.0$ hr - Isotropic and Anisotropic Analyses	58
42	Strains Along $x = 1$ in. for $P = 2020$ lb and $t = 3.0$ hr - Isotropic and Anisotropic Analyses	58
43	Elastic Stress Distribution Along x-Axis	59
71	Elastic Stress Distribution Along $x = 0.8125$ in.	60

SYMBOLS

[]	Rectangular matrix
{ }	Column matrix
q ₁	Member load, any load acting directly on a member
$\sigma_{\mathbf{u}}$	u ordinary stress component (normal or shear) at a node point
°3N-2, °3N-1, °3N	The normal stress components and shear stress component at node N - another designation for $\boldsymbol{\sigma}_u$
$\bar{\sigma}_{ m N}$	Effective stress at node N
o* N	Relaxed effective stress at node N
σ _o	Reference stress in Ramberg-Osgood Equation
$\Gamma_{ m um}$	u th stress component in linear redundant structure due to the m th unit applied load
$\Gamma_{f uv}$	u^{th} stress component in linear redundant structure due to the v^{th} unit initial strain
$\Gamma_{ ext{im}}$	i th member load in the redundant structure due to m th applied load
r _{ij}	i th member load in the redundant structure caused by a unit initial strain at the j th member load
P _m	m applied load
e _v ,	v component of initial strain
e(p)_v	v component of plastic strain
€(c) _v	v th component of creep strain
$\overline{\epsilon}(p)_{N}$	Effective plastic strain at node N
(c) _N	Effective creep strain at node N
E	Total (elastic, plastic, and creep) strain component
\mathcal{E}_{xy}	Engineering shear strain
Ę	Error
E	Young's modulus

T	Temperature
t*	Equivalent time at start of creep cycle calculation
Δt	Cycle duration (elapsed time)
α,β,γ	Material constants in creep strain equation
α _{ij}	Subscripted anisotropic parameters ,
Δ	Increment (prefix)
n,0	Nonlinear parameters in Ramberg-Osgood equation
k	Cycle designation, superscript
n	Nodal index
u,v	Nodal stress component or strain component index, related to the nodal index as indicated in equation
Y _{ij}	Simple directional characteristic stress
oxx, oyy	Uniaxial stress in the x-x, y-y direction
exx, eyy	Plastic strain in the x-x, y-y direction due to uniaxial x-x, y-y stress
σ _{xy}	Shear stress in x-y plane
, XX	Shear strain in x-y plane

SECTION I

INTRODUCTION

With the introduction of high-speed, large-capacity, digital computers, a number of investigators (References 1,4,7) have adapted essentially linear matrix analysis methods to the solution of redundant structures where nonlinear material plasticity and creep properties are considered. These methods have been either iterative or non-iterative step-by-step numerical procedures.

The present work is an effort to explore, revise, and extend the matrix method of analysis in order to apply it to a range of practical aerospace structural problems exhibiting inelastic isotropic or inelastic anisotropic material behavior. Thus, the intent is to concentrate upon methods which are able to predict inelastic strain distributions in irregular idealized structures in a biaxial stress state where materials exhibit strain hardening and creep properties representative of those employed in aerospace construction.

A discussion of complete load reversal, although desirable for plastic fatigue studies, is not included because the theoretical foundation for such a procedure is apparently not yet fully developed. The present formulation of elastic, plastic and creep loading, followed by elastic unloading, while restrictive, is nevertheless of practical interest.

Of the proposed analytical methods, one by Denke (Reference 1) has developed naturally from the matrix force method of analysis and consists of including nonlinear plastic and creep terms in the equations for the gaps at those cuts which are required to make the structure statically determinate. The redundant forces, required to close the gaps and make the structure continuous, are obtained by solving these nonlinear equations by a Newton-Raphson procedure.

A second method reported by Kobayashi and Weikel (Reference 2) has been developed from the direct stiffness method. Here, forces occurring as a consequence of the inelastic effects are included in the nodal force equations. The nodal displacements (or displacement rates, where creep is considered) obtained by solving these equations impose equilibrium at the nodes under the action of internal loads, surface tractions, and prescribed displacements.

When the inelastic effects are accounted for by a flow (or incremental) theory, the deformation is an accumulation of increments each governed by the prevailing stress. Thus, when either of the methods just described is used, one must obtain (for the governing equations) a series of solutions, with one solution corresponding to each load increment. This requires a considerable amount of computer time even for medium-sized analyses.

The approach recommended here, in addition to being conceptually simple, does not require repeated matrix inversions. It was developed from that proposed by R. Gallagher, J. Padlog and others at Bell Aerosystem (References 3,4). Input data, as in the case with these other nonlinear analyses, are generated by an elastic analysis; however, for this approach, either the matrix force method or direct stiffness method can be used. The problem, formulated in terms of standard influence coefficients for applied load and initial strain, is reduced from a nonlinear to a linear one by using those strains obtained at the previous load level to approximate the current inelastic strains.

Development of the anisotropic analysis is based on an extension of the proposed anisotropic theory of Hu, Reference 11. The constant-anisotropic-coefficient assumption of Hu is replaced by one in which the coefficients are allowed to vary with the level of stress. The formulation is then a simple modification of the isotropic procedure. It is also shown that anisotropic creep can be included in a manner similar to the isotropic creep.

SECTION II

INELASTIC MATRIX METHODS

A. Formulation

An inelastic structural analysis can be carried out in two steps. The first is the standard elastic solution where internal stresses and accompanying strains are related through Hooke's law. The second step, the modification of this elastic system to include inelastic strains, is analogous to a procedure for including superimposed thermal strains. The inelastic strains are defined as the differences between the total strains and the elastic strains and are generally functions of the final stresses, not those of the linear, elastic state.

The simple, pin-jointed, single-redundant truss, pictured in Figure (1), illustrates the basic notions more clearly. All bars are considered to be elastic, except the vertical diagonal which can become plastic and has a stress-strain relation represented by the curve shown in Figure (2). The applied load P is large enough to cause member 3 to become plastic.

A solution might be obtained by first simply ignoring plastic strain in member 3 and assuming all members elastic. The resulting stress would then be of magnitude σ . The actual stress for member 3, of lower magnitude due to plastic yielding, is designated $\sigma^{(k)}$ and the associated inelastic strain $\varepsilon^{(k)}$ in Figure (2). These stresses and strains are related in the following equation.

$$\sigma^{(k)} = \sigma + \Gamma \varepsilon^{(k)} \tag{1}$$

where:

 $\sigma^{(k)}$ is the actual final stress

σ is the elastic stress

 $\epsilon^{(k)}$ the inelastic strain

τ the redundant elastic stress for a unit value of initial strain

To be more specific Γ is equal to the redundant stress in member 3 corresponding to a unit initial strain in member 3. Note that Γ must be negative to cause a reduction of stress in the diagonal member.

An important feature to be observed about Equation 1 is that, since the inelastic strain $\epsilon^{(k)}$ is a nonlinear function of the final stress $\sigma^{(k)}$, this equation is really a nonlinear relation to be solved

for $\sigma^{(k)}$. This characteristic will always be present in the analyses to be discussed in this report.

Equation 1 can be generalized to provide stresses in all members of the structure and provide for inelastic strains in all members for a variety of applied loads. This basic influence coefficient equation* is as follows:

$$\{\sigma_{ij}\} = [\Gamma_{ijm}]\{P_m\} + [\Gamma_{ijm}]\{\epsilon_{ij}\}$$
 (2)

The σ_u 's are the ordinary stress components at the various node points of the structure. An element of $[\Gamma_{um}]$ gives the u^{th} stress in the linear redundant structure due to a unit m^{th} applied load, and $\{P_m\}$ represents the actual applied loads. Also, an element of $[\Gamma_{uv}]$ gives the u^{th} stress component in the linear redundant structure due to a unit initial strain at the v^{th} stress location in the unloaded, statically determinate structure. Finally, an element of $\{\varepsilon_v\}$ represents the actual initial strain at the v^{th} stress location.

B. Example Problem

Continuing our study of the simple truss example of Figure (1), we now allow all members to go plastic. The exact results for the deformation and stresses in the truss, for nonlinear properties, are easily obtained by direct numerical solution of the equations, and hence will be used without development.

The step-by-step finite element method for determining the stresses $\{\sigma_u\}$ and strains $\{\varepsilon_v\}$ involves the use of Equation 2 and a nonlinear stress-strain relation. This relation will be assumed to be a piecewise linear approximation of the Ramberg-Osgood stress-strain relation.

$$\mathcal{E} = \frac{\sigma}{E} + \epsilon$$

^{*}The derivation of matrices $[\Gamma_{ijm}]$ and $[\Gamma_{ijv}]$ is given in Appendix VI.

where & denotes the inelastic (or plastic) strains and is given by

$$\epsilon = \frac{3}{7} \left(\frac{\sigma}{\sigma_o} \right)^{\theta - 1}$$

and where

€ = total strain

σ = member stress

E = Young's modulus

σ = reference stress (stress at secant modulus of 0.7E)

θ = nonlinear parameter

The first step, in applying the finite element method, is to obtain the influence coefficient matrices $[\Gamma_{um}]$ and $[\Gamma_{uv}]$ for the linear, redundant structure. This requires specification of the geometry of the structure and the (linear) material properties of the individual structural elements. The geometry of the example truss problem is given in Figure (1). The material is assumed to be an aluminum alloy with the following constants.

$$E = 10^7 \text{ psi, } \sigma_0 = 10^5 \text{ psi, } \theta = 10$$

The approximate stress-strain curve used matches the Ramberg-Osgood values at 2000 psi stress intervals.

In this case, we find

$$[\Gamma_{um}] = \begin{bmatrix} .207 \\ -.293 \\ .707 \end{bmatrix}, [\Gamma_{uv}] = 10^7 \times \begin{bmatrix} -.414 & .207 & .207 \\ .586 & -.293 & -.293 \\ .586 & -.293 & -.293 \end{bmatrix}$$

for the case of the single applied load P.

C. Step-by-Step Methods

The development herein is discussed only in the detail necessary to analyze the redundant truss of Figure (1) being loaded for the first time into the plastic range. Generalization to biaxial plasticity and creep phenomena are discussed in the succeeding sections.

The step-by-step procedure for solving the problem is introduced by rewriting Equation 2 in the form

$$\left\{\sigma_{\mathbf{u}}^{(\mathbf{k})}\right\} = \left[\Gamma_{\mathbf{u}\mathbf{m}}\right] \left\{P_{\mathbf{m}}^{(\mathbf{k})}\right\} + \left[\Gamma_{\mathbf{u}\mathbf{v}}\right] \left\{\varepsilon_{\mathbf{v}}^{(\mathbf{k}-1)}\right\} \tag{3}$$

where

k is the cycle designation

This can be regarded as the fundamental equation for the non-iterative, step-by-step methods. The idea in formulating this equation, as indicated by the cycle designating superscript is that the initial strains of the previous cycle can be used to approximate the initial strains of the current cycle. The strains of the previous cycle may be incorporated in several ways, two of which constitute the constant stress and the constant strain methods of analysis.

D. Constant Stress Method

As indicated previously, in the step-by-step procedure considered here, one enters the kth cycle with applied loads $\left\{P_{m}^{(k)}\right\}$ and initial strains $\left\{\varepsilon_{v}^{(k-1)}\right\}$, the latter evaluated during the preceding cycle.

^{*}These methods make use of devices previously used by others to solve inelastic problems; for example, S. S. Manson at the Lewis Research Laboratory, NASA, Cleveland, Ohio, has previously carried out inelastic analyses of turbine discs involving somewhat similar techniques (Reference 5).

The first operation of the current cycle is to determine $\{c_u^{(k)}\}$ from Equation 3 by direct substitution. The second operation is a determination of $\{\epsilon_v^{(k)}\}$ for use in the next cycle. The constant stress method does this in the most obvious way, by reading from the given stress-strain curve the plastic strains $\{\epsilon_v^{(k)}\}$ corresponding to the $\sigma_u^{(k)}$'s (the reason for the name "constant stress" is thus apparent). The operation is indicated schematically in Figure (2).

The results of the application of this method to the example truss problem are shown in Figure (4), where the stress in the vertical member (Bar #3) has been plotted versus load. These results display a striking defect of the method due to the development of a sudden and catastrophic divergence, whose onset depends upon step size. This dependence is such that any attempt to improve accura by reducing step size only hastens the occurrence of divergence. An anation of this behavior is given in Appendix III. Because of this defect, the constant stress method in this form must be eliminated from consideration as an acceptable method for general use.

E. Constant Strain Method

The first operation of the constant strain method is exactly the same as the first operation of the constant stress method; $\sigma_{\rm u}^{(k)}$ is evaluated by direct substitution in Equation 3. Thereafter, one determines $\varepsilon_{\rm v}^{(k)}$ for use in the next cycle as follows. Referring to Figure (3), for each member, point A is determined with stress-strain coordinates $\sigma_{\rm u}^{(k)}$ and $\sigma_{\rm u}^{(k)}/{\rm E}+\varepsilon_{\rm v}^{(k-1)}$. A relaxed stress $\sigma_{\rm u}^{*(k)}$ is now calculated with the same total strain, corresponding to point B on the given stress-strain curve. Note that here the total strain, rather than stress, remains unchanged—hence the name "constant strain" method. The required initial strain $\varepsilon_{\rm v}^{(k)}$ is the inelastic strain $\varepsilon^{(k)}$ corresponding to the relaxed stress, as indicated on Figure (3).

The results of applying the constant strain method to the truss problem, for the three step sizes 5000, 500 and 50 lb., are shown in Figure (5). The accuracy, for a given step size, is not as good as that of the constant stress method, but the analysis is now free of any instability. The constant strain method is therefore selected for further use herein. The discussion of the step size and of a method of monitoring it is left for a later section.

SECTION III

ISOTROPIC ELASTIC-PLASTIC ANALYSIS

A. Biaxial Theory

Having presented the simple truss example of the step-by-step procedure, we proceed now to the case of more practical interest -- a bi-axially stressed structure. The new procedure is identical to the one already discussed for the simple truss with one exception. Because of the biaxial stress we can no longer work directly from the stress-strain curve to obtain the plastic strains for use in Equation 3; instead, we must employ the well-known concept of an "effective" stress-strain relationship in conjunction with a von Mises type yield condition and the associated incremental flow relations.

The biaxial theory is described by a summary of the steps to be used as a guide for a detailed description which follows. The constant strain method used here is a step-by-step procedure which, after incrementing the applied load, can be applied in four parts:

- Obtain the stress components at each node using the basic Equation 3 by assuming the initial strains from the previous load level.
- Using these stresses, calculate an effective stress at each node.
- 3. Assume that the effective stress-strain relation for the material, modified by including the elastic strain, corresponds to data measured in a simple uniaxial tension test. Using this, calculate the effective strain corresponding to the effective stress.
- 4. Using the incremental flow relations, determine the inelastic strain increments. The proportionality constant in these equations is the ratio of the effective strain increment to the effective stress.

At this point in the calculation, the applied load can be incremented again and the cycle repeated.

When calculating the ordinary stresses $\{\sigma_u^{(k)}\}$ for the k^{th} load level using Equation 3 (Step 1), it is convenient to re-identify these stresses by means of a new subscript N, as follows:

$$\begin{cases}
\vdots \\
\sigma_{3N-2}^{(k)} \\
\vdots \\
\sigma_{3N-1}^{(k)}
\end{cases} = \begin{cases}
\sigma_{3N-1}^{(k)} \\
\sigma_{3N}^{(k)} \\
\vdots \\
\vdots
\end{cases} (4)$$

The stresses are thus arranged in groups of three components (two normal and one shear) at each node point N.

We now calculate the corresponding effective stresses $\bar{c}_N^{(k)}$ for each of the nodes from the von Mises type formula (Step 2)

$$\vec{\sigma}_{N}^{(k)} = \left[\left(\sigma_{3N-2}^{(k)} \right)^{2} - \left(\sigma_{3N-2}^{(k)} \right) \left(\sigma_{3N-1}^{(k)} \right) + \left(\sigma_{3N-1}^{(k)} \right)^{2} + 3 \left(\sigma_{3N}^{(k)} \right)^{2} \right]^{\frac{1}{2}}$$
(5)

Note that by this definition $\bar{a}_N^{(k)}$ must be positive and is proportional to the octahedral shear stress. This formula together with the stress-strain data constitutes the strain hardening criterion.

We now go to the tensile stress-strain curve (which is also the \eth vs $\eth/E + \eth(p)$ curve) for the material of interest and, using the constant strain method, read from it the corresponding effective plastic strain $\eth(p)_N^{(k)}$. This operation (Step 3) is identical to that previously described for the uniaxial case on page 7.

In accordance with the flow theory of plasticity, the increment in the effective strain $\Delta \bar{\epsilon}(p)_N^{(k)}$ over that of the preceding interval must be calculated (Step 4). The increment will be either positive or zero, depending upon whether plastic loading or elastic unloading (or reloading) is taking place. Thus,

$$\Delta \bar{\epsilon}(p)_{\overline{N}}^{(k)} = \bar{\epsilon}(p)_{\overline{N}}^{(k)} - \bar{\epsilon}(p)_{\overline{N}}^{(k-1)}$$
 (6a)

when $\bar{\sigma}_{N}^{(k)}$ is greater than any previous $\bar{\sigma}_{N}$ (inelastic strain increasing)

$$\Delta \bar{\epsilon}(\mathbf{p})_{\mathbf{N}}^{(\mathbf{k})} = 0 \tag{6b}$$

when $\bar{\sigma}_N^{(k)}$ is smaller than a previous $\bar{\sigma}_N$ (elastic unloading or releading, inelastic strain constant)

The increments in the ordinary plastic strain components may now be obtained using a Prandtl-Reuss incremental relationship.

$$\Delta \epsilon(p)_{3N-2}^{(k)} = \frac{\Delta \bar{\epsilon}(p)_{N}^{(k)}}{\bar{\sigma}_{N}^{(k)}} \left[\sigma_{3N-2}^{(k)} - 1/2 \ \sigma_{3N-1}^{(k)} \right]$$

$$\Delta \epsilon(p)_{3N-1}^{(k)} = \frac{\Delta \bar{\epsilon}(p)_{N}^{(k)}}{\bar{\sigma}_{N}^{(k)}} \left[\sigma_{3N-1}^{(k)} - 1/2 \ \sigma_{3N-2}^{(k)} \right]$$

$$\Delta \epsilon(p)_{3N}^{(k)} = \frac{\Delta \bar{\epsilon}(p)_{N}^{(k)}}{\bar{\sigma}_{N}^{(k)}} \left[3\sigma_{3N}^{(k)} \right]$$

$$(7)$$

The total, ordinary plastic strain components are obtained by addition,

$$\begin{cases} \mathbf{c}(\mathbf{p})_{3N-2}^{(k)} \\ \mathbf{c}(\mathbf{p})_{3N-2}^{(k)} \\ \mathbf{c}(\mathbf{p})_{3N-1}^{(k)} \\ \mathbf{c}(\mathbf{p})_{3N}^{(k)} \\ \mathbf{c}(\mathbf{p})_{3N}^{(k)} \\ \vdots \\ \mathbf{c}(\mathbf{p})_{3N}^{(k-1)} \\ \mathbf{c}(\mathbf{p})_{3N}^{(k-1)} \\ \vdots \\ \mathbf{c}(\mathbf{p})_{3N}^{(k-1)} \\ \mathbf{c}(\mathbf{p})_{3N}^{(k-1)} \\ \vdots \\ \mathbf{c}(\mathbf{p})_{3N}^{(k)} \\ \vdots \\ \mathbf{c}(\mathbf{p})_{3N}^{(k-1)} \\ \vdots \\ \mathbf{c}(\mathbf{p})_{3N}^{(k)} \\ \vdots \\ \mathbf{c}(\mathbf$$

These components together with the new applied loads $P_m^{(k+1)}$ may be substituted in Equation 3 to obtain $\sigma_u^{(k+1)}$ in the next load cycle.

B. Determination of Calculation Step Size

It should be noted that, according to the constant strain method, every predicted value of effective strain $\bar{c}(p)_N^{(k)}$ together with its accompanying value of effective stress $\bar{c}_N^{(k)}$ constitutes an approximation to a point on the actual effective stress-strain curve. The excellence of the approximation is directly related to the loading increment, as is shown in the truss results Figure (5). Thus it is only necessary to monitor this agreement for one or more of the critically loaded nodes to determine whether the step size is satisfactory. This is illustrated below in connection with the shear lag structure investigation.

C. Description of Shear Lag Structure

Several very useful tests have been performed for the Air Force upon shear lag structures (Reference 7). The structure, loaded as shown in Figure (6), is an integrally machined part of 2024-T4 aluminum alloy stiffened along the loading (y) axis. The stiffener is tapered in thickness from each end towards the center of the structure.

This structure was chosen originally because it is simple to work with and well adapted to analysis by both matrix methods when appropriate idealizations are employed. When tension forces are applied to the ends of the stiffener, high stress gradients are induced in a manner analogous to those encountered in aircraft structures.

The material properties essential to this analysis were obtained from tension tests reported in Reference 7. These tests were performed on coupons, machined from the parent plate, in the longitudinal or x-direction and the transverse or y-direction of Figure (6). The data resulting from these tests, Figure (11), indicate the presence of a considerable degree of anisotropy. In the present study, three piecewise linear representations of stress-strain curves were fitted to these points; two, RO1 and RO2, in Figure (11), are equivalent to Ramberg-Osgood curves used in Reference 7; the third, RO2M, is a Grumman modification. The modulus of elasticity of all the curves is taken as 10.3×10^{0} psi. Note also that the maximum strains recorded are of the order of 0.010 in/in, whereas the maximum strains reached in the shear lag tests are around 0.020 in/in. Thus there is some doubt as to whether the idealized curve correctly represents the test material in this high strain region.

The locations of the strain gages for the test of the stiffened plate are shown in Figure (13). The plate was loaded by applying tension to the stiffener in steps of 1000 pounds to 6000 pounds, gage readings being taken at each step. It was then unloaded in steps of 1500 pounds to zero, and finally progressively loaded to failure. Buckling occurred at a load of 23,000 pounds and fracture at 25,800 pounds. Data from this test are plotted on Figures (14) through (22).

D. Elastic Shear Lag Structure Analysis

The idealizations of the upper right quandrant of the shear lag structure for a direct stiffness and a force method analysis are shown in Figures (7) and (8) respectively. A typical element of the force method analysis, Figure (9), consists of conventional bars and rectangular shear panels. Many previous idealizations have omitted the Poisson's Ratio effect. The present idealization, however, incorporates this effect in the manner described in Appendix II.

The basic element of the stiffness approach consists of a cluster of four "Turner triangles" (References 8,9) to form a rectangle as shown in Figure (10). The manner of obtaining the stresses is discussed in Appendix I.

An elastic analysis under a unit applied load was performed by both the force and the stiffness methods. These results are compared in Appendix I.

The inelastic analysis can be made using either of the two approaches (stiffness or force method). For the present investigation, only the force method is used.

E. Flow Theory Shear Lag Structure Analysis

The inelastic analysis was carried out using the Fortran 2 program listed in Appendix V. This program is capable of carrying out isotropic or anisotropic, plastic or creep flow theory analyses. The flow charts and instructions for preparation and submission of data are also included in Appendix V.

Before comparing the analytical and test results, let us look at a plot of the tensile stress-strain curve, RO2M, and compare it with the predicted effective stress-strain relationship for various step sizes. Such a comparison is found in Figure (12) for the node corresponding to the center of the specimen which is the point of highest strain in the structure. It can be seen there that for a step size of $\Delta P = 500$ lb., the agreement is rather poor. For $\Delta P = 50$ lb. the agreement is much better, while for $\Delta P = 5$ lb., the predicted value lies directly on the stress-strain curve. The IBM 7094 computer time for this best result and a maximum load of P = 16,760 lb. is approximately 20 minutes.

The predicted strain distributions are shown in Figures (14) through (21), together with the corresponding test values, along the two strain gage lines. In these plots, the calculated results are linearly interpolated values between node points. Figures (14) and (15) give elastic results; the agreement with test data is seen to be rather good, giving the necessary confidence in the accuracy of the basic influence coefficient matrices. It is observed also that the specimen achieves its basic purpose of displaying a pronounced shear lag effect with the highest strain occurring at the central node, as expected.

As the applied load increases through 7070 lbs., the strains at the central node become plastic. During the tests, the strain gages continued to function through an applied load level of 14,600 lb.; beyond this point the x-gage failed to record. The y-gage failed also above a load level of 16,760 lb., which, consequently, is the highest level considered in the comparison of test and analysis even though the plate did not buckle until P=23,000 lb.

The proportional limit for the tes' specimen material occurs at a strain of approximately .004 in/in, as shown in Figure (11). Bearing this in mind during an examination of Figures (16) through (21), it is seen that plastic behavior is primarily confined to a fairly small region around the central node, and we thus have a case of contained plasticity. The analysis predicts a very pronounced strain redistribution extending somewhat beyond this region. This is indicated by a comparison of the plastic results with extrapolated elastic results shown as dotted curves on Figures (20) and (21).

As for agreement with test values, the analysis substantially underpredicts the strain gage readings where plasticity is most pronounced. Since the elastic results agree so much better, one must assume that the difficulty lies somewhere in the plasticity part of the correlation. It was mentioned previously that the idealization of the stress-strain curve RO2M of Figure (11) was open to question at the high strain end because of the absence of test points. Accordingly, an additional run was made for a revised curve extending horizontally beyond the last indicated test point. The plastic strains at the critical central node are increased approximately 10% by so doing. This represents an appreciable closing of the gap, but the gap nevertheless remains.

Calculations were also made based upon the previously mentioned stressstrain curves RO1 and RO2 of Figure (11). The results for the central node are shown on Figure (22). As might be expected, they depart appreciably from the RO2M predictions.

F. Deformation Theory Analysis

Solutions by a deformation theory have traditionally been considered to be more easily obtainable than flow theory solutions. This is, of course, because only the stresses at the final applied load level need be considered, rather than the stress histories developed during loading. It is therefore of interest to determine whether similar benefits are attainable in the case of the finite element analyses currently being considered.

Once again, a solution of Equation 3 is required, this time such that the initial strains ϵ_v satisfy the deformation theory of plasticity. This can be accomplished as follows. Equation 3, the "k" cycle" stress equation of the preceding section, can be used intact if it is understood that $P_m^{(k)}$ is the peak load at which the results are required and does not change from one cycle to another as before. We must iterate to a solution in order to obtain a satisfactory approximation to the plastic strains.

The intra-cycle procedure employed for the determination of the equivalent strain for the kth cycle is the same as before, namely the constant strain method. At this point, however, the equivalent strain itself, not its increment, is resolved into the node plastic strains by utilizing an engineering adaptation of the incremental relations, Equations 7, thus:

$$\epsilon(p)_{3N-2}^{(k)} = \frac{\bar{\epsilon}(p)_{N}^{(k)}}{\bar{\sigma}_{N}^{(k)}} \left[\sigma_{3N-2}^{(k)} - 1/2 \ \sigma_{3N-1}^{(k)} \right]
\epsilon(p)_{3N-1}^{(k)} = \frac{\bar{\epsilon}(p)_{N}^{(k)}}{\bar{\sigma}_{N}^{(k)}} \left[\sigma_{3N-1}^{(k)} - 1/2 \ \sigma_{3N-2}^{(k)} \right]
\epsilon(p)_{3N}^{(k)} = \frac{\bar{\epsilon}(p)_{N}^{(k)}}{\bar{\sigma}_{N}^{(k)}} \left[3\sigma_{3N}^{(k)} \right]$$
(9)

These are now available for the stress equation of the next cycle.

Three analyses, one at P = 11,600 lbs., one at P = 14,600 lbs., and one at P = 16,760 lbs. were performed on the shear lag specimen by this deformation theory procedure. The results were practically identical with those shown in Figures (16) to (21). The convergence to each of these results was obtained after less than thirty cycles of iteration. The machine time for each calculation was approximately four minutes.

In the case of solutions like this, where the two analyses give practically identical results, the deformation approach is naturally very attractive because of the greatly reduced machine time. However, the question remains of determining when to expect the results to agree in this manner.

The IBM program presented in Appendix V cannot be used for deformation theory analyses. However, minor changes can be made in the program to permit calculations of this type to be carried out.

SECTION IV

ISOTROPIC ELASTIC-PLASTIC-CREEP ANALYSIS

A. Introduction to Creep Theory

Strains due to creep constitute an additional form of inelastic strain, and can be handled in a way analogous to that already discussed for bi-axial plasticity by the flow theory. It is only necessary to select a method for evaluating these time-dependent strains based upon the material properties and to add them to the plastic strains prior to insertion in the basic Equation 3.

A familiar relationship used to match the creep behavior in a tensile creep test, performed at constant stress and constant temperature, is (Reference 4):

$$\epsilon(c) = \alpha t^{\gamma}(e^{\beta \sigma}-1)$$
 (10)

in which

- c(c) is the tensile creep.strain
- t is the elapsed time
- σ is the constant tensile stress
- α,β,γ are empirical constants for the particular test temperature

For this analysis the assumption is made that there exists an effective creep strain $\tilde{\epsilon}(c)$ in a biaxial situation which can be calculated using Equation 10. In doing this the stress σ is taken to be the von Mises effective stress obtained from Equation 5. The further assumption is made that this effective creep strain can be resolved into nodal creep strains by use of a Prandtl-Reuss type of flow law.

The creep strain calculation must be generalized to situations in which the stresses vary with time. One well-known procedure for doing this, the strain-hardening rule (Reference 4), has been determined to be most appropriate for the present purposes. Its use will be described presently in connection with the kth calculation cycle.

B. Creep Theory Details

The calculation cycle follows a sequence similar to that described previously for the isotropic elastic-plastic analysis. An additional step is necessary, just after the plastic strains are obtained, to determine the creep strains. The intra-cycle order of calculation is as follows.

Entering the k^{th} cycle with applied loads $\left\{P_{m}^{(k)}\right\}$, and with the initial strains, plastic and creep, as calculated during the preceding cycle, the stresses $\left\{\sigma_{u}^{(k)}\right\}$ are calculated from Equation 3.

The effective stresses $\left\{\bar{\sigma}_{N}^{(k)}\right\}$ obtained from Equation 5 are used to obtain the effective plastic strains.

The creep strain increments at each node, for a specified time step, are now determined by the strain hardening rule which relates the strain at a node to the corresponding stress and strain for the previous cycle by the introduction of an assumed elapsed time.

Referring to Figure (23), one goes to the constant effective stress-temperature curve $(\bar{\sigma}^k, T^k)$ relevant to the node and the cycle, and locates upon it the point with ordinate $\bar{\epsilon}(c)^{(k-1)}$. The corresponding abscissa, designated $t^{*(k)}$, is called the reference time and is generally different from the actual elapsed time at the start of the cycle. The required effective creep strain increment $\Delta \bar{\epsilon}(c)^{(k)}_N$ is that corresponding to the increase in time from t^{*k} to $(t^{*k} + \Delta t^k)$ as shown on Figure (23), Δt^k being the selected calculation time increment.

The increment $\Delta \bar{c}(c)^k$ is substituted into the Prandtl-Reuss type incremental relations, Equations 7, together with the stresses indicated there. The creep initial strains are then obtained as in Equation 8.

In summary, the steps in the kth calculation take the following order:

- (1) Evaluation of Equation 3 to obtaining the tress components,
 σ_n(k)
- (2) The calculation of effective stress according to Equation 5
- (3) The determination of the node plastic strains
- (4) The determination of the node creep strains
- (5) The addition of the nodal plastic and creep strains to give the initial strains for the next cycle.

C. Description of Structure and Tests

The description of the shear lag structure to be analyzed in this section and tests for the material properties may be found in Reference 7. The shear lag structure was manufactured from 1100-F aluminum. It was of the same physical dimensions as the structure of Figure (6). The idealization of the upper right quadrant remains unchanged.

Material properties for the creep analysis were obtained from uniaxial strain-time tests for constant tensile stress. The temperature at which these tests were conducted was 206°C, the temperature identical to that of the structural test. The curves for these tests are presented in Figure (24) together with the fitted curves from Equation 10. The constants of the equation were obtained from Reference 7 and are as follows:

 $\alpha = 0.650 \times 10^{-4}$

y = 0.500

 $\beta = 0.700 \times 10^{-3} \text{ in}^2/1\text{b}$

Ordinary tensile stress-strain tests were performed at room temperature on coupons cut from the x and y orientations of the plate material. The data and faired curve are presented in Figure (25). Tensile stress-strain data for 206°C are also plotted here. These data were obtained from the intersections of the test curves on the zero time axis in Figure (24). A piecewise linear representation TCl was fitted to this latter data.

The location of the strain gages on the structure is given in Figure (26). The shear lag specimen was tested for a total of three hours at 206°C. An initial applied load of 1600 lb. was increased to 2020 lb. at the end of the first hour. It was held constant thereafter to the end of the test.

D. Results of Creep Shear Lag Analysis

The predicted strain distributions along the x-axis and along the section x = 1 in. at t = 0.06 hr., t = 1.10 hr., and t = 3.00 hr. elapsed times, are given in Figures (27) through (32), together with the experimental data of Reference 7. Test data are not available for the y-node strains at the center node, and so this correlation point of critical significance does not exist.

The curve of Figure (33), effective stress versus strain at the central node, exhibits the shapes characteristic to the various regions of the load-time sequence. The initial linear segment, representing elastic loading is followed by the region of the negative curvature representing loading into the plastic range, all at assumed zero time. Thereafter, the applied load remains constant for one hour, during which time there is a stress redistribution in the structure due to creep. This particular node unloads, as evidenced by the reduction in effective stress, although the total strain is growing continuously. The applied load is now increased to 2020 lb. Because of the previous elastic strain recovery, the effective stress at first goes up elastically, and then becomes plastic once more. Once the applied load reaches its final value, redistribution due to creep effects again takes place.

In the initial stages of creep the curve is very sensitive to time increment size and it is necessary to choose exceptionally small time

increments in this region if good accuracy is to be achieved. The time increments employed are as shown in Figure (33).

Considering the simplicity of the expressions employed to describe as complex a phenomenon as creep and the liberal assumptions made in the process, the correlation between analysis and experiment, as evidenced by the preceding graphs and also by Figures (34) and (35), is surprisingly good.

SECTION V

ANISOTROPIC ELASTIC-PLASTIC ANALYSIS

A. Anisotropy in Structures

Several "expanding yield surface" theories for extending the isotropic plastic theory to provide for anisotropy have become available within the last two decades. Each is based on experimentally determined parameters and, therefore, each is biased in favor of specific test data. The complexity and amount of testing required to obtain these parameters differ considerably. Under these circumstances, no single theory can be completely acceptable, but it is thought that a suitable theory must, at least, be capable of evaluating the type of anisotropy associated with biaxially stressed structures used in flight vehicle design without being unduly complex in application. It would be desirable to have the procedure based on a well-known, accepted theory.

A particular type of anisotropy, the so-called "orthotropic symmetric" type, develops during a cold rolling process where the material is lengthened and thinned with no appreciable change in width. Since cold rolled sheet and plate are frequently used in aerospace structures, this type of anisotropy may be anticipated and is considered here.

A theory proposed by Hill, Reference 10, has been widely accepted as the most straightforward extension of the isotropic theory. The formulation, however, is not very convenient for numerical step-by-step computation. A modification of Hill's theory proposed by Hu, Reference 11, however, is very tractable to formulation into the matrix inelastic program discussed previously in this report. The Hu procedure has two distinct advantages:

- (1) It employs a von Mises type hardening surface, associated flow law and effective stress-strain relationships in appropriate form.
- (2) It requires a minimum of material data: simple uniaxial and shear stress-strain tests on coupons cut in the directions of the orthotropy.

B. Hu's Strain Hardening Theory

A summary of Hu's theory is presented to establish its limitations and provide background for the necessary modifications to obtain a more general theory.

The isotropic expressions for effective stress, Equation 5, and associated incremental relations, Equations 7, are modified by means of anisotropic parameters (α_{ij}) . These are constants in Hu's theory. Here it is more convenient to introduce the 1-1, 2-2, etc., directions instead

of x-x, y-y, etc. The modified expression for the effective stress is

$$\bar{\sigma} = \left[\alpha_{12}(\sigma_{11} - \sigma_{22})^2 + \alpha_{23}(\sigma_{22} - \sigma_{33})^2 + \alpha_{31}(\sigma_{33} - \sigma_{11})^2 + 3\alpha_{14}\sigma_{12}^2 + 3\alpha_{55}\sigma_{23}^2 + 3\alpha_{66}\sigma_{31}^2\right]^{\frac{1}{2}}$$
(11)

The incremental flow equations are

$$de_{11} = \frac{d\bar{e}}{\bar{\sigma}} \left[\alpha_{11} \sigma_{11} - \alpha_{12} \sigma_{22} - \alpha_{31} \sigma_{33} \right]$$

$$de_{22} = \frac{d\bar{e}}{\bar{\sigma}} \left[- \alpha_{12} \sigma_{11} + \alpha_{22} \sigma_{22} - \alpha_{23} \sigma_{33} \right]$$

$$de_{33} = \frac{d\bar{e}}{\bar{\sigma}} \left[- \alpha_{31} \sigma_{11} - \alpha_{23} \sigma_{22} + \alpha_{33} \sigma_{33} \right]$$

$$de_{12} = \frac{d\bar{e}}{\bar{\sigma}} \left[3\alpha_{11} \sigma_{12} \right]$$

$$de_{23} = \frac{d\bar{e}}{\bar{\sigma}} \left[3\alpha_{55} \sigma_{23} \right]$$

$$de_{31} = \frac{d\bar{e}}{\bar{\sigma}} \left[3\alpha_{66} \sigma_{31} \right]$$
(12)

Equations 11 and 12 are written for the case where the reference axes are the principal axes of anisotropy.

The anisotropic parameters are determined by means of a total of six, simple, directional, stress-strain tests (i.e., uniaxial and shear tests), where, alternately, all stress components are equal to zero except one. From each of the six tests a characteristic stress, such as an approximate yield stress, is read off. Then substituting each of these results into Equation 11 in succession, we may write

$$\alpha_{11} = \alpha_{12} + \alpha_{31} = \left(\frac{K}{Y_{11}}\right)^{2} \qquad \alpha_{14} = \frac{1}{3}\left(\frac{K}{Y_{12}}\right)^{2}$$

$$\alpha_{22} = \alpha_{23} + \alpha_{12} = \left(\frac{K'}{Y_{22}}\right)^{2} \qquad \alpha_{55} = \frac{1}{3}\left(\frac{K}{Y_{23}}\right)^{2}$$

$$\alpha_{33} = \alpha_{31} + \alpha_{23} = \left(\frac{K}{Y_{33}}\right)^{2} \qquad \alpha_{66} = \frac{1}{3}\left(\frac{K}{Y_{31}}\right)^{2}$$
(13)

where

K = the effective characteristic stress

Y₁₁ = the simple directional characteristic stress

It remains to assume an effective stress-effective strain relationship. Hu shows that it is acceptable to assume the stress-strain data associated with one particular simple tension test as the effective relationship. It can be seen from Equations 13 that this implies setting one α_{ii} equal to unity.

Thus, in particular for α_{22} = 1, from Equations 11 and 12:

$$\bar{\sigma} = \sigma_{22}$$

$$d\bar{\epsilon} = d\epsilon_{22}$$
(14)

Now consider Equation 12 for simple stress-strain tests in the other directions. Then

$$d\epsilon_{11} = \alpha_{11}\sigma_{11}\frac{d\bar{\epsilon}}{\bar{\sigma}}$$

$$d\epsilon_{33} = \alpha_{33}\sigma_{33}\frac{d\bar{\epsilon}}{\bar{\sigma}}$$

$$d\epsilon_{12} = 3\alpha_{11}\sigma_{12}\frac{d\bar{\epsilon}}{\bar{\sigma}}$$

$$d\epsilon_{23} = 3\alpha_{55}\sigma_{23}\frac{d\bar{\epsilon}}{\bar{\sigma}}$$

$$d\epsilon_{31} = 3\alpha_{66}\sigma_{31}\frac{d\bar{\epsilon}}{\bar{\sigma}}$$
(15)

or

$$\frac{d\bar{e}}{\bar{\sigma}} = \frac{1}{\alpha_{11}} \frac{de_{11}}{\sigma_{11}} = \frac{1}{\alpha_{33}} \frac{de_{33}}{\sigma_{33}} = \frac{1}{3\alpha_{14}} \frac{de_{12}}{\sigma_{12}} = \frac{1}{3\alpha_{55}} \frac{de_{23}}{\sigma_{23}} = \frac{1}{3\alpha_{66}} \frac{de_{31}}{\sigma_{31}}$$

These equations say that, with the anisotropic parameters constant for strain hardening, the simple, stress-incremental strain relations must be proportional to the effective stress-incremental strain relationship. The implication is that the integrated forms of Equations 15, that is, the simple, directional stress strain curves, are thus prescribed. These may or may not be a reasonable fit to the test data for the material of interest. Obviously, only when the fit is good can one hope for Hu's theory to give acceptable results for all types of loading.

Based upon the Hu theory, it becomes relatively easy to obtain anisotropic solutions using the previously developed isotropic inelastic procedure and corresponding digital computer program. It is only necessary to substitute the appropriate anisotropic constants for their

isotropic counterparts, for which $\alpha_{11} \cdots \alpha_{66} = 1$, $\alpha_{12} = \alpha_{23} = \alpha_{31} = \frac{1}{2}$.

C. Extension of Hu's Theory

It is in the determination of the parameters that an extension to Hu's theory is made. Except for the special case pointed out in the preceding section, these parameters should not be constant for a strain hardening material, but should be variables dependent upon stress level. The objective, obviously, is to determine the variation in a manner that allows for all of the simple, directional stress-strain curves to be correctly reproduced. This can be accomplished by a consideration of plastic work.

In the current approach, one continues with the assumption of the existence of an effective stress-strain relationship. Then the basic notion is that the anisotropic parameters are determined such that, for equal amounts of plastic work done during simple directional stress strain tests in all directions, the effective stress level reached will be identical.

Accordingly, for a tensile specimen in the 1-1 direction, one calculates the plastic work w performed during a uniaxial test by the formula

$$w = \int \sigma_{11} d\varepsilon_{11} = \int \tilde{\sigma} d\tilde{\varepsilon} \qquad (16)$$

Let the corresponding maximum stress reached be identified by the superscript (I), i.e. $\sigma_{11}^{\rm I}$. For a similar test in the 2-2 direction, and for which the amount of plastic work performed is identical, the corresponding maximum stress reached is $\sigma_{22}^{\rm I}$. Since the amounts of work done in the two cases are the same, $\sigma_{11}^{\rm I}$ and $\sigma_{22}^{\rm I}$ correspond to the same effective stress $\bar{\sigma}^{\rm I}$. By means of Equation 11 we have

$$\left(\bar{\sigma}^{I}\right)^{2} = \alpha_{11}\left(\sigma_{11}^{I}\right)^{2} = \alpha_{22}\left(\sigma_{22}^{I}\right)^{2} \tag{17}$$

This expression constitutes a relationship defining α_{11} and α_{22} as functions of $\tilde{\sigma}$. Similar relationships can clearly be found for the other α_{11} 's. Thereafter, the α_{1j} 's can be determined as functions of $\tilde{\sigma}$ by recourse to the α definitions of Equations 13.

It is convenient to again select the 2-2 direction stress-strain curve as the one defining the effective stress-strain relationship. This results in α_{22} being equal to unity once more.

The actual evaluation of the other α 's as functions of 5 follows easily. Figure (36) indicates schematically how the plastic work done in each simple directional stress-strain test can be plotted as a function of stress. Then for a given amount of plastic work, and reading off the corresponding stresses $\sigma_{11}^{\rm I}$ and $\sigma_{22}^{\rm I}$ for example, by Equation 17 one finds that

$$\alpha_{11} = \frac{\left(\sigma_{22}^{I}\right)^{2}}{\left(\sigma_{11}^{I}\right)^{2}} \tag{18}$$

Using this and similar relationships in the other directions, curves representing all of the α 's as functions of δ may be constructed. The incorporation of this information in the step-by-step calculation procedure is discussed in the next section.

D. Anisotropic Theory Details

The detailed step-by-step calculation procedure to be followed in the case of anisotropic material in a biaxially stressed structure is very similar to that previously discussed for isotropic materials. Accordingly, only the differences will be stressed.

As before, one starts the k^{th} calculation cycle by evaluating $\{\sigma_{tt}^{(k)}\}$ by means of Equation 3. This operation employs the initial strains of the preceding cycle $\{\varepsilon_{tt}(p)^{(k-1)}\}$.

The next operation is to evaluate the effective stresses at each of the nodes, $\tilde{c}_N^{(k)}$, by Equation 11, modified for the biaxial case to

$$\bar{\sigma}_{N}^{(k)} = \left[\alpha_{11}^{(k-1)} \left(\sigma_{3N-2}^{(k)}\right)^{2} - 2\alpha_{12}^{(k-1)} \left(\sigma_{3N-2}^{(k)}\right) \left(\sigma_{3N-1}^{(k)}\right) + \left(\sigma_{3N-1}^{(k)}\right)^{2} + 3\alpha_{11}^{(k-1)} \left(\sigma_{3N}^{(k)}\right)^{2}\right]^{\frac{1}{2}}$$
(19)

We continue here our assumption that the 2-2 direction has been selected as that in which the effective stress-strain relationship is defined; hence α_{22} = 1.

Note that if the Hu theory is being used, the α_{ij} 's are all known constants. If the modified theory is being employed, the variable α_{ij} 's are those that have been evaluated during the preceding cycle, (k-1). This is in keeping with the overall nature of the analysis as a step-by-step procedure.

Having determined the $\tilde{c}_N^{(k)}$'s, one can now go to the curves representing the $\alpha_{i,j}$'s as functions of \tilde{c} to evaluate $\alpha_{i,1}^{(k)}$, $\alpha_{i,2}^{(k)}$ and $\alpha_{i,4}^{(k)}$. After having also determined $\tilde{c}_N^{(p)}(k)$ and $\Delta \tilde{c}_N^{(p)}(k)$ as before by the constant strain method, these quantities may be substituted into a finite equivalent of Equations 12 specialized for the biaxial case, to yield

$$\Delta \epsilon(p)_{3N-2}^{(k)} = \frac{\Delta \bar{\epsilon}(p)_{N}^{(k)}}{\bar{\sigma}_{N}^{(k)}} \left[\alpha_{11}^{(k)} \sigma_{3N-2}^{(k)} - \alpha_{12}^{(k)} \sigma_{3N-1}^{(k)} \right]$$

$$\Delta \epsilon(p)_{3N-1}^{(k)} = \frac{\Delta \bar{\epsilon}(p)_{N}^{(k)}}{\bar{\sigma}_{N}^{(k)}} \left[\sigma_{3N-1}^{(k)} - \alpha_{12}^{(k)} \sigma_{3N-2}^{(k)} \right]$$
(20)

$$\Delta \epsilon(\mathbf{p})_{3N}^{(k)} = \frac{\Delta \bar{\epsilon}(\mathbf{p})_{N}^{(k)}}{\bar{\sigma}_{N}^{(k)}} \left[3\alpha_{\mu\mu}^{(k)} \sigma_{3N}^{(k)} \right]$$

From these, the strain components $\epsilon(p)_{3N-2}^{(k)}$, $\epsilon(p)_{3N-1}^{(k)}$ and $\epsilon(p)_{3N}^{(k)}$ are obtained by addition, as before, using Equation 8.

After incrementing the applied load the sequence can now be repeated for the next load cycle.

E. Rotation of Axes of Anisotropy

Anisotropic symmetry may occur in a structure for which it is convenient to choose coordinate axes that are rotated from the orthogonal axes of anisotropy. The corresponding expressions for the incremental flow equations and effective stress equations are derived in Appendix IV. The derivation is limited to the case of biaxial stress where the 3-3 and z-z axes coincide. A method of obtaining the shear anisotropic coefficients is also indicated.

F. Anisotropic Analysis of Shear Lag Structure

It has been pointed out earlier that the 2024-T4 aluminum alloy of the shear lag structure tested for the Air Force (Reference 7) displayed considerable anisotropy as shown in Figure (11). The structure had been analyzed for isotropic strain hardening based upon the curve RO2M in this figure, and the results discussed in Section III. A corresponding anisotropic strain hardening analysis has also been carried out, employing first the Hu theory and then the proposed extension.

Material stress-strain data is available along two of the axes of anisotropy, the rolling or x-x (1-1) direction, and the long transverse or y-y (2-2) direction. This data has been plotted and discussed in connection with Figure (11); it is replotted for convenience in Figure (37).

The additional required, but missing, test data is (a) tensile stress-strain data in the short transverse or z-z (3-3) direction and (b) shear stress-strain data in the x-y plane. A reasonable assumption to make for engineering purposes for (a) is that the long and short transverse properties are identical; this is made in the analyses to follow. In the case of (b), the missing shear data, the following is done. First, a shear stress-strain curve is obtained based upon the tensile curve in the rolling direction, together with the assumption that the material is isotropic and governed by the incremental theory of Section III -- specifically, Equations 5 and 7. Next, a similar shear stress-strain curve based upon the tensile curve in the long transverse direction is obtained. Finally, a faired-in average of these two curves is taken to represent the missing shear stress-strain relation.

In order to apply the I theory, one must first select four characteristic stresses to represent the directional stress-strain curves, as discussed in Section V-B. These are the quantities Y₁₁, Y₂₂, Y₃₃ and Y₁₂ of Equations 13. We arbitrarily choose the proportional limits from the four curves just discussed for these values; they are

$$Y_{11} = 51 \text{ ksi}$$
 $Y_{22} = 32 \text{ ksi}$
 $Y_{33} = 51 \text{ ksi}$
 $Y_{12} = 22 \text{ ksi}$

Since the simple directional stress-strain curve in the 2-2 direction, i.e. RO2M, is selected for the effective stress relationship, the effective stress characteristic value K is also 32 ksi. Substituting these values in Equations 13, one can solve for the necessary anisotropic parameters. This information is all that is required to carry out an analysis of the shear lag structure by the Hu theory.

As pointed out previously, once the anisotropic parameters α_{11} , α_{22} , α_{12} and α_{14} have been specified and one of the stress-strain curves chosen as the effective stress-strain curve, the remaining simple direc-

tional stress-strain curves are prescribed. Let us now examine the consequences of our current parameter selection. Since only test data in the 1-1 and 2-2 directions are available, we shall concentrate on these. For this special case, Equations 11 and 12 can be easily manipulated to yield

$$\bar{\sigma} = \sqrt{\alpha_{11}} \sigma_{11}$$

$$\frac{d \epsilon_{11}}{d \sigma_{11}} = \alpha_{11} \frac{d \bar{\epsilon}}{d \bar{\sigma}}$$
(21)

Using these expressions, one can construct a σ_{11} stress-strain curve.

Such a curve is shown on Figure (37). As can be seen, the fit with the 1-1 test data is very poor. Apparently, one could do better by arbitrarily choosing for the 1-1 characteristic value Y₁₁ a much lower value than 51 ksi -- perhaps in the neighborhood of 35 ksi. Nevertheless, it is clear that in this case it would still be impossible to get a really good fit because of the fundamentally different shapes of the two stress-strain curves, especially in the region of their knees. It will turn out that, in the case of the shear lag structure, this selection is not critical, because of the fact that stresses in the 1-1 direction are very low, compared to those in the 2-2 direction.

In order to carry out an analysis of the shear lag structure based upon the extension to the Hu theory, one must first evaluate the plastic work done in each of the simple directional stresss-strain tests as a function of the applicable stress. Using this information in the manner discussed previously, one can then obtain the anisotropic parameters as functions of effective stress. This has been done, assuming that it is sufficiently accurate to represent the curves by a small number of connected straight line segments. The key values of the resulting α 's are given in the accompanying table. Corresponding total strains \mathbf{Z} (= $\overline{\sigma}/\mathbf{E}$ + $\overline{\epsilon}$) are also listed.

	E	$\alpha_{11} = 2\alpha_{12}$	<u>α</u> 22	$\frac{\alpha^{j^{\dagger}j^{\dagger}}}{\alpha^{j^{\dagger}j^{\dagger}}}$	
32000	.00310	0.394	1.000	0.697	
	.00378	•510	1.000	•755	- 1/2 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -
	.00435	. 590	1.000	-795	
	.00509	.660	1.000	.833	1 54 - BYD [
	.00622	.742	1.000	. 871	నా నుండు ఉంది మీసుగా
48000	.00734	. 809	1.000	•905	
	•00800	835	1.000	.918	ार्थ (स्ट्राइटिं
51000	.00980	.892	1.000	. 945	
	.03800	•930	1.000	•965	الرائي فيعتمد عربيا

In the preceding table, the reduction in number of independent anisotropic parameters is a consequence of the assumptions which had to be made for the missing stress-strain curves.

The value of unity for α_{22} is in accordance with our continued selection of the tensile stress-strain curve RO2M in the y-y or 2-2 direction as the basis for our effective stress-strain relationship.

It might be reiterated that, because of the manner in which the a's are derived in this case, all of the simple directional stress-strein curves are matched as closely as desired.

Using first the anisotropic parameters selected as described for the Hu theory, and then for its extension, the shear leg structure has been analyzed. The results are presented in the next section.

G. Discussion of Results

Some of the highlights of the two anisotropic analyses are presented in Figures (38) through (40). Corresponding results obtained previously and based upon isotropic theory are also included for comparison.

Figure (38) refers to the central node of the shear lag structure and shows the variation of the total strains in the x and y directions with increasing applied load. The isotropic result is replotted from Figure (22) -- specifically those curves based upon the effective stress-strain curve RO2M.

It can be seen from Figure (38) that the most flexible analysis predictions, that is, those for which the total strains are the largest, are obtained by the isotropic analysis. The analysis based upon the extension to the Hu theory is somewhat less flexible, while the Hu theory results are the stiffest. Also, the differences between the three analyses are less in the y direction than in the x direction.

These observations are clearly in agreement with the nature of the material stress-strain relations upon which the analyses are based. In all three cases, we are assuming that the y-y curves are identical, that is, all are represented by RO2M. Referring to Figure (37), in the case of the isotropic analysis, we are also assuming, in effect, that the x-x stress-strain curve is identical to the y-y curve RO2M. The x-x curve for the extension to the Hu theory is seen to be somewhat stiffer than RO2M, while the x-x curve for the Hu theory is by far the stiffest of the three.

Comparing the analyses with the test data, all three analyses substantially underpredict the test points in the high applied load regime, and more so in the y than in the x direction. It is interesting to note however, that while the anisotropic analyses make these differences even greater, they do have the virtue of making the comparison more consistent as between the x and y directions. Thus it would appear that the

anisotropic nature of the 2024-T4 material does influence the strain distribution in the shear lag structure, and that the anisotropic analyses can detect this tendency.

Figures (39) and (40) show the strain distributions along the two strain gage lines of the test structure. In addition to the isotropic predicted results, replotted from Figures (20) and (21), anisotropic results based upon the extension to the Hu theory are presented. They indicate that while the differences are not dramatic, they do in fact exist.

SECTION VI

ANISOTROPIC ELASTIC-PLASTIC-CREEP ANALYSIS

A. Anisotropic Creep Theory

The application of matrix analysis procedures to problems involving anisotropic creep is at present academic. Neither meaningful analytical research nor appropriate test data has been found. Therefore the procedure presented here for anisotropic creep is a simple extension of that already described in previous sections. Accordingly, only the difference and additional assumptions are discussed.

Strains due to anisotropic creep can be handled in a way similar to those due to isotropic creep. The step-by-step procedure has only to be modified for the anisotropic behavior by substituting Equations 19 and 20 for Equations 5 and 7 respectively in the manner described for time independent plastic anisotropy in Section V-D. The additional assumptions implied by this simple extension are the following:

- (1) The anisotropic parameters calculated from zero time simple directional tests (by either Hu theory or the proposed extension) are valid for anisotropic creep.
- (2) The effective creep strain equation, Equation 10, remains valid and the empirical constants (α,β,γ) are determined for the tensile creep test in the assumed effective stress-strain direction.

Because testing of structures exhibiting anisotropic creep has apparently not been done, the anisotropic creep procedure cannot be checked out against tests at this time. However, the results of a sample calculation are presented for a hypothetical material having this characteristic.

B. Sample Problem

The 1100-F aluminum shear lag specimen, already analyzed for isotropic creep, is used for an anisotropic creep analysis making the following assumptions:

- (1) All the uniaxial data (Figure 25) employed in the isotropic creep analysis is assumed to refer to the y-y (2-2) effective direction of the anisotropic creep analysis.
- (2) The plastic anisotropic parameters (extension of Hu's theory) for the effective stress-strain curve of the 2024-T4 aluminum alloy material for successive levels of stress, 32 ksi, 37 ksi, 40 ksi, etc. are arbitrarily chosen for the stress levels, 2 ksi, 3 ksi, 4 ksi, etc. of the 1100-F aluminum effective stress-strain curve TCl (Figure 25). Thus:

<u>ō</u>	Ē	$\alpha_{11} = 2\alpha_{12}$	α ₂₂	$\alpha_{\underline{1},\underline{1},\underline{1}}$
2000	•000222	0.394	1.000	0.697
3000	•000359	•510	1.000	•755
4000	•000540	•590	1.000	•795
5000	•000815	•660	1.000	.833
6000	.001256	•742	1.000	.871
7000	•001967	.809	1.000	•905
8000	•003038	.835	1.000	•918
10000	.007110	.892	1.000	•945

This means that the uniaxial x-x (1-1) predicted stress-strain curve and the shear x-y stress-strain curve are arbitrarily stiffer than the corresponding isotropic curves.

The node strains obtained, using the anisotropic assumptions for load P = 2020 lbs at time t = 3 hrs, are presented for the x-axis and along x = 1 in. in Figures (41) and (42) respectively.

In general, the anisotropic results appear to be stiffer than those for the isotropic case, and this is especially true for the vertical gage line, where the anisotropic shear strains are of the order of 3/4 of the isotropic values. This should be expected, due to the fact that the anisotropic parameters used are all less than, or at the most equal to, their isotropic equivalents.

In the configuration of the configurat

<u>mineralizada (f.</u> 1808-leanie (f.)

egalises a lot occupió e operans cuestiment Bui n<mark>amia</mark> Activió e é-efflication cue está o o egalitico clonjio e peso objetente insulo e esta ensulo la cersión como esta construicada.

- (3) All the mains of the (11) would be added in the second of the second
- (a) The plantic aristropic narration (extension of Mais theory) for the elientire stress-atheir curve of the 2024-T4 alumination rate entail for excessive levals of stress, 32 kei, 37 kei, 10 kei, etc., are arbitrarilly chosen for the stress levels. I kei, 3 kei, 4 kei, otc., or the jill-F aluminum effective stress-strain curve TOL (Figure 23). Thus:

SECTION VII

CONCLUSION

The linear, matrix structural analysis methods currently in general use throughout the aerospace industry have recently been extended to include structures loaded into the inelastic material behavior regime. However, very little published information is available correlating predicted results with the test data.

The current report recommends a simple analytical approach to such problems. It is based upon the concept of initial strains in combination with a suitable matrix of influence coefficients, obtained by standard linear matrix structural analysis methods. The initial strains are those associated with plasticity and creep.

Some particularly useful tests of aluminum and aluminum alloy shear lag structures have been performed previously for the Air Force. These structures have been analyzed by the recommended method, and the resulting agreement (for both the plasticity and the creep tests) is considered to be very encouraging. On the other hand, additional testing must be carried out and correlations with analysis made before the method can be considered as fully evaluated.

In the meantime, the writers believe that sufficient confidence in the method has been established that it may now be used in practical engineering applications. For example, it should be immediately useful in such problems as predicting inelastic strain distributions around stress raisers in simple structural components.

As for the influence of anisotropy, it has been shown that this material property can be readily accommodated in the recommended procedure. Calculations made for the 2024-T4 shear lag structure indicate that, in this case at least, anisotropy plays a minor but discernable role in determining the strain distributions. This evidence is inconclusive, because in this particular test, while the material itself is decidely anisotropic, the stresses normal to the direction of the applied loads are quite small.

It is recommended that in cases where doubt exists as to the importance of anisotropy, it be included in the analysis. Certainly in such examples as the shear lag structure, the additional complexity in the use of the computer program is very slight.

There is one very important restriction implicit in the method proposed in this report. Essentially, this method applies only to a structure in which the material is initially in the virgin state, and thereafter experiences only continually-increasing applied loads until failure occurs. This limitation can actually be relaxed to the extent that elastic unloading followed by reloading can also be accommodated, but

completely reversed loading is specifically excluded. For the latter case, a different plasticity theory is needed. It is important that a technique for handling such problems be developed because of the need for such applications in fatigue work. Efforts toward removing this restriction are currently under way under government contract.

Other than the preceding, the largest remaining obstacle to complete inelastic analysis of practical aerospace structures is believed to be the dearth of appropriate material property data, and constitutive laws to describe them.

SECTION VIII

FIGURES




Fig. 1 Truss Structure




Fig. 2 Constant Stress Method




Fig. 3 Constant Strain Method




Fig. 4 Results of Constant Stress Method for Bar No. 3 of Truss




Fig. 5 Results of Constant Strain Method for Bar No. 3 of Truss





Fig. 6 Shear-Lag Specimen Designated SIS1 - From Air Force Report No. RTD-TDR-63-4032; 2024-T4 Aluminum Alloy (1100-F Specimen Similar)






Fig. 9 Typical Elements of Force Idealization




Fig. 10 Typical Elements of Stiffness Idealization




Fig. 11 2024-T4 Aluminum Alloy Stress-Strain Data and Curve RO2M





Fig. 12 Comparison of Predicted Effective Stress-Strain Relationship with RO2M at (0, 0) for Various Load Increments



Gage Nos.		Co-ordinates		Gage Nos.		Co-ordinates	
Front	Back	x in.	y in.	Front	Back	x in.	y in.
1	11	ó.0	0.0	6	16	-1.125	0.0
2	12	0.5	-0.0	7	17	0.8125	1,5625
3	13	1.125	0.0	8	18	0.8125	2.8125
4	14	1.750	0.0	9	19	0.8125	4.0625
5	15	3.000	0.0			٠.	

Fig. 13 Instrumentation of 2024-T4 Aluminum Alloy Specimen




Fig. 14 Elastic Strains Along x-Axis for P = 1 1b




Fig. 15 Elastic Strains Along x = 0.8125 in. for P = 1 1b




Fig. 16 Strains Along x-Axis for P = 11,600 lb and $\Delta P = 5$ lb




Fig. 17 Strains Along x = 0.8125 in. for P = 11,600 lb and $\Delta P = 5$ lb




Fig. 18 Strains Along x-Axis for P = 14,600 lb and Δ P = 5 lb




Fig. 19 Strains Along x = 0.8125 in. for P = 14,600 lb and $\Delta P = 5$ lb




Fig. 20 Strains Along x-Axis for P = 16,760 lb, and $\Delta P = 5$ lb




Fig. 21 Strains Along x = 0.8125 in. for P = 16,760 lb and $\Delta P = 5$ lb




Fig. 22 Elastic-Plastic Strains at (0, 0) for Several Assumed Stress-Strain Curves




Fig. 23 The Strain Hardening Rule




Fig. 24 1100-F Aluminum Time-Dependent Behavior and Fitted Curves (Ref. 7)




Fig. 25 1100-F Aluminum Stress-Strain Data at Room
Temperature and at 206° C, for Time t = 0.00




Fig. 26 Location of Strain Gages on 1100-F Specimen (Ref. 7)




Fig. 27 Strains Along x-Axis for P = 1600 lb and t = 0.06 hr




Fig. 28 Strains Along x = 1 in. for P = 1600 lb and t = 0.06 hr




Fig. 29 Strains Along x-Axis for P = 2020 lb and t = 1.10 hr




Fig. 30 Strains Along x = 1 in. for P = 2020 lb and t = 1.10 hr




Fig. 31 Strains Along x-Axis for P = 2020 lb and t = 3.0 hr




Fig. 32 Strains Along x = 1 in. for P = 2020 lb and t = 3.0 hr




Fig. 31 Strains Along x-Axis for P = 2020 1b and t = 3.0 hr




Fig. 32 Strains Along x = 1 in. for P = 2020 lb and t = 3.0 hr




Fig. 33 Effective Stress vs Strain at Center Mode




Fig. 34 Total (Elastic, Plastic and Creep) Strains at Center of Specimen (Gage 1) for P=1600 1b to Time 1 hr, then P=2020 1b to Time 3 hr




Fig. 35 Total (Elastic, Plastic and Creep) Strains at (1.0 in., 3.0 in.) (Gage 8) for P = 1600 lb to time 1 hr, then P = 2020 lb to time 3 hr




Figure 36 Typical Uniaxial Stress vs Plastic Work, w, Plot.




Fig. 37 Assumed Effective Stress (y-y) Curve, Calculated x-x Curves and Test Data




Fig. 38 Node Strains at (0, 0) - Isotropic and Anisotropic Analysis




Fig. 39 Strains Along x - Axis for P = 16,760 lb.
Isotropic and Anisotropic Analyses




Fig. 40 Strains Along x = 0.8125 in. for P = 16.760 lb.
Isotropic and Anisotropic Analyses




Fig. 41 Strains Along x - Axis for P = 2020 lb and t = 3.0 hr. Isotropic and Anisotropic Analyses




Fig. 42 Strains Along x = 1 in. for P = 2020 lb and t = 3.0 hr.
Isotropic and Anisotropic Analyses




Fig. 43 Elastic Stress Distribution Along x-Axis




Fig. 44 Elastic Stress Distribution Along x = 0.8125 in.

APPENDIX I

ELASTIC ANALYSIS OF SHEAR LAG STRUCTURE

A. Idealization of Shear Lag Structure

As stated in the introduction, when a problem is formulated by means of a standard influence coefficient approach, the necessary linear analysis may be carried out using either the force or displacement method. Since published correlations between results of the matrix force and direct stiffness methods of linear elastic analyses for redundant structures have, in the past, left room for doubt as to the equivalence of results, this Appendix presents a comparison of the stresses from two idealizations of the simple shear-lag stiffened-plate structure, Figures (7) and (8). In the past, discrepancies have been due in part to a marked difference in the arrangement of node points for corresponding idealizations, and also to the fact that techniques for obtaining node stresses in finite element analyses are still being improved. An attempt was made to keep the idealizations as comparable as possible with respect to location of nodes and the determination of stresses.

B. Force Method

The idealization for the force method may be seen in Figure (8). It comprises conventional bars and shear panels located in the manner shown. The analyses of some previous idealizations of this type have omitted the Poisson's ratio effect. This effect can be incorporated in the manner described in Appendix II.

C. Stiffness Method

The idealization for the stiffness method consists of "Turner triangles," which are located as shown in Figure (7). The basic theory of the triangle is to be found in References 8 and 9.

While the conventional procedure was used to obtain node stresses for the force method, comparable stiffness-method stresses can be calculated in several ways. A recent paper, Reference 9, suggests two means of obtaining node stress, one of which was employed in the analysis. This method will be reviewed briefly.

Figure (10) represents a cluster of triangles. It is required to find the stresses at the node common to triangles P to W. The node forces for each triangle at this apex are obtained as described in Turner's former papers. Summing the forces on a vertical section through 1 in both directions gives

$$X_v = X_P + X_Q + X_R + X_S$$

 $Y_v = Y_P + Y_Q + Y_R + Y_S$

Analogous results X_h and Y_h are obtained for the corresponding horizontal cut.

The node stresses at the node are

$$\sigma_{x} = \frac{X_{v}}{\frac{1}{2} (ct_{p} + dt_{s})}$$

$$\sigma_{y} = \frac{Y_{h}}{\frac{1}{2} (at_{r} + bt_{u})}$$

$$\sigma_{xy} = \frac{1}{2} \left[\frac{X_{h}}{\frac{1}{2} (at_{r} + bt_{u})} + \frac{Y_{v}}{\frac{1}{2} (ct_{p} + dt_{s})} \right]$$

where a, b, c, and d are as indicated and t is the thickness.

D. Comparison of Elastic Results and Perspective

The results are correlated by means of the curves appearing in Figures (43) and (44) with calculated values from the experimental data of Reference 7.

The correlation between the stresses derived from the force method and from the stiffness method of analysis is excellent and may be regarded as exact for engineering applications. The largest discrepancy is in the direct stresses in the x direction at the middle of the plate as shown in Figure (43). Even in this region the difference is quite small. It is believed that an even closer agreement could be obtained by modifying the idealized structure to provide square shear panels adjacent to the reinforcement and a finer grid at the plate center.

The largest discrepancy between analysis and test results is located in the region of the plate center. Reference 7 indicated that considerable bending was exhibited by the structure as the ends of the stiffener were loaded. The extent to which this affects the gage readings was not determined; however, it may be anticipated that the effect be greatest near the middle of the plate. The curves on Figure (43) reinforce this impression.

On the basis of the excellent agreement noted here, it can be concluded that the incorporation of plastic and creep effects into the present method of structural analysis will not be restricted in any way by the particular linear analysis method employed.

APPENDIX II

POISSON'S RATIO EFFECT

The strain energy relationship for an elastic plate in terms of in plane stresses is given by the volume integral:

$$U = \frac{1}{2E} \int_{V} \left[\sigma_{xx}^{2} + \sigma_{yy}^{2} - 2\nu \sigma_{xx}^{2} \sigma_{yy} + 2(1 + \nu) \sigma_{xy}^{2} \right] dV$$

The idealized structure corresponding to a rectangular plate for a finite element matrix force analysis has orthogonal bars taking only normal stresses and panels in pure shear. Figure (8), the shear-lag specimen, represents a typical idealization of this type. Defining $\bar{\sigma}_{xx}$ and $\bar{\sigma}_{yy}$ as the axial stress in the bars and $\bar{\sigma}_{xy}$ as the shear stress in the panels, the strain energy U' of the idealized structure is sometimes taken as:

$$U' = \frac{1}{2E} \int_{V} \left[\tilde{\sigma}_{xx}^{2} + \tilde{\sigma}_{yy}^{2} + 2(1 + \nu) \tilde{\sigma}_{xy}^{2} \right] dV$$

Comparing the plate strain energy U with the idealized structure strain energy U' it is obvious that the finite element expression neglects to account for the interaction term of the plate $(-2v \sigma_{XX}\sigma_{yy})$ which is due to Poisson's ratio. This uncoupling of the normal stresses has the effect of making the idealized plate less rigid than the actual plate. The finite element idealization is refined by including the term $(-2v \bar{\sigma}_{XX}\bar{\sigma}_{yy})$ in U' making the model more consistent with the elastic plate.

The sketch, Figure (9), shows a shear panel with adjacent axial load carrying bars. Assume the structure represents a portion of a plate structure ℓ inches iong, b inches wide and t inches thick. The normal stresses at one corner of the idealized structure are designated σ_1 and σ_2 in the x and y directions respectively. It is sufficiently accurate in accounting for the interaction term to assume that the normal stresses are constant over the plate corresponding to the shaded quadrant and also to assume that these stresses are equal to σ_1 and σ_2 , the values at the corner. The strain energy term to be included is represented by

where α_{12} represents the interaction flexibility influence coefficient. Carrying out the integration over the quadrant of the plate, the influence coefficient is evaluated.

$$\alpha_{12} = -\frac{1}{E} \sqrt{\frac{dV}{V}} = -\frac{v}{E} \frac{b\ell t}{4}$$

This term together with the reciprocal term α_{21} and similar terms for other biaxially stressed areas, when included in the flexibility matrix, account for the Poisson's ratio effect.

APPENDIX III

INSTABILITY ANALYSIS OF THE CONSTANT STRESS AND CONSTANT STRAIN METHODS

The stability of the two methods is easily tested by determining whether perturbations introduced into the analysis grow or decay with succeeding steps. It is instructive, however, to take the following approach. In place of the computed quantities, introduce exact quantities, signified by a caret and associated error terms, in the manner

$$\left\{q_{i}^{(k)}\right\} = \left\{\widehat{q}_{i}^{(k)}\right\} + \left\{\xi_{i}^{(k)}\right\}.$$
 III-1

The exact relation is taken to be

$$\left\{\widehat{q}_{i}^{(k)}\right\} = \left[\Gamma_{im}\right]\left\{P_{m}^{(k)}\right\} + \left[\Gamma_{ij}\right]\left\{\widehat{z}_{j}^{(k)}\right\}.$$
 III-2

Equation 3 can be written in terms of member loads

$$\left\{q_{j}^{(k)}\right\} = \left[\Gamma_{im}\right]\left\{r_{m}^{(k)}\right\} + \left[\Gamma_{ij}\right]\left\{e_{j}^{(k-1)}\right\}$$
 III-3

Substituting Equation III-1 into Equation III-3 gives

$$\left\{ \mathbf{\hat{q}_{i}^{(k)}} \right\} + \left\{ \mathbf{\hat{g}_{i}^{(k)}} \right\} = \left[\mathbf{\Gamma}_{im} \right] \left\{ \mathbf{\hat{p}_{m}^{(k)}} \right\} + \left[\mathbf{\Gamma}_{i,j} \right] \left\{ \mathbf{\hat{e}_{i-1}^{(k-1)}} \right\}$$

from which Equation III-2 may be subtracted to yield the following expression for the errors

$$\left\{ \xi_{1}^{(k)} \right\} = \left[\Gamma_{1,j} \right] \left\{ e_{j}^{(k-1)} - \hat{e}_{j}^{(k)} \right\}$$
 III-4

The constant stress and constant strain methods are now distinguished by the manner in which the $\epsilon_j^{(k-1)}$ are specified. The Remberg-Osgood stress-strain relation, which we may write in the form

$$e_{i}^{(k)} = \frac{q_{i}^{(k)}}{E_{i}A_{i}} + \frac{3}{7}\frac{\sigma_{oi}}{E_{i}} \left| \frac{q_{i}^{(k)}}{\sigma_{oi}Ai} \right|^{n} \frac{q_{i}^{(k)}}{\left| q_{i}^{(k)} \right|}$$

will be used in exemining both methods.

The nonlinear strains, in the constant stress method, are given by

$$\mathbf{e}_{\mathbf{j}}^{(k-1)} = \frac{3 \cdot \circ \mathbf{j}}{7 \cdot \mathbf{E}_{\mathbf{j}}} \left| \frac{\mathbf{q}_{\mathbf{j}}^{(k-1)}}{\sigma_{\mathbf{o},\mathbf{j}} \cdot \mathbf{A}\mathbf{j}} \right|^{n} \frac{\mathbf{q}_{\mathbf{j}}^{(k-1)}}{\left|\mathbf{q}_{\mathbf{j}}^{(k-1)}\right|}$$

which, on using Equation III-1, may be written in the expanded form

$$\mathbf{e}_{\mathbf{j}}^{(k-1)} = \frac{3\sigma_{0,\mathbf{j}} \widehat{\mathbf{q}}_{\mathbf{j}}^{(k-1)}}{7E\mathbf{j} \left| \widehat{\mathbf{q}}_{\mathbf{j}}^{(k-1)} \right|} \left| \widehat{\mathbf{q}}_{\mathbf{j}}^{(k-1)} \right|^{n} + n \left| \widehat{\mathbf{q}}_{\mathbf{j}}^{(k-1)} \right|^{n-1} \cdot \underbrace{\mathbf{g}_{\mathbf{j}}^{(k-1)}}_{\sigma_{0,\mathbf{j}} A \mathbf{j}} + \dots \right|$$

A similar expansion can be constructed for the $\hat{\epsilon}_1^{(k)}$ on introducing

$$\left\{\widehat{\mathbf{q}}_{\mathbf{j}}^{(\mathbf{k})}\right\} = \left\{\widehat{\mathbf{q}}_{\mathbf{j}}^{(\mathbf{k}-1)}\right\} + \left\{\widehat{\mathbf{aq}}_{\mathbf{j}}^{(\mathbf{k})}\right\}$$

which gives

$$\widehat{\boldsymbol{\varepsilon}}_{j}^{(k)} = \frac{3\sigma_{o,j}}{7E_{j}} \left| \frac{\widehat{\boldsymbol{q}}_{j}^{(k)}}{\left| \widehat{\boldsymbol{q}}_{j}^{(k)} \right|} \left[\left| \frac{\widehat{\boldsymbol{q}}_{j}^{(k-1)}}{\sigma_{o,j} A j} \right|^{n} + n \left| \frac{\widehat{\boldsymbol{q}}_{j}^{(k-1)}}{\sigma_{o,j} A j} \right|^{n-1} \cdot \frac{\widehat{\boldsymbol{A}}_{j}^{(k)}}{\sigma_{o,j} A j} + \cdots \right]$$

Substituting the foregoing expression into Equation III-4, and assuming small errors in the sense that $\xi_1 << q_1$ and small steps in the loading such that $\Delta q_1 << q_1$, so that terms containing the products of these quantities may be dropped, we obtain

$$\left\{ \boldsymbol{\xi_{i}^{(k)}} \right\} = \left[\boldsymbol{\Gamma_{i,j}} \right]_{\overline{TE}_{j}^{A}_{j}}^{\overline{3n}} \left[\frac{\widehat{q}_{j}^{(k-1)}}{\widehat{q}_{j}^{(k-1)}} \right] \left[\frac{\widehat{q}_{j}^{(k-1)}}{\widehat{\sigma}_{o,j}^{A}_{j}} \right]^{n-1} \left[\boldsymbol{\xi_{j}^{(k-1)}} - \Delta \widehat{q}_{j}^{(k)} \right]$$

which may be re-written

$$\left\{ \boldsymbol{\xi}_{i}^{(k)} \right\} = \begin{bmatrix} \Gamma_{i,j} \end{bmatrix} \begin{bmatrix} 1/\overline{E}^{(k-1)} & A_{j} \end{bmatrix} \begin{bmatrix} 1 - \frac{2\widehat{q}_{i}^{(k)}}{\overline{g}_{i}^{(k-1)}} \end{bmatrix} \left\{ \boldsymbol{\xi}_{j}^{(k-1)} \right\} \qquad \text{III-5}$$

where \overline{E}_j give the slope of the stress versus inelastic-strain curve at the individual element stress levels.

Instability develops when the errors in the k^{th} step increase over those in the $k-1^{st}$ step. Clearly, the method would be expected to be unstable, if any of the inequalities $\xi_1^{(k)} > \xi_1^{(k-1)}$ were satisfied directly. A more critical check, however, is the consider the entire set of $\{\xi_1^{}\}$ as a vector (in n-dimensional space where n is equal to the number of elements) and apply the condition that the Eucliudean length of this vector does not increase. Mathematically, this means that for stability

$$\left\{\xi_{1}^{(k)}\right\}^{T}\left\{\xi_{1}^{(k)}\right\} \leq \left\{\xi_{1}^{(k-1)}\right\}^{T}\left\{\xi_{1}^{(k-1)}\right\}$$

where the critical condition is defined by using the equality sign.

For simplicity, we consider the case of infinitesimally small steps in the loading, so that the Δq_1 terms may be neglected, and further, denote

$$\begin{bmatrix} \Gamma_{i,j} \end{bmatrix} \begin{bmatrix} 1 & / \overline{E}_{j}^{(k-1)} & A_{j} \end{bmatrix} = \begin{bmatrix} B_{i,j}^{(k-1)} \end{bmatrix}$$

The critical condition for instability then becomes

$$\left\{ \boldsymbol{\xi}_{i}^{(k)} \right\}^{T} \left\{ \boldsymbol{\xi}_{i}^{(k)} \right\} = \left\{ \boldsymbol{\xi}^{(k-1)} \right\}^{T} \begin{bmatrix} \boldsymbol{B}_{i,j}^{(k-1)} \end{bmatrix}^{T} \begin{bmatrix} \boldsymbol{B}_{i,j}^{(k-1)} \end{bmatrix} \left\{ \boldsymbol{\xi}_{i}^{(k-1)} \right\}$$

$$= \left\{ \boldsymbol{\xi}_{i}^{(k-1)} \right\}^{T} \left\{ \boldsymbol{\xi}_{i}^{(k-1)} \right\}$$

$$= \left\{ \boldsymbol{\xi}_{i}^{(k-1)} \right\}^{T} \left\{ \boldsymbol{\xi}_{i}^{(k-1)} \right\}$$

It is now observed that the eigenvalues of

$$\begin{bmatrix} B_{ij}^{(k-1)} \end{bmatrix}^{T} \begin{bmatrix} B_{ij}^{(k-1)} \end{bmatrix}$$

will all be positive, hence the condition that none of these eigenvalues be greater than one (which becomes the stability requirement), can be replaced by the more severe condition that the sum of the eigenvalues not be greater than one. This latter condition can be assured by requiring that the sum of the squares of all elements of B_{ij} not be greater than one, and in addition, that the absolute sum of any row or

column in B_{ij} not be greater than one. The critical stress is then found from the largest of these sums.

In the case of the example truss problem, where $E_i = E = 10^7$ psi, n = 10, $A_i = 1.0$ sq. in., and $\sigma_{oi} = \sigma_{o} = 10^5$ psi, the sum of the squares approach, viz.,

$$\left(\frac{3n}{7E} \left(\frac{\sigma_{cr}}{\sigma_{o}}\right)^{n-1}\right)^{2} \times \sum_{ij=1}^{3} \Gamma_{ij}^{2} = 1$$

yields $\sigma_{\rm cr}$ = 83,800 psi., while the rows and columns approach gives $\sigma_{\rm cr}$ = 82,900 psi.

Recall that the foregoing development has determined the minimum value at which instability might occur. It is of interest to compute a critical value of stress at which instability is strongly assured to occur. This can be done by returning to the initial notion that instability will occur if $\xi_i^{(k)} > \xi_i^{(k-1)}$. This amounts to restricting attention to the diagonal elements in the B_{ij} matrix. The corresponding critical stress (lowest value) will be given by the largest (in absolute value) element on the diagonal in the B_{ij} matrix. This corresponds to the -0.414 x 10⁷ term in the Γ_{ij} matrix, so that the critical stress is given by

$$\frac{3n}{7E} \left(\frac{\sigma_{cr}}{\sigma_{o}}\right)^{n-1} \times (0.414 \times 10^{7}) = 1$$

which gives $\sigma_{\rm cr}$ = 93,800 psi. The lowest stress at which instability would develop, in the case of the example truss problem, would therefore be expected to occur between 82,900 psi and 93,800 psi.

Note that if only one structural element were inelastic, then the diagonal term in the Γ_{ij} matrix corresponding to this element would give the correct critical stress by the latter procedure. Both of the foregoing values of critical stress have been indicated in Figure 4, where they are seen to correlate with the experimental (computer) results. The simple approach of considering only the diagonal elements

appears to be advantageous in the present problem. With this approach, it is easy to see that finite values of Δq_1 , which make the elements in the second diagonal matrix in Equation III-5 less than one, must raise the stress for instability, which explains the progression of critical stresses (with increasing load step size) appearing in Figure 4.

Finally, it is noted that certain of the foregoing results, viz., the value of σ_{cr} based on one diagonal elements alone, can be obtained simply by introducing $q_1^{(k)} + \psi_1^{(k)}$ in place of $q_1^{(k)}$ directly into Equation III-3, and regarding the $\psi_1^{(k)}$ as perturbations on the $q_1^{(k)}$. The additional results, such as the demonstration of the effects of finite Δq_1 , however, are not obtained by this procedure.

In the case of the constant strain method, in addition to the error quantities in the member loads

$$\left\{d_{(\mathbf{F})}^{\mathbf{I}}\right\} = \left\{d_{(\mathbf{F})}^{\mathbf{I}}\right\} + \left\{\tilde{\mathbf{g}}_{(\mathbf{F})}^{\mathbf{I}}\right\}$$

we also introduce error quantities for the relaxed loads

$$\left\{q_{*1}^{(k)}\right\} = \left\{\widehat{q}_{*1}^{(k)}\right\} + \left\{\underline{\epsilon}_{*1}^{(k)}\right\}.$$

The equation defining the relaxed loads, written for the generic ith member, is

$$\frac{q_{1}^{(k)}}{E_{1}A_{1}} + e_{1}^{(k-1)} = \frac{q_{*1}^{(k)}}{E_{1}A_{1}} + \frac{3q_{*1}^{(k)}}{7E_{1}A_{1}} \left| \frac{q_{*1}^{(k)}}{\sigma_{01}A_{1}} \right|^{n-1}$$

which may be written in the following form

$$\left| \frac{\widehat{q_{1}^{(k)}} + \xi_{1}^{(k)}}{\mathbb{E}_{1}^{A_{1}}} \right| \frac{q_{1}^{(k)}}{|q_{1}^{(k)}|} + \frac{3\sigma_{01}}{7\mathbb{E}_{1}} \left| \frac{\widehat{q_{k+1}^{(k-1)}} + \xi_{k+1}^{(k-1)}}{\sigma_{01}^{A_{1}}} \right|^{n} \frac{q_{k+1}^{(k-1)}}{|q_{k+1}^{(k-1)}|}$$

$$= \left| \frac{q_{\frac{k_{1}}{2}}^{(k)} + g_{\frac{k_{1}}{2}}^{(k)}}{E_{1}^{k_{1}}} \right| \frac{q_{\frac{k_{1}}{2}}^{(k)}}{\left| q_{\frac{k_{1}}{2}}^{(k)} \right|} + \frac{3\sigma_{01}}{7E_{1}} \left| \frac{\hat{q}_{\frac{k_{1}}{2}}^{(k-1)} + \hat{Q}_{\frac{k_{1}}{2}}^{(k-1)} + g_{\frac{k_{1}}{2}}^{(k)}}{\sigma_{01}^{k_{1}}} \right|^{n} \frac{q_{\frac{k_{1}}{2}}^{(k)}}{\left| q_{\frac{k_{1}}{2}}^{(k)} \right|}$$

If we now apply the condition of no load reversals, then the terms $q_1^{(k)}/|q_1^{(k)}|$ etc., will all produce the same sign (for a given element) and hence may be cancelled out. Applying the condition that all error terms ξ_1 and load increments Δq_1 are much smaller than the load magnitude $|q_1|$, leads to the result

$$\xi_{i}^{(k)} = \xi_{*i}^{(k)} - \frac{E_{i}}{E_{*i}^{(k-1)}} \left(\xi_{*i}^{(k-1)} - \xi_{*i}^{(k)} - \Delta_{q_{*i}^{(k)}} \right)$$

where

$$1/\widehat{\overline{E}}_{*i}^{(k-1)} = \frac{3n}{7E_i} \left| \frac{\widehat{q}_{*i}^{(k-1)}}{\sigma_{oi}^{A_i}} \right|^{n-1}$$

The corresponding form of Equation III-4 may now be written by introducing the exact load-reduction-increments $\Delta \hat{q}_{r,j}^{(k)}$, where

$$\Delta \widehat{q}_{rj}^{(k)} = \widehat{q}_{j}^{(k)} - \widehat{q}_{*j}^{(k)}$$

which leads to
$$\left\{ \boldsymbol{\xi}_{1}^{(k)} \right\} = \left[\Gamma_{1,j} \right] \left\{ \frac{3\sigma_{0,j}}{7 E_{j}} \left| \frac{\widehat{\boldsymbol{q}}_{*,j}^{(k-1)} + \boldsymbol{\xi}_{*,j}^{(k-1)}}{\sigma_{0,j}^{A} j} \right|^{n} \frac{\boldsymbol{q}_{*,j}^{(k-1)}}{\left| \boldsymbol{q}_{*,j}^{(k-1)} \right|} - \frac{3\sigma_{0,j}}{7 E_{j}} \left| \frac{\widehat{\boldsymbol{q}}_{*,j}^{(k-1)} + \Delta \widehat{\boldsymbol{q}}_{1,j}^{(k-1)} + \Delta \widehat{\boldsymbol{q}}_{1,j}^{(k)}}{\sigma_{0,j}^{A} j} \right|^{n} \left| \frac{\widehat{\boldsymbol{q}}_{j}^{(k)}}{\left| \boldsymbol{q}_{j}^{(k)} \right|} \right\}$$

Applying, once again, the smallness requirement on the 5, and Aq, , yields

$$\begin{bmatrix}
1 + \frac{E_{i}}{E_{*i}} & \left\{ \xi_{*i}^{(k)} \right\} = \\
\begin{bmatrix}
\Gamma_{ij} & \left[\frac{A_{i}}{E_{*j}} & A_{j} \right] & -\frac{A_{i}^{(k-1)} + A_{i}^{(k)}}{E_{*i}} & -\frac{A_{i}^{(k-1)} + A_{i}^{(k)}}{E_{*i}} & -\frac{A_{i}^{(k-1)} + A_{i}^{(k)}}{E_{*i}} & -\frac{A_{i}^{(k-1)} + A_{i}^{(k)}}{E_{*i}} & -\frac{A_{i}^{(k)} + A_{i}^$$

$$+ \left\lceil \frac{\mathbb{E}_{\underline{i}}}{\mathbb{E}_{\underline{*}\underline{i}}^{(k-1)}} \right\rceil \left\lceil 1 - \frac{\Delta q_{\underline{i}}^{(k)}}{g_{\underline{*}\underline{i}}^{(k-1)}} \right\rceil \left\{ g_{\underline{*}\underline{i}}^{(k-1)} \right\}$$

where the absolute value signs have been omitted for simplicity.

The check for the occurrence of instability may now be carried out in the same manner as for the constant stress method. Thus, considering only the case of infinitesimal load increments, the corresponding form of the $B_{1,1}$ matrix, as defined by Equation III-6, is found to be

$$\begin{bmatrix} \mathbf{B}_{i,j} \end{bmatrix} = \begin{bmatrix} \overline{\mathbf{E}}_{(\mathbf{cr})i} \\ \overline{\mathbf{E}}_{(\mathbf{cr})i} + \overline{\mathbf{E}}_{\underline{i}} \end{bmatrix} \begin{bmatrix} \mathbf{I}/(\overline{\mathbf{E}}_{(\mathbf{cr})j} \mathbf{A}_{\underline{j}}) \end{bmatrix} + \begin{bmatrix} \mathbf{E}_{\underline{i}}/\overline{\mathbf{E}}_{(\mathbf{cr})\underline{i}} \end{bmatrix}$$

A numerical check for the special case of the truss problem shows that the critical condition of the eigenvalues summing to unity calls for physically inadmissible values of $\overline{E}_{(cr)}$. A simpler demonstration of this property is provided by the "direct approach" (i.e., setting $\underline{E}_{(k)}^{(k)} = \underline{E}_{(k-1)}^{(k-1)}$). In this case, the critical stress is given by the lowest value corresponding to the "n" equations obtained by equating the diagonal elements of

$$\left[1 + \frac{E_{\underline{i}}}{E(cr)\underline{i}}\right]^{-1} \left[\Gamma_{\underline{i},\underline{j}}\right] \left[1/(\overline{E}_{(cr),\underline{j}} A_{\underline{j}})\right] + \left[E_{\underline{i}}/\overline{E}_{(cr),\underline{i}}\right] = \begin{bmatrix} \pm & 1 \end{bmatrix}$$

In the example truss problem, where $E_i = E$, $\sigma_{oi} = \sigma_o$, and $A_i = 1.0$, and where the three diagonal elements in the Γ_{ij} matrix can be denoted by $-\zeta_i E$, where in turn $0 < \zeta_i < 1$, the foregoing matrix equation reduces to the following simple algebraic equation

$$\frac{-\zeta_1 E + E}{\overline{E}_{(cr)i} + E} = \pm 1 .$$

The indicated critical values are easily seen to be - ζ_1 E and - $(2 - \zeta_1)$ E, both of which are physically inadmissible for the Ramberg-Osgood stress-strain relation. Thus, the constant strain method is indicated to be free of instability in this case. The problem of accuracy, of course, is another matter, due to the necessity of working with finite (and preferably large) load steps. These, apparently, are responsible for the slow divergence of the computer results shown in Figure 5.

APPENDIX IV

ROTATION OF AXES OF ANISOTROPY

Let the x and y axes be rotated from the axes of anisotropy in a positive sense so that from the strain transformation equations we get:

$$de_{xy} = \int_{0}^{2} de_{11} + \int_{0}^{2} de_{22} + 2 \int_{0}^{2} de_{12}$$

$$de_{xy} = \int_{0}^{2} de_{11} + \int_{0}^{2} de_{22} + 2 \int_{0}^{2} de_{12}$$

$$de_{xy} = \int_{0}^{2} de_{11} + \int_{0}^{2} de_{22} + 2 \int_{0}^{2} de_{12}$$

$$de_{xy} = \int_{0}^{2} de_{11} + \int_{0}^{2} de_{22} + 2 \int_{0}^{2} de_{12}$$

$$de_{xy} = \int_{0}^{2} de_{11} + \int_{0}^{2} de_{22} + 2 \int_{0}^{2} de_{12}$$

when \mathcal{L} , and m are the usual direction cosines of the x-axis with respect to the orthogonal axes.

Similarly from the stress transformation equations:

$$\sigma_{11} = \int_{-\infty}^{2} \sigma_{x} + m^{2} \sigma_{y} - 2 \int_{-\infty}^{2} m \sigma_{xy}$$

$$\sigma_{22} = m^{2} \sigma_{x} + \int_{-\infty}^{2} \sigma_{y} + 2 \int_{-\infty}^{2} m \sigma_{xy}$$

$$\sigma_{12} = \int_{-\infty}^{2} m \sigma_{x} - \int_{-\infty}^{2} m \sigma_{y} + (\int_{-\infty}^{2} m \sigma_{xy}) \sigma_{xy}$$
IV-2

Substituting Equation IV-2 into the appropriate expressions in Equation 12 gives a set of equations as follows:

$$de_{11} = \frac{d\bar{e}}{\bar{\sigma}} \left[(\ell^2 \alpha_{11} - m^2 \alpha_{12}) \sigma_x + (m^2 \alpha_{11} - \ell^2 \alpha_{12}) \sigma_y \right]$$

$$- 2 \ell m (\alpha_{11} + \alpha_{12}) \sigma_{xy}$$

$$de_{22} = \frac{d\bar{e}}{\bar{\sigma}} \left[(m^2 \alpha_{22} - \ell^2 \alpha_{12}) \sigma_x + (\ell^2 \alpha_{22} - m^2 \alpha_{12}) \sigma_y \right]$$

$$+ 2 \ell m (\alpha_{22} + \alpha_{12}) \sigma_{xy}$$

$$de_{12} = \frac{d\bar{e}}{\bar{\sigma}} 3 \alpha_{\mu\mu} \left[\ell m (\sigma_x - \sigma_y) + (\ell^2 - m^2) \sigma_{xy} \right]$$

Finally substituting Equation IV-3 into Equation IV-1, simplifying and defining three new coefficients δ , δ_1 and δ_2 such that $\delta = \alpha_{12} - \frac{3}{2}\alpha_{11}$, $\delta_1 = (\alpha_{11} + \delta)$ and $\delta_2 = (\alpha_{22} + \delta)$ the appropriate incremental flow equations become:

$$d_{\xi_{X}} = \frac{d\bar{\xi}}{\bar{\sigma}} \left[(\mathcal{L}^{h} \delta_{1} + m^{h} \delta_{2} - \delta) \sigma_{X} - (\alpha_{12} - \mathcal{L}^{2} m^{2} \delta_{1} - \mathcal{L}^{2} m^{2} \delta_{2}) \sigma_{Y} \right]$$

$$- 2 \mathcal{L} m (\mathcal{L}^{2} \delta_{1} - m^{2} \delta_{2}) \sigma_{XY}$$

$$- 2 \mathcal{L} m (m^{2} \delta_{1} - \mathcal{L}^{2} \delta_{2}) \sigma_{XY}$$

$$- 2 \mathcal{L} m (m^{2} \delta_{1} - \mathcal{L}^{2} \delta_{2}) \sigma_{XY}$$

$$- 2 \mathcal{L} m (m^{2} \delta_{1} - \mathcal{L}^{2} \delta_{2}) \sigma_{XY}$$

$$- 2 \mathcal{L} m (\mathcal{L}^{2} \delta_{1}^{1} - m^{2} \delta_{2}) \sigma_{X} - 2 \mathcal{L} m (m^{2} \delta_{1} - \mathcal{L}^{2} \delta_{2}) \sigma_{Y}$$

$$- 2 \mathcal{L} m (\mathcal{L}^{2} \delta_{1}^{1} - m^{2} \delta_{2}) \sigma_{X} - 2 \mathcal{L} m (m^{2} \delta_{1} - \mathcal{L}^{2} \delta_{2}) \sigma_{Y}$$

Insertion of Equation IV-2 into 11 gives the expression for effective stress:

$$\bar{\sigma}^{2} = \left[(\mathbf{l}^{14} \delta_{1} + \mathbf{m}^{14} \delta_{2} - \delta) \sigma_{\mathbf{x}}^{2} - 2(\alpha_{12} - \mathbf{l}^{2} \mathbf{m}^{2} \delta_{1} - \mathbf{l}^{2} \mathbf{m}^{2} \delta_{2}) \sigma_{\mathbf{x}} \sigma_{\mathbf{y}} \right] \\
+ (\mathbf{l}^{14} \delta_{2} + \mathbf{m}^{14} \delta_{1} - \delta) \sigma_{\mathbf{y}}^{2} + (3\alpha_{14} + 4\mathbf{l}^{2} \mathbf{m}^{2} \delta_{1} + 4\mathbf{l}^{2} \mathbf{m}^{2} \delta_{2}) \sigma_{\mathbf{x}\mathbf{y}}^{2} \\
- 4\mathbf{l} \mathbf{m} (\mathbf{l}^{2} \delta_{1} - \mathbf{m}^{2} \delta_{2}) \sigma_{\mathbf{x}} \sigma_{\mathbf{x}\mathbf{y}} - 4\mathbf{l} \mathbf{m} (\mathbf{m}^{2} \delta_{1} - \mathbf{l}^{2} \delta_{2}) \sigma_{\mathbf{y}} \sigma_{\mathbf{x}\mathbf{y}} \right]$$
IV-5

Now suppose we make an uniaxial stress-strain test for the x-direction. The valid expressions become:

$$de_{\mathbf{x}} = \frac{d\bar{e}}{\bar{\sigma}} (\mathbf{I}^{l_1} \delta_1 + \mathbf{m}^{l_2} \delta_2 - \delta) \sigma_{\mathbf{x}}$$

$$\bar{\sigma}^2 = (\mathbf{I}^{l_2} \delta_1 + \mathbf{m}^{l_2} \delta_2 - \delta) \sigma_{\mathbf{x}}^2$$

From the three Equations IV-4, we obtain equations similar to Equation 15. This equation is augmented under restrictions of equal plastic work thus:

$$a\sqrt{\alpha_{11}} = b\sqrt{\alpha_{22}}$$
 $c\sqrt{\alpha_{33}} = d\sqrt{4b_1 + m^4b_2 - b}$ IV-6

Assigning the value of unity to one " α " as before we obtain the relative values of the others. In particular we now obtain a value for $(L^4\delta_1 + m^4\delta_2 - \delta)$ which is a function of α_{11} , α_{22} , α_{33} all known and α_{44} unknown. Therefore α_{44} may be determined.

APPENDIX V

INELASTIC MATRIX COMPUTER PROGRAM

A. Program Description

This is a brief description of the Grumman inelastic matrix program for carrying out elastic-plastic-creep analysis - deck No. 45128 - Elastic Unloading (follows Hooke's Law when unloading), including anisotropy.

This program for elastic-plastic analysis has proved to be quite adaptable for analytic investigations. It has been modified to include an option for anisotropic analysis. Previously, the program was modified to use time-hardening theory, deformation theory, inelastic unloading, and constant stress theory (none of which have been retained in the final program). It was not necessary to do major program revisions to accommodate these variations. The program housekeeping is arranged so that modifications to the manipulation of data will not affect the housekeeping. Thus the program makes a convenient framework to explore various calculation procedures.

The program is written in Fortran II to run on the Grumman IEM These are 2 channel (A and B) machines with 6 drives per channel; 32,768 words of core storage; on-line card reader; on-line printer: and printer clock. The program is set to run under Fortran Monitor control which uses a \$JOB card for identification. Input is on logical tape 7 (A-2), print output on logical tape 6 (A-2) and punched output on logical tape 5 (B-4) (not used by this program). Logical tape 8 (B-1) is used for storage of binary output which is converted to BCD print output in link 6 (at the end of job). The program will accept an input data tape on logical tape 9 (A-5) and will write a binary save tape for restart on logical tape 11 (A-6). These 2 auxiliary tapes are optional for each run (see description of the control cards). The Grumman IOU subroutine, as well as the subroutines for rewinding and unloading a tape (RUN) and for moving to the start of a designated file (FILTAP) are included, as required in the program, in column binary form.

The program tape furnished to Wright Patterson Air Force Base contains all the information needed to duplicate our analysis. It is in the following sequence:

- File 1 a 1-card BCD label tested by the program to distinguish BCD data tape from binary save tape.
- File 2 BCD card images for matrices SIM AND SIJ. See pages 79 and 80 for a description of the matrices and their format.

File 3 - BCD card images of Fortran program (6 links), each link including binary subroutines previously mentioned.

Multiple (6) end of file marks.

We recommend that all 3 files of this tape be copied for use, then that file 3 be punched onto Fortran cards. The punching program must be able to handle mixed-mode cards to accommodate the short binary subroutines. This deck of cards, with the proper *I.D. or \$JOB card, will then be in proper form for a Fortran compile and execute, using the copied tape on drive A-5 (logical 9). The program uses only the data from files 1 and 2; it will not move into file 3. This 2-file format for the data tape is generated by the GISMO matrix system in use at Grumman and elsewhere.

Each link of the program contains the non-IBM subroutines needed for operation. Standard input-output subroutines etc. will be taken from the library tape. As a point of information, the program contains six links numbered consecutively from 1 to 6.

- 1) Link 1 reads the first control card, and reads all other decimal input supplied.
- 2) Link 2 is used only on a restart job. It reads the modified step table, if provided, and part of the binary input tape.
- 3) Link 3 is used only on a restart job, and reads the balance of the binary input tape.
- 4) Link 4 is the processing link. It does all the calculation, print control, and writing of binary output on tape B-1 to be converted to BCD print output by Link 6.
- 5) Link 5 writes a binary tape for restart, then transfers to Link 6. If no binary tape is to be written, exit is from Link 6.
- 6) Link 6 reads the binary output stored on tape B-1 and converts it to BCD output on tape A-3 for printing. When tape B-1 has been completely processed, a message to the operator indicates that it need not be saved. If, due to machine error or operator intervention, tape B-1 is not processed into prints on A-3, but is saved, then Link 6 can be used as a separate program using B-1 as a data tape and will process B-1 into prints on A-3. Link 6 does not use any data from COMMON. All necessary clues are stored on B-1.

Sequencing and details of the data cards follow. The symbols used in the program for various items of input data are listed on page 77 and are shown on the sample key-punching sheet page 72.

The data cards are used in the following sequence, immediately after the *DATA card required by the Monitor:

- 1. General clue card (FORMAT 1) containing KLU4, NINCLD, NA, KLU7, KLUISO, ALPHA, EETA, GAMMA, GNU, and a title or caption.
- 2. Table of load or time steps desired. Up to ten cards defining ten steps may be used. Load steps and time steps may be used in any sequence. The maximum level for each load or time step may be above or below the previous maximum level of load or time. The program verifies the algebraic sign of the increment, and corrects it if necessary. Each card contains four variables TEMP1, TEMP2, TEMP3, TEMP4 in FORMAT 2.
- 3. Data matrices. These may be provided in any sequence. Each matrix has a header card in FORMAT 3, one or more data cards in FORMAT 4, and a blank card to end it. The last input matrix on the Monitor input tape must be followed by one added blank card (two total) to trip the program into operation.

In the event that a job is running overtime, and it is desired to stop the program in a restartable form, mount a blank tape on logical tape 11 (drive A-6) and set Sense Switch 6 on. This will write the contents of memory on A-6 in proper form to continue the run later. The program distinguishes between the saved binary tape and a decimal input tape at starting time. Either is mounted on logical tape 9 (Drive A-5).

Built-in pauses in the program are as follows:

- Pause IIIII to mount the data input tape at the start of the program, if all matrices are not on the Monitor input tape
 A-2. For this KLU4, in the first data card, should be a "1" to
 "4" indicating the count of decimal matrices on A-5. If A-5
 is a binary saved tape from a preceding run, any digit (except zero) acceptable for KLU4.
- 2. Pause 1 to mount a blank tape on A-6 to receive memory. This is reached either with Sense Switch 6, or with a card in the table of steps punched TAPE in columns 7-10.
- B. Symbols and Format of the Data Cards
- 1. General Clue Card FORMAT 1

Cols. Field Symbol

1 II KLU4

This gives the number of input matrices on the auxiliary input tape (A-5). If all matrices are on the monitor tape, leave this blank. If using binary restart tape, use a digit. Maximum number of decimal input matrices on the auxiliary input tape is 4.

Cols.	Field	Symbol	
2-4	13	NINCLD	This gives the number of non-increment recycles at each load or time level. The total cycles at each level is NINCLD + 1. When printing, the first, tenth, twentieth, etc., and last cycle of each printable level will be printed.
5-7	13	NA	This sets the frame size for the problem to be handled. NA is three times the number of nodes. Maximum value is 165 (55 nodes).
.8	n	KLU7	O, or blank, prints 5 preselected matrices on cycles indicated by the step table; 1 prints all matrices on cycles indicated by the step table. 2 prints 5 preselected matrices on all cycles; 3-9 print all matrices on all cycles.
9	n	KLUISO	O indicates an isotropic run 1 indicates an anisotropic run
10	ıx		Not used
11-20	E10.3	ALPHA	A variable defined by the creep-strain equation.
21-30	E10.3	BETA	A variable defined by the creep-strain equation.
31-35	F5.2	GAMMA (A variable defined by the creep-strain equation.
36-40	₹5.2	GNU	Poisson's ratio "nu"
41-50	lox		Not used
51-80	, 5A6	TA-TE	Any 30 characters of alpha-numeric text to be printed as a heading for identification purposes.
M-2-1 -	C+	/1 dmd+	to ton outsides) BODMAN O

2. Table of Steps (limited to ten entries) - FORMAT 2

COTS.	kiera	
1-6	6 x ,	Not used
7-10	A ¹ t	LOAD indicates a load step, TIME indicates a time step, TAPE indicates write memory on a save-tape on drive A-6 (logical #11) then exit.

Cols.	Field	
		FINS or blank indicates end of table (this may be the 11th card in the table).
11-20	E10.6	Upper limit of step in pounds or hours
21-30	E10.1	Interval or increment for calculation
31-40	E10.1	Interval or increment for print output. Prints are generated on tape A-3 for the current cycle when the current load or time level is an integral multiple of the print interval. If the print interval is left blank, no prints are generated for cycles in this step. If print interval is very small compared to the current level, then numeric problems sometimes occur in the print control subroutine (OUTPUT), and it may be necessary to re-run with the every-cycle print control "2" or "3" for KLU7 punched in the first control card.

41-80

Ignored

3. Data Matrices - Header Card - FORMAT 3

Cols.	Field		
1-6	6x .	Not use	e d
7-10	4X	patibil	ed. We use the letters MTRX for com- ity with the GISMO Matrix System, which and writes matrices in this format.
11	1 X	Not use	d.
12-17	A6	matrice	s the identification name for the input es and must correspond exactly with one following names:
		bbbSIM	Matrix of stresses for applied loads maximum size 165xl
		bbbSIJ	Matrix of stresses for member strains maximum size 165x165
•		disign	Table of stress values llxl)
		boxepsiv	Table of strain values llxl)
•	•		Mhaga tua matudaga daddag tiba atuana

These two matrices define the stressstrain curve as a series of chords. The data is entered in this format

merely to conform to the format of the SIM-SIJ matrices which were generated using the GISMO Matrix System. Note that the first value in both TSIGN an TEPSN must be zero to avoid upsetting the interpolation procedure.

TALF 12	α ₁₂	}
TALF 23	α ₂₃	Basic anisotropic parameters
TALF 31	α ₃₁	{ llxl
TALF 44	$a^{j \uparrow j \uparrow}$,

18	ıx	Not used
19-21	13	Number of rows in this matrix
22-24	13	Number of columns in this matrix
25-32	8 x	Not used
33	n	The digit 3
34-80	٠	Not used

4. Data Matrices - Data Cards - FORMAT 4

Cols.	Field	
1	1X	Not used
2-4	13	Row index for the first element
5-7	13	Column index for the first element
8-23	E16.8	The first element on this card
24	אנ	Not used
25-27	13	Row index for the second element
28-30	13	Column index for the second element
31-46	E16. 8	The second element on this card
47	1X	Not used
48-50	13	Row index for the third element
51-53	13	Column index for the third element

Cols. Field

54-69 : E16.8

The third element on this card

70-80

Not used

The last card of a matrix must be completely blank (tested in Col. 2-4). The last matrix on the Monitor input tape 7 (drive A-2) must be followed by one added blank card (two total) to trip the program into operation.

The input matrices on the Monitor tape may be in any sequence as long as each matrix starts with a header card, has all its data cards next, and ends with a blank card.

C. Anisotropic Parameter Matrices

If a run is indicated as isotropic in the first control card (KLUISO in Col. 9 is zero or blank) the program will read in the anisotropic parameters, if provided; then it will replace them with the built-in parameters for the isotropic condition. If a run is indicated as anisotropic in the first control card (KLUISO is 1 to 9), then one each of the anisotropic parameter matrices must be provided or the program will terminate on an error.

D. Restart Procedure

If the run being set up is a <u>restart</u>, the input deck can be in several forms. The first control <u>card must</u> have a digit in KLU4 so that the program will read tape A-5; NINCLD and KLU7 are read from this card. The other factors are carried from the previous run. The continuation of an isotropic run will always be isotropic, and conversely, regardless of the clue provided (KLUISO).

The table of steps may be read in again (modified) if the previous run is stopped with sense switch 6, or it may be retained and continued from the previous run. However, if the previous run is stored on tape A-6 by using a TAPE card in the step table, then a new step table must be read in.

In either case, the last data card on a restart job must be FINS or blank in columns 7-10. This means a restart data deck will have a minimum of two cards (clue card and a blank), or a maximum of 12 cards (clue card, 10 step cards and a FINS or blank).

E. Time Estimates

For time estimates, allow 3.5 minutes to compile the Fortran, 1.5 minutes to read the input tape, 2.0 seconds per cycle printed, and 100 to 110 cycles of calculation per minute. Each printed cycle writes approximately 3 feet of print tape (55 node problems).

Deck 45128 Isotropi

Matrix Analysis of an Inelastic Plate - E

01	82	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41
	_	_			RA	_	_	01		-			-	R	_	_		-	_		_			D.	_				OR	_	-	-	1				-		-	ᅱ
71	_	73			13		†	11		-	-	 		0.3		<u> </u>								E J			-					5.	2			F	5.			
ų.	NI	VC E	D		NA		U.V	1150 150		T	 		 	PHA						Н				BE	TA		-		П		6A.	\vdash	┼		П		NU	,		ヿ
П																									· —-							Г							┪	7
						Г													Г						1															
																													·											٦
		57	E	P	7	A	BI	E	(0/	VE	7	0	7	El	7	CA	AR	D.	ما	P	Lυ	S	ļ		F1	N	5	0.	R	B	1	AA	K	4	A	R4	5)		
			бΧ				A	4						EI	7.6									E/	p./									ΕI	7. /					
						7	EA	1P					7	ΕΛ	15	2							7.	E A	IP.	3							7	E٨	76	4				
						L	0	Α	D		UP	PE	R	LIM	117	OF	5	TEI	,	IA	CR	EM	EN	T F	D#	CAL	cu	47	ЮN		INC	RE	ME	NT	F	R	PR.	N	•	
						T	I	M	Ε		UF	PE	R	LIM	77	OF	S	TE	•	15	CR	EM.	-N7	F	PR	CAL	CUL	ATI	ON		INC	RE	HE	NT	FO	R	R	NT		
						T		P	_																															
L			L	L		F	I	N	\$	<u> </u>															L							L								
							_		_	_															_								L							
	L		L	_	<u> </u>		L		_	L															L	_						L							_	
L				_	X		HE					A	RU	S				N		_		-	_	1E	, 5	12	Ε	LA	N		57	A	7	-	E	A	Z	A		<u>/X</u>
	Н		5 X	_		L	4	×	<u> </u>	/X		_	-	6			/X	_	13	\vdash	-	13	\vdash		_	_	8	X_				11	-						_	_
	Н	Н			L	_	Ļ	_		_		٨	VA.	ME	_			-		VS.	N	OL	S .	-	L_	_						1	<u> ^</u>	IFO	<i>K</i>	_		-	4	_
Н		Н				_	Ţ			_	_	 	\vdash	\$	I	_			12	-		<u> </u>	Щ		-	_		Ш			·	3	<u> </u>	_				-	_	
Н		Н			-	M	T	-	X			T	Š	3	I	1		S	12.		3	Z			_	-	-	Н	\vdash	_	Н	3	┡	_		_		\dashv		
Н	Н	H	H			_	T	_	_	-			۶ E		G \$	_		Н	1	-	Н	-	Н			_	\vdash	Н	\vdash	_		ကက	┞			_		-	-	-
┝		Н	_	-		_	T			\vdash	-	A		F	9	2			1	-		-	-		┝	-		Н	Н			၁ က	-			•	-	-	_	_
┝		Н	-	_	\vdash	-	l'	1	<u> </u>	┝	۲	•		-	-	-			-	-	\vdash	┝			┝		\vdash	\vdash	\vdash		Н	2			4	AL	F2	, د	-1	47
		W	47	R	X		A	74		A	R	5	\vdash	7	TH	R	F #		EJ	F	W	FA	7	5	P	F	R	7	A A	2		R	bu	-	C	R	7	-		<u> </u>
X		73			73	-				f	H	H	H		76			-		F			, /X		I3	_		<i>I</i> 3		۲		Γ΄			H			16	g	-
Н		R(-		0(1	_	-			-	\vdash		H	E	_					-			H			1	~			_	Н	Η	-		Н		<u>-</u>			-
П	_	ON			OL		_			H				EΛ											OH			04				-	H				E٨	_	_	
		П				Г				\vdash		П	П	П						\vdash					Ť			П	Н			┢						Ī	+	_
Г		E	4	H		M	47	R	/X		15		71	R	M	'N	A	TE	D		ΒY	6	N	E	C	DN	P	E	71	EZ	Y	E	L	AN	K	-	A	24		
01	82	8	04	05	08					11	12	13	-	15		17	18	19		21	_	23	_	25	-	27	-	20	_	31		33	-	25	_	27	38	30	40	41

CODING INSTRUCTIONS:

1. Alphabetical characters are written as follows
ABCDEFGHIJKLMN PPQRFTUVWXYE
2. Numerical characters are written as follows
1234567890

otropie - Anisotropic

- Elastic Unloading (Follows Hooke's Law)


	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80
											L																														
		L	! 	!	L	10	K		L	L	L				L		_	L	3	1	6				L	L	L		L		L		L	L							L
Ц			L			L		L	L	L	<u> </u>	_	_		71	Ŀ	TE		(177	11	<u> </u>	OF	4	E	D	NE	2	L	L	L			L	L				L	L	L
Ц			┞	L		L	L		L	_	$oldsymbol{\perp}$	L	L	_	L	_	L	L		L	L				L	L	L	L	L	L	L	L	L	L					L		L
Ц		_	_	L	L	_	L	_	L	_	L	L	L			_	_	L	L	L	<u> </u>				L	L	L		lacksquare	L	L	L		_	L	_			<u> </u>	L	L
Ц		_	L	L		Ļ		_	Ļ	┞-	$oldsymbol{oldsymbol{\perp}}$	┞		_	L	_	<u> </u>	<u> </u>		L	_			_	L	L	L	L	L	L	L	_	_	L	L				_	L	L
4			Ľ	FO	R	M,	17	_	2	1	L	-	<u> </u>	_	_	<u> </u>	_	<u> </u>	_	L	L	L		_	L	L	\vdash	L	1	L	L	<u> </u>	_	L	L	L			ļ	<u> </u>	_
Ц		L	lacksquare	igspace	_	_	_	<u> </u>	L	_	\vdash	\vdash	_	L	_	_	_	_		<u> </u>	L				L	L	_	L	┞	_	L	L	_	<u> </u>	<u> </u>	L				<u> </u>	L
Ц		-	<u>i </u>	\vdash	L	<u> </u>	L	-	-	_	Ļ	<u> </u>	_	_	<u> </u>	L	_	L		<u> </u>					L	_	<u> </u>	L	ļ_	L	_	<u> </u> _	_	<u> </u>	<u> </u>			_		-	L
"		 	L	_	_	_	_	_	7	_	_	_	C	_	_	_	_							_	_	_	┞-	L	_	_	L	<u> </u>	_	_	_			-		_	L
7		 _	L	_	_	_	7	_	_	_	_		1		_		_	_					Ų		_	_	_	L	<u> </u>	L	<u> </u>	 -		<u> </u>	 -					_	<u> </u> _
Ц		_	\vdash		_	_			_	_	,	_	TA.					_							_	_	_	_	_		_		EX	!7	_					L	_
4		_	<u> </u>	E	VD	(F	7	14	14	<u> </u>	E/	77	R/	ES	.(84	A	YK.	C	4.5	D	<u></u>		45	0	1	CI	P	E	<u>P</u>)	_	_	<u> </u>	_			Ш		Ļ	_
4	٠.	<u> </u>	igspace	\vdash	L	_	L	_	Ļ	_	\vdash	_	_		_	_	_	_	Ш	_		Н		_	_	_	<u> </u> _	_	_	_	_	<u> </u>			<u> </u>	Н				_	<u> </u>
		_		-	_	_	L	_	-	L	L	_		_	_	<u> </u>	-	_				-			_	_	-	L			L	_			_	Н				_	L
3	A	11	1	├-	-		DK	M	A	1	3	\vdash	_		_	_	-				\vdash	Н			-	-	-	L		-	H		H		<u> </u>	Н	\dashv	\dashv	-		-
4		-	├	-	<u> </u>	-	-	-	-	\vdash	\vdash			_	_	\vdash	-			_	\vdash	Н	-		Н	-		-		-	Н				_	\vdash	-	\dashv	_		-
+		-	-	-	_	-	\vdash	-	├-	╀╌	├	-		-	-	\vdash	-	-		_	Н		-			-	-	-		\vdash					_	Н	\dashv	\dashv		H	-
\dashv	_	-	┝	-	\vdash	-		-	┝	╁	╁	├		_	-	-	-	Н				\vdash			_	┝	-								-		\dashv	\dashv		\vdash	\vdash
┪		 	-	-	_		<u> </u>	-	\vdash	╁╌	-	-		-		H			Н									-	Н							H	\dashv	ᅱ	\dashv		
┪		-	-		_		┝	-	\vdash	-	╁	\vdash		\vdash	\vdash				Н			Н	-					\vdash	Н	Н			\vdash			Н	┪	\dashv		Н	-
3,		01	-	3,	A &	6	7	-		4	A	PE	5	IM	,		,		\vdash	_		\vdash	\dashv	_				\vdash	Н	Н							\dashv	-			┢
1		-					 	-	-	†		<u> </u>	H					Н					1						Н							H	1	7			-
7	' A	57	 	CA	RI	5	M	AY	17	VA	VE		o	R	2	F	7	FΛ	1E	N'	7.9	•)	\dashv	A	0	7 A	1A	7	4								1	\dashv	\neg		_
_	8							/X	•	_	_	_	_									E							H							1	7	\dashv	7		-
1 1 2 3 3 3 3 3 3 3 3 3 3	7		\vdash						1	RI	3)	M	23 D(3	H				\exists				: 1	(3	7			П		H					٦		\dashv	7	\dashv	7		
E	π	-			-				•	b n	.		OL		П		·		7			EA					П		П					7			1	7	\neg		
Ť				Π									П	П	П							\neg	7	٦			П									\dashv	7	1			
Ø				П					Γ				П									一	\exists	コ									一				7	寸			
9		41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	62	69	70	71	72	73	74	75	76	77	78	79	80


December, 1965


82


CORPORATION - ENGINEERING DEPARTMENT


FLOW CHART FOR INELASTIC PLATE ANALYSIS



































FORTRAN II LISTING
FOR INELASTIC PLATE
ANALYSIS

```
6001
      XEO
       CHAIN(1,3)
                                                                                 0002
                                                                                 0003
       LISTB
 451281 GRUMMAN AIRCRAFT ENGINEERING LURP.
                                                 DECK NO. 45128
                                                                   LINK 1
       MATRIX ANALYSIS FOR ISOTRUPIC UK ANISOTROPIC INCLASTIC STRUCTURES
                                                                                 0005
       IN THE PLASTIC AND CREEP REGIME
C
                                                                                 COOS
C
                                                                                 6007
C
                                                                                 0008
      THIS PROGRAM WRITTEN FOR AIR FURLE CONTRACT AF 33(615)-2260
                                                                                 0009
                                                                                 0010
C
                             TABLE UF SYMBULS USED
                                                                                 0011
                                                                                 0012
            * * ARRAYS * *
                                                                                 0013
      AL1212 - MATRIX OF ANISUTRUPIC PARAMETERS FOR EACH NUDE
                                                                                 0014
      AL1223 - MATRIX OF ANISOTRUPIC PARAMETERS FOR EACH NUDE
                                                                                 0015
      AL1231 - MATRIX OF ANISOTRUPIC PARAMETERS FOR EACH NUDE
                                                                                 0016
       ALFA44 - MATRIX OF ANISUTRUPIC PARAMETERS FOR EACH NUDE
C
                                                                                0017
      DELEPK - MATRIX OF NUDE STRAIN CHANGES (DELTA EPSILON)
C
                                                                                 0018
                FOR THE X AND Y DIRECTIONS, AND THE SHEAR STRAIN CHANGE
C
                                                                                 0019
      DELEPN - MATRIX OF EFFECTIVE INCLASTIC STRAIN CHANGES
                                                                                 0020
C
      EPBARN - MATRIX OF EFFECTIVE INCLASHIC STRAINS (EPSILON BAR SUB N)
                                                                                 0021
C
                FOR K-TH CYCLE
                                                                                 0922
                MATRIX OF EFFECTIVE INCLASTIC STRAINS (EPSILON BAR SUB N)
C
                                                                                 0023
                FOR K-1 CYCLE (THE PRECEDING CYCLE)
C
                                                                                 0024
      EPCNK
               MATRIX OF EFFECTIVE CHEEP STRAINS FOR THIS CYCLE
                                                                                 0925
                                                                                 0026
      EPCNP
              - MATRIX OF EFFECTIVE CREEP STRAINS FOR PREVIOUS CYCLE
      EPSUK
              - MATRIX OF NODE PLASSIL STRAINS (EPSILON SUB U) FOR THE
                                                                                 0027
                X, Y AND SHEAR STRAINS, FUR THE K-TH CYCLE
                                                                                 0028
              - TABLE OF CONTROL CLUES ILUAD STEP, TIME STEP, WRITE SAVE
      KPMTM
                                                                                 0029
                        READ-IN CUNTRUL INFORMATION USED HITH PMTM
                                                                                 0030
C
      PMTM
              - TABLE OF LOAD INCREMENTS, PRINT CONTROL INCREMENTS AND
                                                                                 0031
                UPPER LOAD LEVEL PER STEP (CONTROL INFORMATION)
                                                                                 0032
C
      SGBARM - MATRIX OF EFFECTIVE NUDE STRESSES FOR LAST CYCLE THAT
                                                                                 0033
                SHOWED AN INCREASE AT A PARTICULAR NODE
                                                                                 0034
      SGBARN - MATRIX OF EFFECTIVE NUDE STRESSES FOR CURRENT CYCLE SGBARP - MATRIX OF EFFECTIVE NUDE STRESSES FOR PREVIOUS CYCLE
                                                                                0035
                                                                                0036
      SIGUK - MATRIX OF NODE STRESSES (SIGMA SUB U) FOR K-TH CYCLE
                                                                                0037
              - MATRIX OF STRESSES FOR MEMBER STRAINS
      LIZ
                                                                                0038
C
              - MATRIX OF STRESSES FUR APPLIED LOADS
                                                                                0039
      MIZ
C
      TALF12 - MATRIX OF ANISOTRUPIC PARAMETERS (INPUT DATA)
                                                                                0040
C
      TALF23 - MATRIX OF ANISOTROPIC PARAMETERS (INPUT DATA)
                                                                                0041
C
      TALF31 - MATRIX OF ANISOTROPIC PARAMETERS (INPUT DATA)
                                                                                0042
C
      TALF44 - MATRIX OF ANISOTRUPIC PARAMETERS (INPUT DATA)
                                                                                0043
      TEFSTN - MATRIX OF TOTAL EFFECTIVE STRAINS
C
                                                                                U044
      TEPSN - TABLE OF STRAIN VALUES DEFINING THE STRESS-STRAIN CURVE
      TIMEL - MATRIX OF REFERENCE CHEEP TIMES FOR ALL NODES
C
                                                                                0046
C
      TOTEPS - MATRIX OF TOTAL NUDE STRAINS
                                                                                0047
              - TABLE OF STRESS LEVELS DEFINING THE STRESS-STRAIT CURVE
C
      TSIGN
                                                                                0048
C
                                                                                0049
           * * VARIABLES AND CLUES * *
C
                                                                                0050
      ALPHA - PARAMETER USED IN THE CREEP EQUATIONS
C
                                                                                0051
             - PARAMETER USED IN THE CREEP EQUATIONS
C
      BETA
                                                                                0052
             - MODULUS OF ELASTICITY
- PARAMETER USED IN THE CREEP EQUATIONS
C
                                                                                0053
C
      GAMMA
                                                                                0054
C
      GNU
              - POISSONS RATIO
                                                                                CO55
             - THE CYCLE COUNTER
C
                                                                                0056
      KERRSW - CLUE USED FOR TEMPURARY INDICATOR BETWEEN LINKS
C
                                                                                0057
            - CLUE INDICATING TOTAL COUNT OF MATRICES ON AUXILIARY TAPE
                                                                                0058
           - CLUE INDICATING MATRICES STILL NOT READ FRUM AUXIL. TAPE
                                                                                0059
```

The second of th

```
KLU6
             - CLUE FOR PRINT LUNIAUL (WHICH CYCLES)
                                                                              0060
      KLU8
             - CLUE FOR PRINT CUNTRUL (WHICH MATRICES)
                                                                              0061
      KLUISO - CLUE FOR ISOTRUPIC OR ANISOTROPIC RUN (INPUT)
                                                                              6062
      KSET
             - CLUE FOR THE LUAD OR TIME LEVEL CURRENTLY IN USE
                                                                              0063
             - 3 TIMES THE NODE COUNT (INPUT)
      NΔ
                                                                              0764
      NC
             - NUMBER OF NODES
                                                                              0065
      NINCLD - NUMBER OF NON-INCREMENT CYCLES AT EACH LOAD LEVEL (INPUT)
                                                                              00 5
            - CURRENT LOAD LEVEL
                                                                              0057
      SHRMOD - SHEAR MUDULUS
                                                                              8400
      TIME
             - CURRENT TIME LEVEL
                                                                              0:069
                                                                              0070
      OUTPUT - SUBROUTINE TO CONTROL PRINTING AT VARYING LOAD LEVELS
                                                                              0071
                                                                              0072
C
                                                                              0073
      ELASTIC UNLUADING (FULLOWS HOUKES LAW WHEN UNLUADING)
                                                                              0074
      COMMON TEFSTN, TOTEPS
                                                                              0075
                                                          NC,
      COMMON KLU4,
                               KLÜO,
                                        KLU8;
                      KLU5,
                                                  NA.
                                                                              0076
                                                  . E,
      COMMON KERRSW, NINCLD.
                               KSET.
                                        PM,
                                                         GNU, SHRMUD
                                                                              0077
                                        TIME, KLUISO
                              GAMMA .
                      BETA,
      COMMON ALPHA,
                                                                              0078
              PHTM.
                      KPMTM.
                                sim.
                                         SIJ, TSIGN, TEPSN
                                                                              0079
      COMMON TALF12, TALF23, TALF31, TALF44
                                                                              0080
      COMMON AL1212, AL1223, AL1231, ALFA44
      DIMENSION TALF12(11), TALF25(11), TALF31(11), TALF44(11)
                                                                              0082
      DIMENSION AL1212(55), AL1223(55), AL1231(55), ALFA44(55)
                                                                              0083
      EQUIVALENCE (TIMKI, TEFSIN) , (TUTEPS , DELEPK)
                                                                              0084
      THESE FOUR ARRAYS ARE EQUIVALENCED TO SAVE CORE SPACE.
C
                                                                              0085
      DIMENSION TIMK1(55), TEFSIN(55), TUTEPS(165), DELEPK(165)
                                                                              0086
      DIMENSION PMTM(10.3), KPMTM(10), SIM(165), SIJ(165, 165), TSIGN(11)
                                                                              0087
      DIMENSION TEPSN(11)
                                                                              8800
      DIMENSION BL(5), ID(9), NR(3), NU(3), EL(3)
                                                                              0089
      DIMENSION PSTEP(3)
                                                                              0090
      EQUIVALENCE (ID(1), AD1), (ID(2), AD2), (ID(3), AD3), (ID(4), AD4), (ID(5)
                                                                              0091
     1,AU5),(IU(6),AD6),(ID(7),AU7),(IU(8),AD8),(ID(9),AD9)
                                                                              0092
      AD1 = 606060623144
                                                                              0093
             606060623141
      AD2 =
                                                                              0094
      AD3 =
             606362312745
                                                                              0095
      AD4 = 606325476245
                                                                              0096
      AD5 = 632143260102
      AD6 = 632143260203
AD7 = 632143260301
                                                                              0098
                                                                              0099
      AD8 = 632143260404
                                                                              0100
      AD9 = 606060606060
                                                                              0101
      BL(1) = 434621246060
BL(2) = 633144256060
                                                                              0102
                                                                              0103
      BL(3) = 632147256060
                                                                              0104
      BL(4) = 263145626060
                                                                              0105
      BL(5) = 606060606060
                                                                              0106
      KERRSW = 1
                                                                              0107
      INTAPE = 7
                                                                              8010
      KLU5 = 0
                                                                              0109
      KLU6 = 0
                                                                              0110
      KLU8 = 10000
KLUALF = 0
                                                                              0111
                                                                              0112
      PSTEP(1) = 0.0
                                                                              0113
      PSTEP(2) = 0.0
                                                                              0114
      PSTEP(3) = 0.0
                                                                              0115
```

E 1	DO 51 J22=1,10 KPMTM(J22) = 0
7 L	LROW = 0
	READ INPUT TAPE 7,1,KLU4,NINCLU,NA,KLU7,KLUISO,ALPHA,BETA,GAMMA,
	1GNU, TA, TB, TC, TO, TE
	WRITE OUTPUT TAPE 6,21,TA,TB,TL,TU,TE
	KLU7 (INPUT) = 0 TO PRINT PRE-SELECTED MATRICES UN SELECTED CYCLES
	KLUT (INPUT) = 1 TO PRINT ALL MATRICES ON SELECTED CYCLES
	KLU7 (INPUT) = 2 TO PRINT PRE-SELECTED MATRICES UN ALL CYCLES
	KLU7 (INPUT) = 3-9 TO PRINT ALL MATRICES ON ALL CYCLES
	IF(KLU7)384,384,381
-	IF(KLU7-1)383,383,382
82	KLU6 = 1
	KLU6 (OUTPUT) = 1 TO PRINT EACH CYCLE, O TO PRINT SELECTED CYCLES
	IF(KLU7-2)384,384,383
83	KLU8 = 0
_	KLUB (QUTPUT) = O TO PRINI ALL MATRICES
	KLUB (OUTPUT) = 10000 TO PRINT SELECTED MATRICES
84	CONTINUE
	IF(KLU4)302,302,301
ים	PRINT 17
J I	PAUSE 11111
	TEST INPUT TAPE TO DISTINGUISH GISMU BCD FROM INELASTIC PROG. SAVE
	READ INPUT TAPE 9.31, LTAPE
	RENIND 9
	SUBROUTINE FILTAP POSITIONS A TAPE AT THE FIRST RECORD OF ANY FILE
	CALL FILTAP(9.2)
	IF(LTAPE-21)343,344
77	CONTINUE SAVED TAPE FROM PREVIOUS RUN UF INELASTIC PLATE
	THIS RUN IS A CONTINUATION
	The state of the s
4.7	CALL CHAIN (2,3)
775	CONTINUE
	GISMO FORMAT BCD TAPE
	THIS RUN IS A NEW ONE
	KLU5 = KLU4
	INTAPE = 9
102	CONTINUE
	KLUISO = 0 FOR ISOTROPIL RUN
	KLUISO = 1 FOR ANISOTRUPIC RUN
	WRITE DUTPUT TAPE 6,9
	IF(KLUISO)380,380,379
79	CONTINUE
	WRITE OUTPUT TAPE 6,10
	CONTINUE
52	READ INPUT TAPE 7,2,1EMP1,1EMP2,1EMP3,TEMP4
	LROW = LROW + 1
	DO 53 J22=1.5
	IF(TEMP1*(-BL(J22)))53,54,53
53	CONTINUE
<u>د</u> د	DAD CONTROL CARD
	WRITE OUTPUT TAPE 6,12,LRUW
	WRITE OUTPUT TAPE 6,2, TEMP1, TEMP2, TEMP3, TEMP4
	CALL EXIT
. .	CALL EXIT GO TO(55,55,55,60,60),J22

	0172
KPMTH(N) = 1 FOR A LOAD STEP	0173
	0174
HOUSEL M 1 = 3 TO DUMP MERUKI ANIO M SATE	01/5
	C176
	0177
PMTM (N.2) = INTERVAL (INCREMENT) FUR PRINT UUTPUT PMTM (N.3) = INTERVAL (INCREMENT) FUR PRINT UUTPUT	0178
56 KPMTH(LROH) = J22	0179
nutmij DCu. Fla TFMP2	U180
TEMPZ-PSIEPIJZZI	0181
PMTH(LROW, 2) = SIGNF(TEMP3, TEMP3)	0182
octsp(122) = TEMP2	0183
IF(PMTM(LROW, 2)157, 63, 57	0184
63 GO TO(995,995,57), J22	0185
57 CONTINUE	0186
PMTM(LROW, 3) = TEMP4	0187
GU TO 52	0188
60 CONTINUE	0189
$a_{1} = a_{1} = a_{2} = a_{3} = a_{3$	0190
1F(KPMTM(J23) 1361,361,362 362 IF(KPMTM(J23) -4)363,361,361	0191
15 (KOMTM(1/23)-4)363,361,361	0192
3.4 136 m FONTM1 1241 :	0193
	0194
The maite dillant lake ofsethings are the contractions and the contractions are the contractions and the contractions are the contractions and the contractions are the contracti	0195
IF(PMTM(J23,3))361,361,305	0196
IF(PMTM(J23,31)361,361,305 365 WRITE OUTPUT TAPE 6,23,PMIM(J23,4)	0197
GO TO 361	0198
244 MPITE MUTPUT TAPE 6,24,PMIMIJ23,21,FMIMIJ23,21	0199
	0200
307 WRITE OUTPUT TAPE 6,26,PMIHLJ23,31	1080
GQ TQ 361	9202
368 WRITE OUTPUT TAPE 6,27	0203
361 CONTINUE WRITE DUIPUT TAPE 6,28, NINCLD WRITE DUTPUT TAPE 6,25, ALPHA, BÉTA, GAMMA 1F(GNU)86,87,87	0204
WRITE OUTPUT TAPE 6,28, NINCLU	0205
WRITE DUTPUT TAPE 6,25, ALPHA, BETA, DANGA	0206
1F(GNU)86,87,87	0207
86 GNU = -3	0208
A7 CINI INUE	0209
IF(NA)999,91,92	0210
91 NA = 165	021
92 IF(NA-165)93,93,999	0213
93 CONTINUE	021
96 IF(NA-3*(NA/3))999,97,999	021
97 NC * NA/3	021
IF(KLU4)304,304,303	021
303 1F(KLU4-41306,306,994	021 021
306 CONTINUE	
INTAPE = 9	021 022
KLUS = KLUS - 1 108 READ INPUT TAPE INTAPE, 3, NAME, NRUWS, NCOLS, NFORM	022
108 READ INVOLUENCE AND A STATE OF THE PROPERTY OF THE PROPERT	022
00 110 [21=1,, [F(NAME-ID(121))]]]0,3]],4]0	022
	922
110 CUNTINUE C BAD INPUT - MATRIX NAME NUT ACCEPTABLE	022
C BAD INPUT - MAINTA MAINTA MAINTA	
GO TO 997 311 GO TO (321, 322, 323, 324, 325, 320, 327, 328, 111), 121	022
311 GO 10 (321) 324 324 324 324 324 324 324 324 324 324	
3/1 UU 331 11 -1110°	

331	SIM(II) = 0.0
	WRITE DUTPUT TAPE 6,20, NAME, NKOWS, NCOLS, INTAPE
	GU TO 111
22	00 332 11 =1,165
	DO 332 12 =1,165
32	SIJ(I1.12) = 0.0
	GO TO 111
23	00 333 11 = 1,11
33	TSIGN(11) = 0.0
	GO TO 111
24	DO 334 11 = 1,11
	TEPSN(II) = 0.0
	GO TO 111
25	00 335 11 = 1,11
35	TALF12(II)= 0.0
	KLUALF = KLUALF + 1
	GO TO 111
26	DO 336 II = 1,11
36	TALF23(11)= 0.0
	KLUALF = KLUALF + 2
	GO TO 111
27	DO 337 11 = 1,11
37	TALF31(11) = 0.0
	KLUALF = KLUALF + 4
	GO TO 111
	00 338 11 = 1,11
8	TALF44(II)= 0.0
	KLUALF = KLUALF +8
_	GO TO 111
ll	GO TO (112,112,112,112,112,112,112,112,150),121
12	READ INPUT TAPE INTAPE, 4, (NR(122), ND(122), EL(122), 122=1,3)
	1b(uk(11)330*103*113
	IF(KLU5)308,308,306
08	INTAPE = 7
	GO TO 108
	GO TO 308
13	GO TO (121,122,125,126,201,202,203,204,150),121
	READ IN ARRAY SIGMA-IM
Z į	MROW = NR(1) WRITE OUTPUT TAPE 6,4,(NR(122),ND(122),EL(122),122*1,3)
	SIN (MROW) = EL(1)
	IF(EL(2))127,128,127
7	
27	MROW = NR(2)
	SIM (MROW) = EL(2)
8	SIM (MROW) = EL(2) IF(EL(3))129,112,129
8	SIM (MROW) = EL(2) IF(EL(3))129,112,129 MROW = NR(3)
8	SIN (MROW) = EL(2) IF(EL(3))129,112,129 MROW = NR(3) SIN (MROW) = EL(3)
8	SIN (MROW) = EL(2) IF(EL(3))129,112,129 MROW = NR(3) SIN (MROW) = EL(3) GO TO 112
8	SIN (MROW) = EL(2) IF(EL(3))129,112,129 MROW = NR(3) SIN (MROW) = EL(3) GD TO 112 READ IN ARRAY SIGMA-IJ
28	SIN (MROW) = EL(2) IF(EL(3))129,112,129 MROW = NR(3) SIN (MROW) = EL(3) GD TO 112 READ IN ARRAY SIGMA-IJ MROW = NR(1)
28	SIN (MROW) = EL(2) IF(EL(3))129,112,129 MROW = NR(3) SIN (MROW) = EL(3) GD TO 112 READ IN ARRAY SIGMA-IJ MROW = NR(1)
8	SIN (MROW) = EL(2) IF(EL(3))129,112,129 MROW = NR(3) SIN (MROW) = EL(3) GD TO 112 READ IN ARRAY SIGMA-IJ MROW = NR(1)
2	SIN (MROW) = EL(2) IF(EL(3))129,112,129 MROW = NR(3) SIN (MROW) = EL(3) GO TO 112 READ IN ARRAY SIGMA-IJ MROW = NR(1) MCOL = ND(1) SIJ (MROW, MCOL) = EL(1) IF(EL(2))130,131,130
2829	SIM (MROW) = EL(2) IF(EL(3))129,112,129 MROW = NR(3) SIM (MROW) = EL(3) GU TO 112 READ IN ARRAY SIGMA-IJ MROW = NR(1) MROW = NR(1) SIJ (MROW, MCOL) = EL(1) IF(EL(2))130,131,130 MROW = NR(2)
	SIN (MROW) = EL(2) IF(EL(3))129,112,129 MROW = NR(3) SIN (MROW) = EL(3) GO TO 112 READ IN ARRAY SIGMA-IJ MROW = NR(1) MCOL = ND(1) SIJ (MROW, MCOL) = EL(1) IF(EL(2))130,131,130

	•	
131	IF(EL(3))132,112,132 MROW = NR(3) MCOL = ND(3)	
132	MROW = NR(3)	
	MCOL = NO(3)	
	SIJ = (MROW,MCOL) = EL(3)	
	60 TO 112	
	READ IN ARRAY TSIGN (TABLE UP	SIGMA BAR NI
25	MROW = NR(I)	
	TSIGN(MROW) = EL(1)	
	IF(EL(2))139,140,139	
139	GO TO 112 READ IN ARRAY TSIGN (TABLE UP MROW = NR(I) TSIGN(MROW) = EL(1) IF(EL(2))139,140,139 MROW = NR(2) TSIGN(MROW) = EL(2) IF(EL(3))141,112,141 MROW = NR(3) TSIGN(MROW) = EL(3)	
	TSIGN(MROH) = EL(2)	
	IF(EL(3))141,112,141	
141	MROW = NR(3)	
	TSIGN(MROW) = EL(3)	
	60 TO 112	·
	READ IN ARRAY TEPSN (TABLE UP	EPSILUN BAR N)
126	MROW = NR(1)	•
	TEPSN(MROW) = EL(1)	
•	TEPSN(MROW) = EL(1) IF(EL(2))142,143,142	e e e e e e e e e e e e e e e e e e e
142	MKUW = NK(2)	
•	TEPSN(MROW) = EL(2)	
	IF(EL(3))144,112,144	
144	MROW = NR(3)	
	TEPSN(MROW) = EL(3)	
	GO TO 112	e la compania de la c
	READ IN ALPHA TABLES	•
201	MROW = NR(1)	
	TALF12(MRUW) = EL(1)	
	IF(EL(2))221,222,221	
221	MROW = NR(2)	
	TALF12(MROW) = EL(2)	A CONTRACTOR OF THE PARTY OF TH
	IF(EL(3))223,112,223	
223	MROW = NR(3)	
	TALF12(MROW) = EL(3)	
303	GO TO 112	
202	MROW = NR(1)	
	TALF23(MRUH) = EL(1) IF(EL(2))224,225,224	Seattle series and restriction of the series
224	MROW = NR(2)	
664	TALESS/MODUL = 51/21	
225	TF(EL(2))224,225,224 MROM = NR(2) TALF23(MROW) = EL(2) IF(EL(3))226,112,226	•
	MROW = NR(3)	
-20	TALF23(MROW) = EL(3)	
	GO TO 112	tion of the second section section section sections and the second section sec
203	MROW = NR(1)	
	TALF31(MROW) = EL(1)	
	IF(EL(2))227,228,227	•
227	MRCW = NR(2)	
_ •	TALF31(MROW) = EL(2)	
28	IF(EL(3))229,112,229	nganan and the same of the sam
	MROW = NR(3)	,
,	TALF31(MROW) = EL(3)	
204	MROW = NR(1)	
	TALEAA(MROW) = FL(1)	addisia istina da que mai minestir estato acesto acesto estato en incidente de incidente de la composición del composición de la composición de la composición de la composición del composición de la composición
	The state of the s	

230	MROW = NR(2)
	TALF44(MROW) = EL(2)
231	IF(EL(3))232,112,232
232	MROW = NR(3)
	TALF44(MROW) = EL(3)
	GO TO 112
160	the second secon
150	CONTINUE
	IF(KLUISO)165,161
	IF(KLUALF-15)162-167-162
162	WRITE OUTPUT TAPE 6,32,KLUALF
	1F(KLU4)164,164,163
	SUBROUTINE RUN REWINDS AND UNLUADS THE DESIGNATED TAPE
163	CALL RUN(9)
164	CALL EXIT
	DO 166 I = 1.11
100	
	TALF12(1)= 0.5
	TALF23(I)= 0.5
	TALF31(I)= 0.5
166	TALF44(I)= 1.0
167	CONTINUE
	E = TSIGN(2)/TEPSN(2)
۵1	SHRMOD = E/(2.*(1.+GNU))
01	
	WRITE DUTPUT TAPE 6.5.E. SHKMUD. GNU
	WRITE DUTPUT TAPE 6.6
	DO 149 [1=1,1]
149	WRITE OUTPUT TAPE 6,7,11, [SIGN(11), TEPSN(11), TALF12(11), TALF23(11)
	1,TALF31(I1),TALF44(I1)
	K = 0
	PM = 0.0
	IF(KLU4)152,152,209
	SUBROUTINE RUN REWINDS AND UNLUADS THE DESIGNATED TAPE
200	CALL RUN(9)
	PRINT 19
	CALL CHAIN(4,3)
994	WRITE OUTPUT TAPE 6,18,KLU4
	CALL EXIT
995	WRITE OUTPUT TAPE 6.16.LKUN
	CALL EXIT
996	CONTINUE
	WRITE OUTPUT TAPE 6,14, NAME
	WRITE OUTPUT TAPE 6,4, (NR(122), NO(122), EL(122), 122=1,3)
	CALL EXIT
447	CONTINUE
	WRI E OUTPUT TAPE 6, 13, NAME
	CALL EXIT
999	WRITE DUTPUT TAPE 6,11,NA
-	CALL EXIT
1	FURMAT(11,213,211,1x,2£10.3,2£5.2,10x,5A6)
	### ### ### A ## ## A ### A ### A ## A ## A
	FORMAT(6X, A4, E10.6, E10.1, E10.1)
	PUKMAI(IIX+A0+IX+213+8X+II)
•	FORMAT(3(1x,213,E16.8))
5	FORMAT(26H1 MODULUS OF ELASTICITY = +F11.0+4H PSI+6X+16HSHEAR MODU
	LUS = ,F11.0,4H PSI,6x,5HNU = ,F0.3)
4	FORMATI41HO TABLE OF VALUES FUR STRESS-STRAIN CURVE //
•	
	15X,29HPOINT STRESS LEVEL STRAIN,7X,8HALPHA 12,7X,8HALPHA 23,7X

7 FURMAT(0x,13,2x,f11.2,513x,f12.d)	U396
9 FURMAT(//79H THIS ISUTHUPIL NUM USES ELASTIC UNLUAUING (HOUKES L	0397
IAW) WITH STRAIN MARDENING)	0398
10 FORMAT(1H+,5X,2HAN)	0399
11 FURMAT(1)H ERROR NA=14)	0400
12 FURMATIZEH ERROR- INCREMENT CAKU NU., 13,5H N.G.)	0401
13 FORMAT(14H ERROR-MATRIX ,Ao)	0402
14 FORMATULTH ERROR-NEG.INDEX ADJ	0403
16 FORMATISSH ERROR-NU INTERVAL-INCREMENT CARD, 13)	0404
17 FORMATISTHO PAUSE 11111 TO MOUNT INPUT DATA TAPE ON DRIVE A-5///)	0405
18 FORMATITH ERRUR-15, 18H INPUT MATRICES NGT	0400
19 FORMATIBYH DEMUUNT AND SAVE TAPE A-D. DATA HAS BEEN READ INTO MEMO	0407
IRY. THE PROGRAM CONTINUES TO HUN. //)	0408
20 FORMATI//5X. THMATRIX . AO. IX. 13. OH KUNS X . 13. 19H CULUMNS FRUM TAPE	0409
1,12)	0410
21 FORMAT(1H1,29x,5A6)	0411
22 FORMATESX, 16HLDAD INCREMENTS , 19.2, 11H POUNDS TO , F10.2, 7H PJUNDS)	0412
23 FURMATILH+,61x,19HPRINT UUIPUT EVERY ,F9.2,7H POUNDS)	0413
. 24 FORMATISX, 16HTIME INCREMENTS , FY. 4, 11H HOURS TO , F10.4, 6H HOURS)	0414
25 FORMAT(/ 9H ALPHA = ,ELO.3,5x,7HDETA = ,ELO.3,5x,8HUAMM4 = ,ELO.3)	0415
'26 FURMAT(1H+,61x,19HPRINT UUTPUT EYERY ,F9.4,0H HUUKS)	0416
27 FURMAT(5X,35HSTORE MEMORY UN TAPE A-6, THEN EXIT)	0417
28 FURMAT(//5x,13,48H NUN-INCREMENT CYCLES AT EACH LOAD OR TIME LEVEL	0418
1)	0419
31 FURMAT(10X,12)	0420
32 FORMATISX, 12,65H ALPHA TABLES WERE READ IN UF 4 REQUIRED. CHECK YU	0421
IUR INPUT CARDS.)	0422
END(1,1,0,0,0,0,1,1,0,1,0,0,0,0)	
CHAIN(2,3)	0424
LIST8	0424
	U423

451282 GRUMMAN AIRCRAFT ENGINEERING CUMP. DECK NU. 45128 LINK 2 C451282 MATRIX ANALYSIS UF INCLASTIC PLATE - LINK 2 - WITH CREEP C THIS LINK READS IN A SAVED BINARY TAPE - FIRST PART 0427 0428 COMMON TEFSIN, TOTEPS 0429 KLU8, NA, PM, E, TIME, KLUISO NC, K GNU, SHRMOD COMMON KLU4, KLU5, KLJ6, 0430 COMMON KERRSW, NINCLD, KSEI, 0431 COMMON ALPHA, BETA, GAMMA, 0432 COMMON PMTM, KPMTM, SIM, SIJ, COMMON TALF12, TALF23, TALF31, TALF44, COMMON ALIZ12, ALIZ23, ALIZ31, ALFA44 SIJ. TSIGN, TEPSN 0433 0434 0435 DIMENSION TALF12(11), TALF23(11), TALF31(11), TALF44(11) 0436 DIMENSION AL1212(55), AL1223(55), AL1231(55), ALFA44(55) COMMON SIGUK, EPSUK 0438 EQUIVALENCE (TIMKI, TEFSTN), (TUTEPS, DELEPK) THESE FOUR ARRAYS ARE EQUIVALENCED TO SAVE CORE SPACE. DIMENSION TIMK1(55), TEFSTN(55), TUTEPS(165), DELEPK(165) 0439 0440 DIMENSIUN PHTM(10,3), KPMTM(10), SIM(165), SIJ(165,165), TSIGN(11) 0442 DIMENSION TEPSN(11), SIGUK(105), EPSUK(165) 0443 DIMENSION BL(5) 0444 DIMENSION PSTEP131 0445 READ TAPE 9, KLU4, KLU5, LA, LB, NA, NC, K, KERRSW, LC, KSET, PM, E, 1GNU, SHRMOU, ALPHA, BETA, GAMMA, TIME, KLUISO 0447 KLU6 = 1 WILL PRINT EVERY LYCLE, U WILL PRINT UNLY SELECTED CYCLES 0448 C KLUB = 0 WILL PRINT ALL MATRICES, NUN-ZERO PRINTS SELECTED MATRICES 0449 NINCLD (NON-INCREMENT CYCLES AT EACH LOAD LEVEL) ACCEPTED FROM 0450 INPUT CUNIROL CARD WRITE OUTPUT TAPE 6,9 0451 0452 IF(KLUISD)380,380,379 0453 379 CONTINUE WRITE OUTPUT TAPE 6,10 0455 380 CONTINUE 0456 NCLU = 1 0457 KERRSW = 2 BL(1) = 434621246060 0459 BL(2) = 633144256060 0460 BL(3) = 632147256060 0461 BL(4) = 263145626060 0462 В BL(5) = 606060606060 0463 00 51 142 = 1,10 0404 51 KPMTM(142) = 0 PSTEP(1) = 0.0 0465 0466 PSTEP(2) = 0.0 PSTEP(3) = 0.0 0468 LROW = 0 52 READ INPUT TAPE 7,2, TEMP1, IEMP2, TEMP3, TEMP4 0470 EROW = LROW + 1 0471 DO 53 J22=1,5 0472 IF(TEMP1*(-BL(J22)))53,54,53 0473 53 CONTINUE 0474 BAD CONTROL CARD 0475 WRITE OUTPUT TAPE 6,12,LKUW 0476 WRITE OUTPUT TAPE 6,2, TEMP1, TEMP2, TEMP3, TEMP4 0477 CALL EXIT 0478 54 GO TO(55,55,55,60,601,J22 0479 55 IF(LROW-10)56,56,53 0480

0481

KPMTM(N) = 1 FOR A LUAD STEP

MONTH! ALL - 2 COD A TIM. LT II	
	0
DATA IN 11 - 3 TO DOMP MEMORY INTO A SAVE TAPE	0
DMTM (N.2) - CATEDVAL (INC. DEMONIT) BID CALCIDATION.	0
	0
	0
	0
	0
	Ç
	0
	0
• • • • • • • • • • • • • • • • • • • •	C
	0
IF(PMTM(LRUH,2))57,63,57	, 0
GD TO [995,995,57],J22	0
CONTINUE	0
PMTM(LROW, 3) = TEMP4	O
GO TO 52	0
CONTINUE	0
GO TO (61,62),NCLU	Ō
	0
READ TAPE 9.JUNK	Ü
READ TAPE 9.JUNK	
GO TO 64	0
CONTINUE	õ
READ TAPE 9.PMTM	Õ
	ŏ
	ŏ
WRITE DUTPUT TAPE 6.1	ő
DO 361 123 # 1.10	ŏ
IF(KPMTM(J23))361.361.362	ő
IFIKPMTM(J23)-4) 363-361-101	ő
	ŭ
	0
	č
	Ö
	. 0
	-
UDITE OUTOUT TABE 4.24 DATM/ 124.31 DATM/ 122.11	. 0
WRITE UUTPUT TAPE OJETJPHINIJEDJEJJPHINIJEDJEJ TELDWÝMI 191 211241 241 2-7	O
	0
	0
UDITE OUTDUT TAGE (39	0
WRITE UDIFUL TAPE 0,27	0
UNITING	0
MEAN TARE O CIM	0
	. 0
· · ·	0
READ TARE O TEREN	0
KEAN TAPE ATTENDA	0
	<u>0</u>
READ TAPE 9,TALF23	0
READ TAPE 9,TALF31	0
OLAN TABL M TAICAA	0
READ TAPE 9.TALF44	
READ TAPE 9.AL1212	0
	CONTINUE GO TO (61,62),NCLU CONTINUE READ TAPE 9,JUNK READ TAPE 9,JUNK GO TO 64 CONTINUE READ TAPE 9,PMTM READ TAPE 9,KPMTM CONTINUE WRITE OUTPUT TAPE 6,1 DO 361 J23 = 1,10 IF(KPMTM(J23))361,361,362 IF(KPMTM(J23))4)363,361,361 J24 = KPMTM(J23) GO TO (364,366,368),J24 WRITE OUTPUT TAPE 6,22,PMIM(J23,2),PMTM(J23,1) IF(PMTM(J23,3))361,361,360 WRITE OUTPUT TAPE 6,22,PMIM(J23,3) GO TO 361 WRITE OUTPUT TAPE 6,23,PMIM(J23,3) IF(PMTM(J23,3))361,361,367 WRITE OUTPUT TAPE 6,24,PMTM(J23,2),PMTM(J23,1) IF(PMTM(J23,3))361,361,367 WRITE OUTPUT TAPE 6,25,PMIM(J23,3) GO TO 361 WRITE OUTPUT TAPE 6,25,PMIM(J23,3) READ TAPE 9,SIM READ TAPE 9,SIM READ TAPE 9,TSIGN READ TAPE 9,TSIGN READ TAPE 9,TSIGN READ TAPE 9,TALF12 READ TAPE 9,TALF12

	READ TAPE 9.SIGUK	0538
	READ TAPE 9.EPSUK	0539
	CALL CHAIN (3.3)	0540
99	5 WRITE OUTPUT TAPE 6.16.LHUM	0541
	CALL EXIT	0542
		0543
	1 FORMAT(1HU, 29X, 3 THCONTINUALIUN KUN - INELASTIC ANALYSIS)	
	2 FORMAT(6X,A4,E10.6,E10.1,E10.1)	0544
,	9 FORMATI//79H THIS ISUTRUPIC NUN USES ELASTIC UNLOADING THUUKES L	0545
	1AW) WITH STRAIN HARDENING)	0546
10	O FURMAT(1H+,5X,2HAN)	0547
1.	2 FORMAT(26H ERROR- INCREMENT LARD NU., 13,5H N.G.)	0548
	6 FORMAT(33H ERROR-NU INTERVAL-INCHEMENT CARD. 13)	0549
_	2 FORMAT(5%, 16HLOAD INCREMENTS , F9.2, 11H POUNDS TO , F10.2, 7H POUNDS)	0550
	3 FORMAT(1H+,61X,19HPRINT UUTPUI EVERY ,F9.2,7H POUNDS)	0551
		0552
	4 FORMAT(5X.16HTIME INCREMENTS , Fy.4, 11H HOURS TO , F10.4, 6H HOURS)	
	5 FORMAT(1H+,61X,19HPRINT DUTPUT EVERY ,F9.4,6H HOURS)	0553
20	6 FORMAT(//5x,13,48H NON-INCREMENT CYCLES AT EACH LOAD OR TIME LEVEL	0554
•	1)	0555
2	7 FORMAT(5x, 35HSTORE MEMORY UN TAPE A-6, THEN EXIT)	0556
_	END(1,1,0,0,0,0,1,1,0,1,0,1,0,0,0)	
	CMAINER 23	0550
	CHAIN(3,3)	0558
,	LIST8	0559

```
451283 GRUMMAN AIRCRAFT ENGINEERING LUKP.
                                               DECK NJ. 45128
                                                                LINK 3
C451283 MATRIX ANALYSIS OF INCLASITE PLATE
                                               LINK 3 - WITH CREEP
                                                                              OSAL
      THIS IS THE SECOND HALF UF ULU LINK 2
                                                                              0562
      THIS LINK READS IN A SAVED DIMARY TAPE - SECOND PART
                                                                              6640
      CUMMUN TEFSTN, TOTEPS
                                                                              0564
                       KLU5,
               KLU4.
                                                                              0565
      CUMMON
                                KLUO.
                                        KLU8.
                                                  NA.
                                                          NC .
      COMMON KERRSW. NINCLD.
                               KSET,
                                          PM.
                                                   Ε,
                                                         GNU. SHRMGD
                                                                              0566
      COMMUN ALPHA,
                       BETA.
                              JAMMA.
                                        TIME . KLUISU
                                                                              0567
               PMTM,
                      KPMTM,
                                sim.
                                        SIJ. TSIGN, TEPSN
                                                                              0568
      COMMON
      CUMMON TALF12, TALF23, TALF31, TALF44
                                                                              0569
      COMMON AL1212, AL1223, AL1231, ALFA44
                                                                              0570
      OIMENSIUN TALF12(11), TALF23(11), TALF31(11), TALF44(11)
                                                                              0571
      DIMENSION AL1212(55), AL1223(35), AL1231(55), ALF444(55)
                                                                              0572
      COMMON SIGUK, EPSUK
                                                                              U573
      COMMON SGBARN, SGBARP, SUBARM, EPBARN, EPBARP, DELEPN
                                                                              0574
      COMMUN EPCNK, EPCNP
                                                                              0575
      EQUIVALENCE (TIMKI, TEFSTM), (TUTEPS, DELEPK)
                                                                              0576
      THESE FOUR ARRAYS ARE EQUIVALENCED TO SAVE CURE SPACE.
                                                                              0577
      DIMENSION TIMK1(55), TEFSIN(55), JUILEPS(165), DELEPK(165)
                                                                              0578
      DIMENSIUN PMTM(10,3), KPMIM(10), SIM(165), SIJ(165, 165), TSIGN(11)
                                                                              0574
                                                                              0380
      DIMENSION TEPSN(11),SIGUK(165),EPSUK(165),SGBARN(55),SGBARP(55)
      DIMENSION SGBARM(55).EPBARN(55).ePBARP(55).DELEPN(55).EPCNK(55)
                                                                              0581
      DIMENSIUN EPCNP(55)
                                                                              0582
      READ TAPE
                  9.SGBARN
                                                                              0583
           TAPE
      RFAD
                 9,SGBARP
                                                                              0584
      READ TAPE
                                                                              2585
                  9.SGBARM
                                                                              0586
      READ TAPE
                  9, EPBARN
                                                                              0587
      READ TAPE
                  9, EPBARP
      READ TAPE
                  9.DELEPN
                                                                              0588
      READ TAPE
                  9.EPCNK
                                                                              0589
      READ TAPE
                  9, EPCNP
                                                                              0540
      SUBROUTINE RUN REWINDS AND UNLUADS THE DESIGNATED TAPE
C.
                                                                              0591
      CALL RUN(9)
                                                                              0592
      PRINT 31
                                                                              0593
      WRITE OUTPUT TAPE 6,5,E,SHKMUD,GNU
                                                                              0544
      WRITE UUTPUT TAPE 6,6
                                                                              0595
      DO 149 11=1,11
                                                                              0596
  149 WRITE OUTPUT TAPE 6,7,11,151GN(11),TEPSN(11),TALF12(11),TALF25(11)
                                                                              0597
     1, TALF31(11), TALF44(11)
                                                                              0548
      CALL CHAIN (4,3)
                                                                              0599
    5 FORMAT(26HO MODULUS OF ELASTICATY = F11.0,4H PSI,6X,16HSHFAR MODU
                                                                              0600
     1LUS = .F11.0,4H PS1,6X,5HNJ = .F4.3)
                                                                              0601
    6 FORMATIALHO TABLE OF VALUES FUR STRESS-STRAIN CURVE //
                                                                              0602
     15x,29HPDINT STRESS LEVEL SIRAIN,7X,8HALPHA 12,7X,8HALPHA 23,7X
                                                                              0603
     1,8HALPHA 31,7X,8HALPHA 44/10X,3HP51,9X,7HIN./IN.//)
                                                                              0604
    7 FORMAT(6X,13,2X,F11.2,5(3X,F12.8))
                                                                              0605
   31 FORMAT(118HOIF NECESSARY IN STUP THIS RUN BECAUSE IT EXCLEDS THE F
                                                                              0606
     TIME ESTIMATE, PUT A RING IN THE SAVE TAPE ON A-5 AND CHANGE IT /
                                                                              0607
     256H TO DRIVE A-6 TO UPDATE IT, THEN PUT SENSE SWITCH 6 ON. //)
                                                                              0608
      END(1,1,0,0,0,0,1,1,0,1,0,0,0,0,0)
                                                                              0610
      SAVE TAPE 8-1 UNLESS ON-LINE PRINT SAYS IT HAS BEEN PROCESSED
                                                                              0511
                                                                              0612
      PUT SENSE SWITCH 6 ON TO END THE NUN IF IT EXCEEDS THE TIME ESTIM.
                                                                              0613
                                                                              0614
      IF PAUSE 1 DCCURS (SENSE SWITCH 6 OR INTERNAL CONTROL), MOUNT A
                                                                              0615
      BLANK TAPE ON A-6. THIS TAPE WILL HAVE RESTART DATA WRITTEN ON IT.
                                                                              0616
      AND MUST BE SAVED.
                                                                              0617
      CH4 IN (4,3)
                                                                              0618
      LIST8
                                                                              0619
```

```
KLUB = 0 WILL PRINT ALL MAINILES+ NUN-ZERU PRINTS SELECTED UNES
                                                                             0676
                                                                             0677
    IF(KLU6)248,248,249
                                                                             0678
244 KLU2 = 0
                                                                             0679
248 CUNTINUE
                                                                             0680
    IF(K-1)270,270,271
                                                                             0681
210 KLU2 = 0
                                                                              0682
271 CUNTINUE
                                                                              0683
    GO TO (416,417), KERRSW
                                                                              0684
417 KLU2 = 0
                                                                              0685
    KERRSW = 1
                                                                              0686
410 CUNTINUE
    KSET IS THE ROW OF KPMTM UK PMTM BEING USED (CURRENT LOAD OR
                                                                              0667
                                                                              0688
    TIME LEVEL)
                                                                              6890
300 IF(KSET-11)301,319,319
                                                                              0690
301 IF(KPMTM(KSET))302,302,303
                                                                              0691
302 KSET = KSET + 1
                                                                              0692
    GO TO 300
                                                                              0693
303 IF(KPMTM(KSET)-4)304,302,302
    VARIABLE (J24) INDICATES A LUAD CYLLE (1). A TIME CYCLE (2).
                                                                              3694
                                                                              0695
    OR WRITE MEMURY ON A SAVE TAPE 13)
                                                                              0696
304 J24 = KPMTM(KSET)
                                                                              0697
    KSET
              * KSET
                                                                              0698
              ≖ KERRS₩
    KERRSW
                                                                              0699
    IF(PHTM(KSET, 2)) 342,342,341
                                                                              0700
341 GU TO (305,315,423),J24
                                                                              0701
342 Gu TO (345,355,423),J24
                                                                              0702
305 IF(PHTM(KSET, 1)-(PM+PMTM(KSET, 2)) 1306, 307, 308
                                                                              0703
345 IF (PMTM(KSET, 1)-(PM+PMTM(KSET, 2))1308,307,306
                                                                              0704
307 IF(NINCLD)309,309,308
                                                                              0705
 309 KLU2 = 0
                                                                              0706
 308 DELPM = PMTM(KSET,2)
                                                                              0707
     GU TO 154
                                                                              0708
 306 1F(NINCPM-2)316,316,154
                                                                              0709
 316 KLU2 = 0
                                                                              0710
     GO TO 302
 315 IF(PMTM(KSET, 1)-(TIME+PMTM(KSET, 2)))306,317,318
                                                                              0711
                                                                              0712
 355 IF(PMTM(KSET+1)-(TIME+PMTM(KSET+2)))318+317,306
                                                                               0713
 317 IF(NINCLD)314,314,318
                                                                               0714
 314 KLU2 = 0
                                                                               0715
 318 DELTIM= PHTM(KSET,2)
                                                                               0716
     GO TO 330
                                                                               0717
 319 IF(KLU2)205,205,320
                                                                               0718
 320 KLU2 = 0
KSET = KSET - 1
                                                                               0719
     KSET
                                                                               0720
     [F(KSET)205,205,321
                                                                               0721
 321 IF(KPMTM(KSET))320,320,322
                                                                               0722
 J22 J24 = KPMTM(KSET)
                                                                               0723
     GO TO (308,318),J24
                                                                               0724
      ONTINUE.
 3
                                                                               0725
       .NT!NUE
                                                                               0726
      UNTINUE
 33:
                                                                               0727
     1F(NINCLD)501,501,510
                                                                               0728
 510 IF(K-1)501,501,511
                                                                               0729
 511 NINCPH = NINCPH - 1
                                                                               0730
      IF(NINCPH-3)513,515,515
                                                                               0731
 513 CONTINUE
```

	GO TO (501,512), NINCPM NINCSN = 1 MEANS THIS IS A RE-LYCLE STEP (NO LOAD OR TIME INCREASE)
	NINUSH = 2 MEANS THIS IS LAST RE-LYCLE AT THIS LOAD OR TIME LEVEL
	NINGSW = 3 MEANS THIS IS A LUAD UN TIME INCREMENT STEP
12	NINCSW = 2
12	GU 10 514
15	NINCSW = 1
• •	GO TO 514
οı	GO TO (502,503), J24
	PM = PM + DELPM
UZ,	GO TO 504
0 2	TIME = TIME + DELTIM
	NINCPH = NINCLD + 2
V T	NINCSW # 3
14	CONTINUE
7.75	
25	IF(NINCLD)524,524,525
۷٦	NINKCY = NINCLD + 3 - NINCPM
	GO TO (523,524,524),NINCSH
23	NINKLU = NINKCY - (NINKCY/10)*10
	IF(NINKLU)328,524,328
	NINKCY IS COUNT OF TOTAL CYCLES AT THIS LOAD OR TIME LEVEL
	NINKLU = 0 WILL PRINT EACH TENTH CYCLE, IF THIS LUAD OR
	TIME LEVEL IS TO BE PRINTED
4	GU TO (324, 325), J24
4	CALL OUTPUT (PM,PMTM(KSET,3) &KLUL)
	GU 10 326
	CALL OUTPUT(TIME, PMTM(KSET, 3), KLUL)
	IF(KLU2)327,328,327
	KLU2 = KLU1
į	CONTINUE
	IF(TIME)333,333,332
2	GO TO(333,337),J24
	COMPUTE REFERENCE CREEP TIME FUR ALL NODES
	DO 331 I3 = 1,NC
	EPCNP(13) = EPCNK(13)
	FACNUM = ABSF(EPCNP(13))
	EXPON = BETA*ABSF(SGBARN(13))
	FACDN1 = { 2.71828183**EXPUN}-1.
	TIMK1(I3) = (FACNUM/(ALPHA*FAGUNI))**(1./GAMMA)
	GO TO (336,336,334),NINCSH
6	CONTINUE
	EPCNK(I3) = (ALPHA*(TIMK1(13))**GAMMA)*FACDN1
	GO TO 331
4	CONTINUE
	EPCNK(13) = (ALPHA*(TIMKL(13)+DELTIM)**GAMMA)*FACDN1
l	CONTINUE
3	CONTINUE
,	FA = 214747433125
	KLU9 = 1
	IF(KLU2)250,250,251
9	CONTINUE
	LABEL = APPLIED LOAD
	FB = 246043462124
	FC = 6060606060
	KLUSIZ = 2

```
251 CUNTINUE
                                                                               078H
      KLU9
            = 2
                                                                               0789
      IF(KLU2+KLU8)252,252,253
                                                                               0790
  252 CUNTINUE
                                                                               0791
      LABEL = REF. CREEP TIME
                                                                               0792
      FA = 512526336023
                                                                               0743
В
      FB = 512525476003
                                                                               0794
      FC = 314425606060
ы
                                                                               0795
      WRITE TAPE 8.KLU9.
                             NC, FA, FB, FC, (TIMK1 (J1), J1=1.NC)
                                                                               0796
      FA = 252626336023
                                                                               0798
      FB = 512525476062
                                                                               0799
      FC = 635121314560
                                                                               0800
      WRITE TAPE 8, KLU9,
                             NC, FA, FB, FL, (EPCNK (J1), J1=1.NC)
                                                                               0801
  253 CONTINUE
                                                                               0402
      SAVE PRECEDING CYCLE VALUES OF EPBARN
                                                                               0803
      DO 152 II = 1.55
                                                                               ORO4
  152 EPWARP(II) = EPWARN(II)
                                                                               0805
      CALCULATE NUDE STRESSES - MAIRIX SIGUK - FRAME SIZE 165 X 1
                                                                               0806
      DO 861 I5 = 1.NA
                                                                               0807
      SIGUK(I5) = SIM(I5) *PM
                                                                               ROBO
      DU 861 16 = 1.NA
                                                                               0809
      SIGUK(15) = SIGUK(15) + SIJ(15.10)*EPSUK(16)
                                                                               0810
                                                                               0811
  861 CONTINUE
      IF(KLU21254,254,255
                                                                               0812
                                                                               0813
  254 CONTINUE
      LABEL = NODE STRESSES
                                                                               0814
      FA = 454624256062
8
                                                                               0815
R
      FB = 635125626225
                                                                               0816
      FC = 626060606060
                                                                               0817
                             NA.FA.FB.FC.(SIGUK (J1).J1=1.NA)
      WRITE TAPE 8.KLU9.
                                                                               C818
  255 CONTINUE
                                                                               0819
      CALCULATE MAGNITUDE AND SIGN OF EFFECTIVE STRESS AT EACH NODE
                                                                              0820
      CALCULATE EFFECTIVE STRESSES - MATRIX SGBARN - FRAME SIZE 55 X 1
                                                                               0821
      DO 166 I7 = 1.NC
                                                                               0822
      SGBARP(17) = SGBARN(17)
                                                                               0823
                                                                               0824
      H3
               = 3+17
      H32
               = M3-2
                                                                               0825
      M31
               = M3-1
                                                                               0826
      SGBARN(17)=SORTF(AL1231(1/)+S1GUK(M32)++2-AL1212(17)+S1GUK(M32)+
                                                                               0827
     1SIGUK(M31)+AL1223(I7)+SIGUK(M31)++2+3.*ALFA44(I7)+SIGUK(M3)++2)
                                                                               0828
  166 CONTINUE
                                                                               0829
      IF(KLU2)256,256,257
                                                                               0830
  256 CONTINUE
                                                                               0831
C
      LABEL = EFF. STRESSES
                                                                               0832
      FA = 252626336062
                                                                               0833
B
      FB = 635125626225
                                                                               0834
                                                                               0835
      FC = 626060606060
      WRITE TAPE 8, KLU9,
                             NC, FA, FB, FC, (SGBARN(J1), J1=1, NC)
                                                                               0836
  257 CONTINUE
                                                                               0837
      CALCULATE EFFECTIVE INCLASTIC STRAIN FOR EACH NUDE - INTERPOLATE
                                                                               0838
C
      IN TABLE (TSIGN VS. TEPSN)
                                                                               0839
      DO 181 18 = 1.NC
                                                                               0840
C
      SGBARP IS EFFECTIVE STRESS OF PREVIOUS CYCLE
                                                                               0841
      IF(SGBARN(18)-SGBARP(18))411,401,401
                                                                               0842
      EFFECTIVE STRESS IS ABOVE PREVIOUS LEVEL
                                                                               0843
      SGBARM IS EFFECTIVE STRESS OF LAST CYCLE TO SHOW AN INCREASE
                                                                               0844
```

```
401 IF(SGBARN(18)-SGBARM(18))411,402,402
      EFFECTIVE STRESS IS ABOVE KNEE OF PREVIOUS DROP-OFF, IF ANY
                                                                                2846
  402 IF(SGBARP(18)-SGBARM(18))403,403,403
                                                                                0847
  403 \text{ SGBARM(I8)} = \text{SGBARN(I8)}
                                                                                0848
      00 171 19 = 1.11
                                                                                0849
      ESUPRK =(SGBARN(18)/E) + EPBARP(18)
                                                                                7850
      IF(ESUPRK-TEPSN(19))173,1/2,1/1
                                                                                0851
  171 CUNTINUE
                                                                                0452
                                                                                0853
      GO TO 998
  172 BARSGN = TSIGN(19)
                                                                                0854
      IF(SGBARN(18)-TSIGN(21)170,177,171
                                                                                0855
  177 AL1212(18)= 2.*TALF12(19)
                                                                                0950
      AL1223(18) = TALF12(19) + TALF23(19)
                                                                                2857
      AL1231(18) = TALF12(19) + TALF31(19)
                                                                                0858
      ALFA44(18) = TALF44(19)
                                                                                0859
  178 CONTINUE
                                                                                0360
      GO TO 174
                                                                                0861
  173 \text{ KKK2} = 19
                                                                                0862
      KKK1 = 19 - 1
                                                                                0863
               = (ESUPRK-TEPSN(KKK1))/(TEPSN(KKK2)-TEPSN(KKK1))
      STNRAT
                                                                                0364
      BARSGN
               = TSIGN(KKK1)+(ISIGN(KKK2)-TSIGN(KKK1))*SINRAT
                                                                                0865
      IF(SGBARN(18)-TSIGN(2))170,175,175
                                                                                9999
  175 CONTINUE
                                                                                0867
      ALFA12
               = TALF12(KKK1)+(TALF12(KKK2)-TALF12(KKK1))*STNRAT
                                                                                0868
      ALFA23
               = TALF23(KKK1)+(TALF23(KKK2)-TALF23(KKK1))+STNRAT
                                                                                0869
               = TALF31(KKK1)+(TALF31(KKK2)-TALF31(KKK1))*STNRAT
      ALFA31
                                                                                0870
      ALFA44(18)=TALF44(KKK1)+(TALF44(KKK2)-TALF44(KKK1))*STNRAT
                                                                                0471
      AL1212(18) = 2. + ALFA12
                                                                                0972
      AL1223(18) = ALFA12 + ALFA23
                                                                                0873
      AL1231(18) = ALFA12 + ALFA11
                                                                                0874
  176 CONTINUE
                                                                                0875
      GO TO 174
                                                                                0876
  174 EPBARN(I8) = ESUPRK - BARSGN / E
                                                                                0877
      CALCULATE TOTAL EFFECTIVE STRAIN - MATRIX TEFSTN - FRAME SIZE 55X1
C
                                                                                0878
      TEFSTN(18) = ESUPRK
                                                                                0879
  415 TEFSTN(18) = TEFSTN(18) + EPCNK(18)
                                                                                0880
      CALCULATE EFFECTIVE STRAIN CHANGES - MATRIX DELEPH - FRAME 55 X 1
                                                                                0881
                                                                                0882
      CALCULATE INCREMENTAL EFFECTIVE INCLASTIC STRAIN
      DELEPN(18) = EPBARN(18) - EPBARP(18)
                                                                                0883
      GO TO (420,425), J24
                                                                                0884
  425 DELEPN(18) = DELEPN(18) + EPCNK(18) - EPCNP(18)
                                                                                0885
  420 CONTINUE
                                                                                0886
      GO TO 181
                                                                                C887
      DROP-OFF OF EFFECTIVE STRESS
                                                                                0888
      OR STILL BELOW THE KNEE UP PREVIOUS DROP-OFF
                                                                                DRRO
  411 EPBARN(18) = EPBARP(18)
                                                                                0990
      TEFSTN(18) = EPBARP(18)+(SGBARN(18)/E)
                                                                                0891
      TEFSTN(18) = TEFSTN(18) + EPCNK(18)
                                                                               0892
      DELEPN(18) = 0.0
                                                                               0893
      GO TO (424,426), J24
                                                                               0894
  426 DELEPH(IB) = EPCNK(IB) - EPUNP(IB)
                                                                               0895
 424 CONTINUE
                                                                               0896
      GO TO 181
                                                                               0897
  181 CONTINUE
                                                                               0898
      IF(KLU2+KLU8)266,266,267
                                                                               0899
 266 CONTINUE
                                                                               0900
```

```
C
      LABEL = EFF.PLASTIC STRAIN
                                                                                0901
                                                                                0902
      FA = 252626334743
A
                                                                                0903
8
      FB = 216263312360
      FC = 626351213145
                                                                                0904
                             NC.FA.Fb.FC.(EPBARN(J1).J1=1.NC)
                                                                                0905
      WRITE TAPE 8.KLU9.
                                                                                0906
  267 CONTINUE
      IF(KLU2)258,258,259
                                                                                0907
  258 CUNTINUE
                                                                                Dina
      LABEL = TOTAL EFF. STRAIN
8
      FA = 634663214360
                                                                                0910
В
      FB = 252626336062
                                                                                0911
      FC = 635121314560
                                                                                0912
A
      WRITE TAPE 8, KLU9,
                             NC, [A, Fb, Fc, (TEFSTN(J1), J1=1, NC)
                                                                                0913
  259 CONTINUE
                                                                                0914
      DD 862 I25=1.NC
                                                                                0915
  862 \text{ TEFSTN(125)} = 0.0
                                                                                0916
      CALCULATE NODE STRAIN CHANGE - MAIKIX DELEPK - FRAME SIZE 165 X 1
                                                                                0917
      DO 191 III = 1.NC
                                                                                0918
                        DELEPHILLIA SGBARN(III)
                                                                                0919
      TEMPA =
      M,3
                = 3*111
                                                                                0920
                = M3-2
                                                                                0921
      M32
                = M3-1
                                                                                0922
      DELEPK(M32)=TEMPA*(AL)231(111)*51GUK(M32)-.5*AL1212(111)*51GUK(M31
                                                                                0923
     1))
                                                                                0924
      DELEPK(M31)=TEMPA+(AL1223(111)+SIGUK(M31)-.5+AL1212(111)+SIGUK(M32
                                                                                0925
                                                                                0926
                                                                                0927
      DELEPK(M3) = TEMPA + (3. +ALPA + 4 + (1.11) + 5 + 1GUK(M3))
  191 CUNTINUE
                                                                                0928
      CALCULATE NODE PLASTIC STRAIN - MATRIX EPSUK - FRAME SIZE 165 X 1
C
                                                                                0929
      CALCULATE NODE POINT STRAINS
      DO 192 I23=1,NA
                                                                                0931
  192 EPSUK (123) = EPSUK (123) + DELEPK(123)
                                                                                0932
      IF(KLU2+KLU8)260,260,261
                                                                                0933
  260 CONTINUE
                                                                                0934
      LABEL = EFF.STRAIN CHANGES
                                                                                0935
      FA = 252626336263
A
                                                                                0936
8
      FB = 512131456023
                                                                                0937
      FC = 302145272562
                                                                                0938
8
      WRITE TAPE 8, KLU9,
                             NC, FA, FB, FC, (DELEPN(J1), J1=1, NC)
                                                                                0939
C
      LABEL = NUDE STRAIN CHANGE
                                                                                0940
      FA = 454624256062
                                                                                0941
8
      F8 = 635121314560
                                                                                0942
8
      FC = 233021452725
                                                                                0943
B
      WRITE TAPE 8, KLU9,
                             NA,FA,FB,FC,(DELEPK(J1),J1=1,NA)
                                                                                0944
      LABEL = NUDE INELAS.STRAIN >
                                                                                0945
      FA = 454624256031
                                                                                0946
В
      FB = 452543216233
                                                                                0947
a
      FC = 626351213145
                                                                                0948
      WRITE TAPE 8.KLU9.
                              NA, FA, Fb, FC, (EPSUK (J1), J1=1, NA)
                                                                                0949
  261 CONTINUE
                                                                                0950
      CALCULATE TOTAL NODE STRAINS - MATRIX TOTEPS - FRAME SIZE 165 X 1
                                                                                0951
      DO 201 I14=1,NC
                                                                                0952
      M32 = 3*I14-2
                                                                                0953
      M31 = 3 + [14 - 1]
                                                                                0954
      M3 = 3*114
                                                                                0955
      TOTEPS(M32)=EPSUK (M32)+SIGUK(M32)/E -GNU+SIGUK(M31)/E
                                                                                0956
```

	TOTEPS(M31)=EPSUK (M31)+51gUK(M31)/E -GNU+SIGUK(M32)/E	0957
20	1 TOTEPS(M3)=EPSUK (M3)+SIGUK(M3)/SHRMOD	0958
	1F(KLU2)262,262,263	0951
26	2 CUNTINUE	0960
נ בי	LABEL = TOT. NUDE STRAINS	096
8	FA = 634663336045	0462
ò	FB = 462425606263	0963
B	FC = 512131456260	0964
-	WRITE TAPE 8,KLU9, NA,FA,FB,FL,(TUTEPS(J1),J1=1,NA)	0965
24	3 CONTINUE	0966
۷0.	IF(KLU2)268,268,269	0967
24		0968
20	8 CONTINUE	0969
	KLU9 = 3	
	KLUSIZ = 2	0970
	WRITE TAPE 8, KLU9, KLUSIZ, K.PM.PM.PM.TIME	0971
	IF(NINCLD)269,269,273	0972
27	3 CONTINUE	0973
	KLU9 = 4	0974
٠.	KLUSIZ = 2	0975
	WRITE TAPE 8,KLU9,KLUSIZ,PM,PM,PM,MINKCY,NINTOT	0976
26	9 CUNTINUE	0977
	1F(NINCLD)370,370,371	0978
37	1 IF(NINCSW-2)422,370,422	0979
370	O CONTINUE	0980
	IFISENSE SWITCH 61421,422	6981
422	2 CONTINUE	0982
	GO TO 151	0983
42	1 IF(KLU2)423,423,208	0984
	3 CUNTINUE	0985
_	5 KLU9 = 7	0986
3	FA = 17777777777	0987
_	00 204 125 - 1 10	0988
20/	DU 206 125 = 1,10 6 WRITE TAPE 8,KLU9,KLU9,FA:FA:FA:FA:FA:FA:FA:FA:FA:FA:FA	0989
200	END FILE 8	0990
	END FILE 8	0991
	END FILE 8	0992
	FMS ET E O	0993
	END FILE 8	0993
	END FILE 8	0999
	REWIND 8	0996
201	IF(SENSE SWITCH 6)207,209	0997
	9 IF(J24-3)210,207,210	0998
20	7 CONTINUE	0999
	PAUSE 1	1000
	REWIND 11	1001
	CALL CHAIN(5,3)	1002
210	D CONTINUE	1003
	CALL CHAIN(6,3)	1004
208	B KERRSW = 2	1005
•	KERRSW SET TO 2 TO MAKE KLUZ = 0 AND PRINT A CYCLE	1006
	GO TO 151	1007
948	B KLU9 = 6	1008
	KLUSIZ = 3	1009
	WRITE TAPE 8,KLU9,KLUSIZ, K,18,PM,ESUPRK,SGBARN(18),TIME	1010
	GO TO 205	1011
	GO TO 205 END(1,1,0,0,0,0,1,1,0,1,0,0,0,0)	
3	LIST8	1013

	SUBROUTINE OUTPUT(VALUE1, STEP1, KLUL)	· ·	1
	THIS SUBROUTINE SETS KLUL = 0 IF THE	CURPENT CYCLE IS TO BE P	RINTED !
	VALUE = ABSF(VALUE1)		
	STEP = ABSF(STEP1)		1
102	IF(VALUE-STEP)131,100,100		
100	NTEST1 = (VALUE/STEP)*1.00001		
	NTEST2 = (VALUE/STEP)+.998		
	IF(NTEST1-NTEST2)131,130,131	,	
130	KLU1 = 0	*	
•	GO TO 135	•	
131	KLU1 = 1	•	
-,	RETURN		
	END(1,1,0,0,0,0,1,1,0,1,0,0,0,0,0)	• :	
	CHAIN(5,3)		•
	L1218		

<u>C451</u>	285 MATRIX ANALYSIS OF INCLASTIC PLATE - LINK 5 - WITH CREEP	1030
;	THIS LINK WRITES A SAVE TAPE FUR RESTART	1031
	CONNON TEFSTN, TOTEPS	1032
	COMMON KEU4, KEU3, KLU6, KEU8, NA, NC, K	1033
	COMMON KERRSW, NINCLD, KSET, PM, E, GNU, SHRMOO COMMON ALPHA, BETA, GAMMA, TIME, KLUISO	1034
	COMMON PHTH, KPMTM, SIM, SIJ, TSIGN, TEPSN	1036
-	COMMON TALF12, TALF23, TALF31, TALF44	1037
	COMMON AL1212, AL1223, AL1231, ALFA44	1038
	DIMENSION TALF12(11), TALF23(11), TALF31(11), TALF44(11)	1039
	DIMENSION AL1212(55), AL1223(55), AL1231(55), ALFA44(55)	
	COMMON SIGUK, EPSUK	1041
	COMMON SGBARN, SGBARP, SGBARN, EPBARN, EPBARP, DELEPN	1042
	COMMON EPCNK. EPCNP EQUIVALENCE (TIMK1, TEFSTN), (TOTEPS, DELEPK)	1043 1044
	THESE FOUR ARRAYS ARE EQUIVALENCED TO SAVE CORE SPACE.	1045
:	DIMENSION TIMK1(55), TEFSTN(55), TOTEPS(165), DELEPK(165)	1046
•	DIMENSION PHTM(10,3), KPMTM(10), SIM(165), SIJ(165,165), TSIGN(11)	1047
	DIMENSION TEPSN(11), SIGUK(165), EPSUK(165), SGBARN(55), SGBARP(55)	1048
	DIMENSION SGBARM(55), EPBARN(55), EPBARP(55), DELEPN(55), EPCNK(55)	1049
	DIMENSION EPCNP(55)	1050
	DEMIND 11	1051
	WRITE OUTPUT TAPE 11.33	1052
	END FILE 11 WRITE TAPE 11.KLU4.KLU5.KLU6.KLU8.NA.NC.K.KERRSW.NINCLD.KSET.PM.E.	1053 1054
•	IGNU, SHRMOD, ALPHA, BETA, GAMMA, TINE, KLUISO	1059
	WRITE TAPE 11, PMTM	1056
	WRITE TAPE 11.KPMTM	1057
	WRITE TAPE 11,SIM	1058
	WRITE TAPE 11,SIJ	1059
	WRITE TAPE 11.TSIGN	1060
	WRITE TAPE 11 TALES IN	1061
	WRITE TAPE 11, TALF12 WRITE TAPE 11, TALF23	1062
	WRITE TAPE 11, TALF31	1064
	WRITE TAPE 11, TALF44	1065
	WRITE TAPE 11,AL1212	1066
	WRITE TAPE 11,AL1223	1067
	WRITE TAPE 11.AL1231	1068
	WRITE TAPE 11,ALFA44 WRITE TAPE 11,SIGUK	1069 1070
	WRITE TAPE 11.EPSUK	1071
	WRITE TAPE 11.SGBARN	1072
	WRITE TAPE 11,5GBARP	1073
	WRITE TAPE 11, SGBARM	1074
	WRITE TAPE 11, EPBARN	1075
	WRITE TAPE 11, EPBARP	1076
	WRITE TAPE 11,DELEPN WRITE TAPE 11,EPCNK	1077 1078
	WRITE TAPE 11, EPCNP	1079
	END FILE 11	1080
	END FILE 11	1801
	END FILE 11	1082
	SUBROUTINE RUN REWINDS AND UNLOADS THE DESIGNATED TAPE	1083
	CALL RUN (11)	1084
	PRINT 32	1085
	KERRSW = 5	1086
	CALL CHAIN(6.3)	1087
32	FORMAT(//52H * * * SAVE TAPE A-6 FUR RESTART AT THIS POINT * * *) FORMAT(67HCONTIN 99 SAVE THIS TAPE FOR RERUN DECK 45128 INELAST	1088
_33		1089
	IIC ANALYSIS)	1090
	END(1,1,0,0,0,0,1,1,0,1,0,0,0,0,0)	
	CHAIN(6,3)	1092
		1093

```
451280 GRUMMAN AIRCRAFT ENGINEERING CURP.
                                               DECK NU. 45128
C451286 MATRIX ANALYSIS OF INCLASIAL PLATE - LINK 6 - WITH CREEP
                                                                               1095
      THIS LINK CUNVERTS BINARY JUIPUL ON TAPE 8 TO HCD
                                                                               1096
      ON THE MONITOR PRINT TAPE
                                                                               1097
      CUMMON TEFSIN, TOTEPS
                                                                               1048
                        KLU5,
                                                   NA.
                                                           NC .
      COMMON
               KLU4.
                                KLUO.
                                        KLU8,
                                                                               1099
                                                   Ę,
      COMMON KERRSH, NINCLD,
                                                          GNU, SHRMOJ
                                KsEf,
                                          PH.
                                                                               1100
             ALPHA.
                        SETA.
                              GAMMA.
                                        TIME, KLUISO
                                                                               1101
      DIMENSION TEFSTN(55), TOTEPS(105)
                                                                               1102
      DIMENSION ARRAY(165), LISI(105)
                                                                               1103
      EQUIVALENCE (FA, IFA), (Fb, & Fb), (FL, IFC), (ARRAY, LIST)
                                                                               1104
      REWIND 8
                                                                               1105
  101 READ TAPE 8,KLU9,KLUSIZ,Fa,Fa,Fc,(ARR ( (J1),J1=1,KLUSIZ)
                                                                               1106
      IF(KLU9)101,101,106
                                                                               1107
  106 IF(KLU9-9)111,111,101
                                                                               1108
 111 GO TO(121,122,123,124,125,126,127,128,129),KLU9
                                                                               1109
 121 CUNTINUE
                                                                               1110
      WRITE OUTPUT TAPE 6,22, FA, FB, FC, ARRAY(1), ARRAY(2)
                                                                               1111
      GU TO 101
                                                                               1112
  122 CONTINUE
                                                                               1113
      WRITE OUTPUT TAPE 6,21, FA, FB, FC, (ARRAY(J1), J1=1, KLUSIZ)
                                                                               1114
      GO TO 101
                                                                               1115
  123 CUNTINUE
                                                                               1110
      WRITE OUTPUT TAPE 6,31,1FA,AKKAY(1),ARRAY(2)
                                                                               1117
      GU TO 101
                                                                               1118
  124 CONTINUE
                                                                               1119
      WRITE OUTPUT TAPE 6,32,LIST(1),LIST(2)
                                                                               1120
      GO TO 101
                                                                               1121
 126 CONTINUE
                                                                               1122
      WRITE OUTPUT TAPE 6,12, ARRAY(1), ARRAY(2)
                                                                               1123
      WRITE OUTPUT TAPE 6,13,1FA,1Fb,FC,ARRAY(3)
                                                                               1124
      GO TO 101
                                                                               1125
  127 CONTINUE
                                                                               1126
      PRINT 14
                                                                               1127
      WRITE OUTPUT TAPE 6,14
                                                                               1128
      REWIND 8
                                                                               1129
      IF(KERRSY-5)132,131,132
                                                                               1130
  131 PRINT 33
                                                                               1131
  132 CALL EXIT
                                                                               1132
  125 CONTINUE
                                                                               1133
  128 CONTINUE
                                                                               1134
  129 CONTINUE
      GO TO 101
                                                                               1136
   12 FORMAT(46H VALUE NOT FOUND IN TABLE FOR EPSILON BAR N = , £15.8,
                                                                               1137
     119H ( SIGNA BAR N = ,E15.8,2H ) )
                                                                               1138
   13 FORMAT(16H CYCLE NUMBER = ,15,20H
                                            ELEMENT INDEX = ,14,17H
                                                                               1139
                             TIME = .F8.4)
     1AD LEVEL = ,F9.2.11H
                                                                               1140
   14 FORMAT(76H DO NOT SAVE TAPÉ B-1 - IT HAS BEEN COMPLETELY PROCESSED
                                                                               1141
     1 ONTO THE PRINT TAPE)
                                                                               1142
   21 FORMAT(// 1x,3A6,5(1PE16.7)/(19x,5E16.7))
                                                                               1143
   22 FURMAT(//1x,3A6,2x,F12.2,5x,6HflMc =,F12.6)
                                                                               1144
   31 FORMATIZHO ,16,27H CYCLES COMPLETED - LOAD = ,F 9.2.
                                                                               1145
                 12H
                         TIME = ,F 8.4)
                                                                               1146
   32 FORMAT(1H+,68X,6HCYCLE ,13,4H OF ,13,27H AT THIS LUAD OR TIME LEVE
                                                                               1147
                                                                               1148
   33 FORMAT(//52H * * * SAVE TAPE A-o FOR RESTART AT THIS POINT * * *)
                                                                               1149
      END(1,1,0,0,0,0,1,1,0,1,0,0,0,0,0)
```

DATA

APPENDIX VI

STRESS DISTRIBUTIONS DUE TO UNIT INITIAL STRAINS

The basic matrix utilized in the nonlinear and inelastic analysis described in this report is the initial strain influence coefficient matrix $[\Gamma_{uv}]$. Elements of this matrix provide the u^{th} stress component caused by a unit initial strain at the v^{th} stress location. The first description and derivation of this useful matrix was made by Denke in 1954, Reference 20. The matrix is generated by a structural analysis which may be of the force or stiffness type.

A. Force Method Application

The method utilized here is a simple extension of redundant structure analysis. Essentially, the additional work involved is the calculation of displacements at the applied loads and redundants in the statically determinant structure caused by initial strains. These displacements are combined with those caused by the applied loads and redundants. The final step is to adjust the magnitude of the redundants to eliminate the total displacements at the redundants. From this point the determination of stress distributions for the redundant structure is carried out as before.


The displacement in the statically determinate structure at the tth applied load or redundant due to initial strain can be expressed by use of the principle of virtual work as follows:

$$\alpha_{tv} = \sum_{a} \int (\sigma_{xt} \cdot \epsilon_{xv}) dV$$
Volume of
ath member

In the above expression, α_{tv} is the displacement at the t^{th} unit applied load or redundant due to the v^{th} initial strain, σ_{xt} is the direct stress in the a^{th} member due to the unit load, and ϵ_{xv} is the initial strain in the a^{th} member at the corresponding stress point. The summation \sum_{a} indicates that the virtual work in all members affected by the induced strain, ϵ_{xv} must be considered.

Equation A-1 is written for the uniaxial direct stress condition that is commonly assumed to exist in bar members as pictured in Figure (1). The effect of a shear panel has been omitted in the derivation for simplicity. Terms necessary for inclusion of shear may be derived in a similar manner.

Suppose that the ath member of a structure is a bar, with cross sectional area A, linearly varying axial load $\sigma_{\rm xt}$.A, and linearly varying initial strain $\epsilon_{\rm xv}$.



Then

$$\sigma_{xt} = \frac{1}{A} \left\{ \gamma_{1t} (1 - \frac{x}{Z}) + \gamma_{2t} \frac{x}{Z} \right\}$$

$$\epsilon_{xv} = \epsilon_{1v} (1 - \frac{x}{Z}) + \epsilon_{2v} \frac{x}{Z}$$

and after evaluation

$$\int_{\mathbf{x}_{\mathbf{t}} \cdot \mathbf{c}_{\mathbf{x}_{\mathbf{v}}} dV} = \begin{bmatrix} \gamma_{1t} & \gamma_{2t} \end{bmatrix} \begin{bmatrix} \mathbf{L}_{\mathbf{a}_{11}} & \mathbf{L}_{\mathbf{a}_{12}} \\ \mathbf{L}_{\mathbf{a}_{21}} & \mathbf{L}_{\mathbf{a}_{22}} \end{bmatrix} \begin{Bmatrix} \epsilon_{1v} \\ \epsilon_{2v} \end{Bmatrix}$$
Volume of ath member

where

$$L_{a_{11}} = L_{a_{22}} = \frac{2}{3}$$
 $L_{a_{12}} = L_{a_{21}} = \frac{2}{6}$

The $L_{a_{i,j}}$ matrix can be similarly determined for other types of structural elements. For rectangular shear panels, of dimensions b and h, it can be shown that the $L_{a_{i,j}}$ factor for shear strain γ_{xy} , is bh, the panel flat plate area. For nonorthogonal structure (swept panels) other $L_{a_{i,j}}$ factors may be developed. The sum of such matrices for the entire structure is designated $[L_{i,j}]$.

The matrix expression for the displacements at all of the applied loads and redundants due to unit initial strain is

$$\begin{bmatrix} \frac{\alpha}{\alpha} \underline{m} \underline{v} \\ \frac{\alpha}{\alpha} \underline{r} \underline{v} \end{bmatrix} = \begin{bmatrix} \gamma_{im} & \gamma_{ir} \end{bmatrix}^{T} \begin{bmatrix} L_{iv} \end{bmatrix}$$
 A-2

The $\epsilon_{\mathbf{V}}$'s are the initial strains corresponding to each of the member loads q..

Utilizing Equation A-2, the redundants are evaluated by

$$\begin{bmatrix} \alpha_{rm} & \alpha_{rv} & \alpha_{rs} \end{bmatrix} \begin{pmatrix} P_{m} \\ e_{v} \\ q_{g} \end{bmatrix} = 0$$

the solution of which is

$$\left\{q_{\mathbf{g}}\right\} = \left[\Gamma_{\mathbf{gm}} \mid \Gamma_{\mathbf{gv}}\right] \left\{\frac{P_{\mathbf{m}}}{\epsilon_{\mathbf{v}}}\right\}$$

where

$$\begin{bmatrix} \Gamma_{\text{sm}} & \Gamma_{\text{sv}} \end{bmatrix} = - \begin{bmatrix} \alpha_{\text{rs}} \end{bmatrix}^{-1} \begin{bmatrix} \alpha_{\text{rm}} & \alpha_{\text{rv}} \end{bmatrix}$$

The member loads in the redundant structure become

$$\left\{ q_{1} \right\} = \left[\Gamma_{im} \mid \Gamma_{iv} \right] \left\{ \frac{P_{m}}{\epsilon_{v}} \right\}$$
 A-3

where

$$\begin{bmatrix} \Gamma_{im} & \Gamma_{iv} \end{bmatrix} = \begin{bmatrix} \gamma_{im} & \gamma_{ir} \end{bmatrix} \begin{bmatrix} I & O \\ \Gamma_{rm} & \Gamma_{rv} \end{bmatrix}$$

Member stresses are obtained by pre-multiplying member loads by $[\beta_{ui}]$, the reciprocal values of appropriate bar areas and skin gages.

$$\begin{bmatrix} \Gamma_{um} \mid \Gamma_{uv} \end{bmatrix} = \begin{bmatrix} \beta_{ui} \end{bmatrix} \begin{bmatrix} \Gamma_{im} \mid \Gamma_{iv} \end{bmatrix}$$

$$\{ \sigma_{u} \} = \begin{bmatrix} \Gamma_{um} \mid \Gamma_{uv} \end{bmatrix} \{ \frac{P_{m}}{\epsilon_{v}} \}$$

$$A = \begin{bmatrix} \Gamma_{um} \mid \Gamma_{uv} \end{bmatrix} \{ \frac{P_{m}}{\epsilon_{v}} \}$$

then

Digital computer programs which are available for conventional force method analyses may be used to determine the $\Gamma_{\rm um}$, $\Gamma_{\rm uv}$ matrices. This is readily accomplished by redefining several input matrices.

(1) replace $[\gamma_{im}]$, the usual unit load distribution in the statically determinate structure due to applied loads by

$$\begin{bmatrix} \gamma_{\underline{1}\underline{m}} & 0 \\ 0 & 1 \end{bmatrix}$$
(21) x (m + 1)

the unit diagonal matrix I has as many elements as there are member loads in the structure.

(2) replace $[\gamma_{ir}]$, the usual unit load distribution in the statically determinate structure due to redundants by

$$\begin{bmatrix} \frac{y_{1r}}{0} \\ 0 \end{bmatrix}_{21 \times r}$$

(3) replace $[\alpha_{i,j}]$, the member flexibility matrix by

$$\begin{bmatrix} \mathbf{r}^{\mathbf{i}\mathbf{j}} & \mathbf{0} \\ \mathbf{r}^{\mathbf{i}\mathbf{v}} & \mathbf{0} \end{bmatrix}$$
 si x si


The L_{iv} values are the geometrical factors of Equation A-2. Straightforward matrix operation will now yield a load distribution matrix for the redundant structure which may be identified as follows:

$$\begin{bmatrix} \Gamma_{\underline{i}\underline{m}} & \Gamma_{\underline{i}\underline{v}} \\ 0 & 1 \end{bmatrix}$$

The upper portion $[\Gamma_{\underline{i}\underline{m}}\ ;\ \Gamma_{\underline{i}\underline{v}}]$ are the values defined by Equation A-3, and stresses may be obtained by using Equation A-4.

B. Direct Stiffness Method

Consider a truss shown in Figure (2a) where all the nodes are "locked" (prevented from displacing). If a strain ϵ_0 is induced in a



Derivation of $[\Gamma_{um}]$ and $[\Gamma_{u\tilde{V}}]$

Consider an element of the total structure, let this element be supported in a statically determinate fashion. The total strain ε is then written as the sum of two strains namely $\varepsilon_{_{\rm C}}$ - the strains due to stresses, and $\varepsilon_{_{\rm C}}$ - a set of induced strains. Thus

$$\{e\} = \{e_{o}\} + \{e_{o}\}$$
 B-1

Rewriting this,

$$\{e_{\sigma}\} = \{e\} - \{e_{\sigma}\}$$
 B-2

The stresses may be expressed in terms of the strains by using Hooke's law.

$$\{\sigma\} = [b]\{\epsilon_{\sigma}\}$$
 B-3

Thus

$$\{\sigma\} = [b]\{\epsilon\} - [b]\{\epsilon_0\}$$
 B-4

 $\{\varepsilon\}$ (the total strains) may be expressed in terms of the displacements of the nodes that affect the particular member in question. That is

$$\{e\} = [a]\{\delta\}$$
 B-5

It should be noted that the expression contains the basic assumption governing the behavior of the element. For example, for a triangle or bar element it will contain the assumption that the strains are constant throughout the element. Substituting this into Equation B-4

$$\{\sigma\} = [b][a]\{\delta\} - [b]\{\epsilon_o\}$$
 B-6a

=
$$[s_d]{\delta} - [b]{\epsilon_0}$$
 B-6b

From virtual work it can be shown that the nodal forces $\{f\}$, associated with $\{\delta\}$, may be expressed in terms of the stresses by:

$$\{f\} = \int_{Vol} [a]^{T} \{\sigma\} dV$$
 B-7

Substituting B-6a into B-7 yields:

$$\{f\} = \int_{V_{01}} [a]^{T}[b][a]\{\delta\} dV - \int_{V_{01}} [a]^{T}[b]\{\epsilon_{0}\} dV \qquad B-8$$

For simple elements such as bars or triangles where the strains are assumed to be constant over the element none of the matrices within the integrals will be functions of the coordinates x, y or z and hence they are independent of the integration. The first portion of (B-8) yields the standard stiffness matrix [k] while the second portion yields the nodal forces due to induced strains $\{e_0\}$.

$$\{f\} = [k]\{\delta\} - V[a]^{T}[b]\{\epsilon_{0}\}$$
B-9

In this expression, V is the volume of the element. Noting that $[a]^T[b] = [b][a]^T = [s_d]^T$ yields

$$\{f\} = [k]\{\delta\} - V[s_d]^T\{\epsilon_0\}$$
 B-10

The total stiffness matrix for the entire structure is obtained by superposing the stiffnesses for the individual elements to yield:

$$\{F\} = [K]\{\Delta\} - [S_d]^T[V]\{\epsilon_{OT}\}$$
 B-11

Where $\{F\}$ represents all of the external nodal forces, $\{\Delta\}$ represents all of the nodal displacements, $\{\varepsilon_{OT}\}$ represents a column of all the induced strain components and [V] is a diagonal matrix containing the values of the volumes of the various elements. (Note that for a triangle, where three strain components may be induced, the volume will appear three times). $[S_d]$ is the total stress matrix array which is obtained by proper arrangement of the individual stress matrices $[s_d]$.

Applying boundary conditions (via matrix [BC]) to equation (B-11) and introducing the applied external loads {P}, with nodal distribution [L], yields:

$$[L]{P} = [BC]^{T}[K][BC]{\Delta'} - [BC]^{T}[S_{d}]^{T}[V]{\epsilon_{OT}}$$
 B-12

which may be solved to give the allowed nodal displacements under the boundary conditions:

$$\{\Delta'\} = [K_{11}]^{-1}[L]\{P\} + [K_{11}]^{-1}[BC]^{T}[S_{d}]^{T}[V]\{\epsilon_{oT}\}$$
 B-13

where

$$[K_{11}] = [BC]^{T}[K][BC]$$

For the total structure, B-6b may be written as:

$$\{\sigma_m\} = [S_a]\{\Delta\} - [B]\{\epsilon_{cm}\}$$
 B-14

where [B] is a diagonal block of the elastic relations [b] for each member. Substituting (B-13) into (B-14) and using the relation $\{\Delta\}$ = [BC] $\{\Delta'\}$ yields:

$$\{\sigma_{\mathbf{T}}\} = [s_{\mathbf{d}}][BC][K_{11}]^{-1}[L]\{P\}$$

$$+ \left[[s_{\mathbf{d}}][BC][K_{11}]^{-1}[BC]^{\mathbf{T}}[s_{\mathbf{d}}]^{\mathbf{T}}[V] - [B]\right]\{\epsilon_{\mathbf{OT}}\}$$

$$B-15$$

which, to use the previous notation, may be written as:

$$\{\sigma_{\mathbf{u}}\} = [\Gamma_{\mathbf{u}\mathbf{m}}]\{P_{\mathbf{m}}\} + [\Gamma_{\mathbf{u}\mathbf{v}}]\{e_{\mathbf{v}}\}$$
 B-16

The first matrix, $[\Gamma_{um}]$, of this expression, is the conventional distribution obtained for unit applied loads as indicated in Section A of this appendix.

REFERENCES

- Denke, P. H., <u>Digital Analysis of Plasticity in Plates</u>, Appendix C of "Effects of Compressive Loads on Structural Fatigue at Elevated Temperatures," Technical Document Report ASD-TDR-62-448, October 1962.
- 2. Kobayashi, A. S. and Weikel, R. C., "A Method of Estimating Creep Deformations and Stress Relaxations in Plane Structures" The Trend in Engineering, October 1961.
- 3. Gallagher, R. H., Padlog, J., and Bijlaard, P. P., "Stress Analysis of Heated Complex Shapes," ARS Journal, Volume 32, No. 5, pages 700-707, May 1962.
- 4. Padlog, J., Huff, R. D., and Holloway, F. G., <u>Unelastic Behavior of Structures Subjected to Cyclic Thermal and Mechanical Stressing Conditions</u>, WADD Technical Report 60-271, December 1960.
- 5. Manson, S. S., "Thermal Stresses in Design," Machine Design, Parts 11, 12, and 13, July 9, July 23, August 6, 1959.
- 6. Mentel, T. J., Comparison of Matrix Methods for Inelastic Structural Analysis, Grumman Advanced Development Report No. ADR 02-11-64.1, February 1964.
- Percy, J. H., Loden, W. A., and Navaratna, D., <u>A Study of Matrix</u>
 Analysis Methods for Inelastic Structures, Air Force Systems Command,
 Technical Document Report No. RTD-TDR-63-4032, October 1963.
- 8. Turner, M. J., The Direct Stiffness Method of Structural Analysis, Paper presented at the AGARD Structures and Material Panel Meeting, Aachen, Germany, September 1959.
- Turner, M. J., Martin, N. C., and Weikel, R. C., "Further Development and Applications of the Stiffness Method," from Text, Matrix Methods of Structural Analysis edited by F. de Veubeke, Macmillan Company, New York, 1964.
- Hill, R., The Mathematical Theory of Plasticity, Clarendon Press, Oxford, 1950.
- 11. Hu, L. W., "Studies on Plastic Flow of Anisotropic Metals," Journal of Applied Mechanics, September 1956.
- 12. Argyris, J. H., "Energy Theorems and Structural Analysis," Butterworth's Scientific Publications, London, England, 1960.
- 13. Falby, W. E., and Zalesak, J., Comparison of Matrix Force and Direct Stiffness Methods of Redundant Structure Analysis, Grumman Advanced Development Report No. ADR 02-11-65.1, January 1965.

- 14. Griffith, G. E., Experimental Investigation of the Effects of Plastic Flow in a Tension Panel with a Circular Hole, NACA TN No. 1705, September 1948.
- 15. Jones, I. W., Some Refinements to Wing Redundant Structure Analysis Methods, Grumman Advanced Development Report No. ADR 04-03b-61.3.
- 16. Mendelson, A., and Manson, S. S., <u>Practical Solutions of Plastic Deformation Problems in Elastic-Plastic Range</u>, NACA TN 4088, September 1959.
- 17. Mentel, T. J., On Evaluation of Matrix Methods for Nonlinear Biaxial Stress Analysis, Grumman Advanced Development Report No. ADR 02-11-64.2, June 1964.
- 18. Millenson, M. B., and Manson, S. S., <u>Determination of Stresses in Gas Turbine Disks Subjected to Plastic Flow and Creep</u>, NACA Report No. 906, 1948.
- 19. Lansing, W., Jensen, W. R., and Falby, W. E., Matrix Analysis Methods for Inelastic Structures, Grumman Advanced Development Report No. ADR 02-11-65.4, November 1965. Presented at conference on "Matrix Methods in Structural Mechanics," October 26-28, 1965 at the Air Force Institute of Technology, Wright-Patterson Air Force Base, Dayton, Ohio.
- 20. Denke, P. H., "A Matrix Method of Structural Analysis," Proceedings of the Second U. S. National Congress of Applied Mechanics, June 1954.

A number of the references were traced by a machine search of NASA and Department of Defense holding under the following headings:

- 1) Anisotropic plasticity of metals
- 2) Anisotropic creep of metals
- 3) Bauschinger effect of metals
- 4) Cyclic loading of metals

Security Classification

Security Chasatheatholi						
DOCUMEN	IT CONTROL DATA - R&	D	and the second s			
Geoughty elecetification of Hite, body of abstract and indexing amount on must be a something Activity (Corporate author) Grumman Aircraft Engineering Corporation		Ze REPORT SECURITY CLASSIFICATION Unclassified				
South Oyster Bay Road Bethpags, Long Island, New York			28 SROUP			
3. REPORT TITLE		<u></u>				
(U) MATRIX ANALYSIS METHODS FOR A	NISOTROPIC INELASTIC	C STRUC	TURES			
4. DESCRIPTIVE NOTES (Type of report and inclusive data Final technical report on work acc	complished from Jan	uary 19	65 to October 1965			
Jensen, W. R.; Falby, W. E.; Prince	ce, N.					
4 REPORT DATE April 1966			75. NO. OF REFS			
AUTH 1900 84. CONTRACT OR SRANT NO. AF 33(615)-2260	Se ORIGINATOR'S RE	9a. ORIGINATOR'S REPORT NUMBER(3) ADR 02-11-65-5				
A РИОЈЕСТ НО. 1467						
Task No. 146701	S& OTHER REPORT	35. OTHER REPORT MO(3) (Any other numbers that may be seeligned AFFDL-TR-65-220				
4	AFFDL-TR-65-2					
This document is subject to special foreign governments or foreign nat the AF Flight Dynamics Laboratory,	tionals may be made	only w	ith prior approval of			
11. SUPPLEMENTARY NOTES	Air Force Flig Research and I Air Force Syst	12. SPONSORING MILITARY ACTIVITY Air Force Flight Dynamics Laboratory Research and Technology Division Air Force Systems Cormand				
13. ABSTRACT	Wright-Patter	son Air	Force Base, Ohio 4543			
Most aerospace structural mat						

Most aerospace structural materials exhibit some degree of anisotropic strain hardening. A measure of anisotropy is introduced into structural elements by such febrication processes as drawing, cold rolling and extrusion. During the past few years, several methods have appeared in the literature for introducing inelastic isotropic material behavior effects into existing metrix analysis routines. A review is presented of one of these methods. It is essentially a step-by-step calculation procedure, and corresponds to the flow theory of plasticity. The method has been extended to include the effects of anisotropic material and is formulated as a standard initial strain influence coefficient problem. Several analyses of an aluminum alloy (2024-T4) shear lag structure which has been tested previously for the Air Force are carried out first assuming isotropic material properties and then anisotropic properties. The resulting correlation between test results and that predicted by isotropic theory is reasonably good.

An analysis of a 1100 aluminum shear lag structure, carried out by the incremental method, gave reasonably good agreement. However, the anisotropic creep capability was not checked for want of test data. The approach is a reasonably good phenomenological model of a complex physical problem. The digital computer program submitted is suited for inclusion of other material nonlinearity.

DD 1508M 1473

INCLASSIFIED
Security Classification

Security Classification

14.		LIN	LINK A		LINK D		LINK C	
	KEY WORDS		WT	ROLE	WT	ROLE	WT	
Anisotropic Plasticity of Metals Anisotropic Creep of Metals Matrix Structurel Analysis								
							,	
				1 1				
		-						
			ĺ				'	
			1					
	•							
			ľ				,	
				1. 1				
	,		<u> </u>	I			<u> </u>	

INSTRUCTIONS

- ORIGINATING ACTIVITY: Enter the name and address of the contractor, subcontractor, grantee, Department of Defense activity or other organization (corporate author) issuing the report.
- 2a. REPORT SECURITY CLASSIFICATION: Enter the overall security classification of the report. Indicate whether "Restricted Data" is included. Marking is to be in accordance with appropriate security regulations.
- 2b. GROUP: Automatic downgrading is specified in DoD Directive 5200. 10 and Armed Forces Industrial Manual. Enter the group number. Also, when applicable, show that optional markings have been used for Group 3 and Group 4 as authorized.
- 3. REPORT TITLE: Enter the complete report title in all capital letters. Titles in all cases should be unclassified. If a meaningful title cannot be selected without classification, show title classification in all capitals in parenthesis immediately following the title.
- DESCRIPTIVE NOTES: If appropriate, enter the type of report, e.g., interim, progress, summary, annual, or final. Give the inclusive dates when a specific reporting period is covered.
- 5. AUTHOR(3): Enter the name(a) of author(a) as shown on or in the report. Enter last name, first name, middle initial. If military, show rank and branch of service. The name of the principal author is an absolute minimum requirement.
- REPORT DATE: Enter the date of the report as day, month, year; or month, year. If more than one date appears on the report, use date of publication.
- 7a. TOTAL NUMBER OF PAGES: The total page count should follow normal pagination procedures, i.e., enter the number of pages containing information.
- 7b. NUMBER OF REFERENCES: Enter the total number of references cited in the report.
- 8a. CONTRACT OR GRANT NUMBER: If appropriate, enter the applicable number of the contract or great under which the report was written.
- 8b, 8c, & 8d. PROJECT NUMBER: Enter the appropriate military department identification, such as project number, subproject number, system numbers, task number, etc.
- 9a. ORIGINATOR'S REPORT NUMBER(S): Enter the official report number by which the document will be identified and controlled by the originating activity. This number must be usique to this report.
- 98. OTHER REPORT NUMBER(3): If the report has been assigned any other report numbers (either by the originator or by the aponeor), also exter this number(s).
- 10. AVAILABILITY/LIMITATION NOTICES: Enter any limitations on further dissemination of the report, other than those

imposed by security classification, using standard statements such as:

- (1) "Qualified requesters may obtain copies of this report from DDC."
- (2) "Foreign announcement and dissemination of this report by DDC is not authorized."
- (3) "U. S. Government agencies may obtain copies of this report directly from DDC. Other qualified DDC users shall request through
- (4) "*U. 3. military agencies may obtain copies of this report directly from DDC. Other qualified users shall request through
- (5) "All distribution of this report is controlled. Qualified DDC users shall request through

If the report has been furnished to the Office of Technical Services, Department of Commerce, for sale to the public, indicate this fact and enter the price, if known

- 11. SUPPLEMENTARY NOTES: Use for additional explana-
- 12. SPONSORING MILITARY ACTIVITY: Enter the name of the departmental project office or laboratory sponsoring (paying for) the research and development. Include address.
- 13. ABSTRACT: Enter an abstract giving a brief and factual summary of the document indicative of the report, even though it may also appear elsewhere in the body of the technical report. If additional space is required, a continuation sheet shall be attached.

It is highly desirable that the abstract of classified reports be unclassified. Each paragraph of the abstract shall end with an indication of the military security classification of the information in the paragraph, represented as (TS), (E), (C), or (U).

There is no limitation on the length of the abstract. However, the suggested length is from 150 to 225 words.

14. KEY WORDS: Key words are technically meaningful terms or short phrases that characterize a report and may be used as index entries for cataloging the report. Key words must be selected so that no security classification is required. Identifiers, such as equipment model designation, tude same, military project code same, geographic location, may be used as key words but will be followed by an indication of technical context. The assignment of links, rules, and weights is optional.

UNCLASSIFIED

DATE FILMED